

PHILIPS

Mobile Phone

Xenium

9@9m

CT9A9MSLV



Incredible battery life

Tablet phone

With Philips Xenium 9@9m, enjoy the ease of multimedia messaging and real freedom of always being connected - thanks to an incredibly long battery life. Its ultra-intuitive touch screen and handwriting recognition keep you on the lead.

Always on, always connected

- Up to 1 month of standby time
- Up to 8.5 hours of talk time

Multimedia - anytime, anywhere

- MP3 playback and ringtones for a superior audio experience
- Video capture and playback in MPEG4 and H263 format
- 2 megapixel digital camera for crisp, vivid pictures
- Mini SD card expansion slot for extra memory/data storage

Quick and easy messaging

- 2.5" 262K color TFT display for vivid, colorful graphics
- On-screen handwriting recognition
- Touch screen

Highlights

Up to 1 month standby time

The phone can be on and in standby mode continuously for up to 1 month on a single charge.

Up to 8.5 hours talk time

The phone can support up to 8.5 hours talk time on a single charge.

MP3 playback and ringtones

Use the data cable or an external memory card to transfer MP3 music files to your phone for a superior audio experience on the go. You can also personalize your ringtone with a selection from your MP3 files.

Video capture and playback

The video capture function lets you record precious moments in MPEG4 or H263 format. Play it back on your phone or PC.

Handwriting recognition

The intuitive and fast way to write text messages. Simply write on the touch screen as you would write on a piece of paper to have the phone convert your handwriting into an SMS (Short Message Service) text message. The feature has built-in handwriting recognition capability in both Chinese (traditional and simplified) and English (Roman alphabet).

Specifications

Power

Battery Capacity: 1280mAh Li-Polymer
Standby time: Up to 1 month
Talk time: Up to 8.5 hours
Battery saving manager: Auto switch on/off

Picture/Display

Diagonal screen size (inch): 2.5 inch
Main Display Colors: 262K
Main Display Resolution: 176x220 pixel
Main Display Technology: TFT
Touch panel

Dimensions

Antenna: Integrated
Form Factor: Candy bar
Handset color: Executive silver, Rusted brown
Handset dimensions: (105 x 50 x 17.3)mm
Handset weight: 109g (With battery) / 78g (Without battery)

Network Features

GSM band: 900, 1800, 1900 MHz
Voice Codec: FR/EFR/AMR
GPRS (Rx+Tx): Class 10 (4+2), Class B
Messaging: Concatenated SMS (Long SMS), E-mail, EMS / release 4, MMS, Multimedia Message Service, SMS CB (Cell Broadcast), SMS (Short Message Service), SMS multi-target
Services: OTA provisioning (WAP, MMS), SIM Toolkit / Release 99, WAP 2.0

Sound

Ringers: MP3 ringer, Polyphonic (40 tones)

Still Picture Capturing

Camera: Integrated
Digital zoom: 8x
Image sensor type: CMOS
Integrated flash
Picture resolution: VGA (640x480), 2M (1600x1200), 176x220, QVGA (320x240)
Picture quality: Normal, Fine, Superfine
Picture file format: JPEG
Preview frame rate: 15 frames/second
Picture Mode: Night mode, Self-timer mode, Multi-shot
Special effects preview mode: Sepia, Negative color, B&W, Red effect, Sketch, Solarize

Video Playback

Compression formats: MPEG4, H.263, 3GP
Resolution (pxl): 176x144, 352x288, 320x240
Frame rate (fps): 30

Video Recording

Compression formats: 3GP
Resolution (pxl): 176x144, 352x288
Frame rate: 15 fps

Audio Playback

Audio supported formats: AMR, Midi, MP3, SP-Midi

Audio Capturing

Voice recording: Yes, AMR

Audio Recording

Recording time: up to 30 minutes, up to 12 minutes per record

Convenience

Buttons and controls: 4-way navigation key and enter, Camera key, Side keys, Soft keys
Call Management: Call Cost, Call Counters, Call Forwarding, Call on Hold, Call Time, Call Waiting*, Caller ID*, Conference Call, Emergency Call, Explicit Call Transfer, Microphone mute, Missed Calls, Multi-party call, Received Calls
Ease of Navigation: Animated Color Matrix, Touch panel
Ease of Use: Hands free mode, Hot Keys, Keypad Lock, Screen Saver Digital Clock, Softkeys, Vibra Alert
Games and applications: Agenda, Alarm Clock, Calculator, Calendar, Java MIDP 2.0, Lunar Calendar, Chinese festival reminder, ENG-CHN and CHN-ENG dictionary, Handwriting recognition, International converter, Voice reminder if appointment, Sudoku game
Language available: UI: Chinese Simplified, Chinese Traditional, English, Indonesian, Thai, Vietnamese
Personal Info Management: Daylight saving, Time Zone, Smart Phonebook, Safeguard, International clock

Connectivity

Headset: Via mini USB connector
Modem Capabilities: CSD (Voice, Data), GPRS, SMS
Wireless connection: Bluetooth, Infrared
PC Link: USB 1.1
Bluetooth profiles: A2DP, Handsfree, Headset, Object push profile

Storage Media

User memory: 70 MB
Memory Card Types: mini Secure Digital (SD)
Memory management: Memory status, Dynamic memory allocation

Accessories

Standard Package Includes: Battery, CD ROM (Mobile Phone Tools), Charger, Stereo Headset, Stylus, User Manual, USB data cable, Handset

Green Specifications

Packaging material: Carton
Packaging type: Giftbox
Lead-free soldered product

