

# PHILIPS

Mobile Phone

535

CT5358



## Snap, Talk & Send

FotoTalk: add voice to your pictures

### Capture and share your life

- Integrated VGA digital camera
- Digitally zoom up to 4 times
- TFT display with 65,536 gorgeous colors

### Add Emotion to your Messages

- MMS (Multimedia Messaging Service)
- FotoTalk adds voice to your MMS pictures
- Special effects for creative picture personalization

### Maximize your Multimedia Experience

- Mix your own polyphonic melodies and ringtones with BeDJ
- 32-tone rich polyphonic melodies

# Highlights

## Integrated VGA digital camera

The integrated digital camera with VGA resolution (640x480 pixels) allows you to take high-quality pictures anytime, anywhere with your phone, then send them via MMS or email, or store the pictures in your phone's memory.

## Digital zoom x4

Easily zoom the picture in and out up to 4 times, composing better and more meaningful pictures by capturing the right detail from the overall scene. In preview mode, activate the zoom function to take pictures of distant objects or to concentrate attention on a specific part of the picture.

## 65K color TFT display

Brilliant 65K color TFT display offers high contrast and high brightness with 65,536 gorgeous colors and ultra fine pitch for clear, bright color graphics and photos.

## MMS messaging

MMS (Multimedia Messaging Service) allows you to use your mobile phone to send and receive pictures, video, and audio files with your text messages.

## FotoTalk

FotoTalk allows you to instantaneously send pictures and recorded voice messages via MMS to friends and family. Access the camera application via camera hard key or multimedia menu to choose FotoTalk, then take a picture, record your voice, and go to MMS to finalize and send the message.

## Special effects

Special effects provide you with several modifications that can be applied in order to personalize camera images: sepia, gray scale, edge, digital, embossed, or negative colors. Choose one of the special effects in camera

preview mode, take the picture, then save the photo in phone screen resolution format e.g. 128x160 pixels.

## BeDJ

The amazing BeDJ feature allows you to easily create, enjoy, and share your own music mixes anytime, anywhere for unlimited creativity with this real, portable mixing studio. Create your own sounds using predefined styles provided by famous international DJs, your phone's own polyphonic ring tones, or by downloading content via WAP, infrared, or MMS to mix up to 9 different tracks in real time.

## 32-tone polyphonic melodies

32-tone polyphonic melodies can create simultaneous tones of different notes using MIDI format for more natural and realistic musical results, sounding just like a small orchestra of different instruments for outstanding sound effects.



# Specifications

## Dimensions

Handset weight: 95  
 Antenna: Integrated  
 Form Factor: Candy bar  
 Handset dimensions: 101x44x19  
 Handset volume: 79  
 Handset Color: Black Motion, Red Lens, Blue Focus, Silver Digit

## Power

Battery Capacity: 720 mAh  
 Charging time: less than 2 hours hr  
 Standby time: up to 300 hrs  
 Talk time: up to 6 hrs  
 Battery Type: Lithium-ion

## Picture/Display

Brightness: 120 cd/m<sup>2</sup>  
 Lines of text: 8  
 Main Display Resolution: 128x128 pixel  
 Main Display Technology: TFT  
 Main Display Colors: 65536

## Sound

Ringers: Polyphonic (32 tones)

## Audio Playback

Audio supported formats: AMR, ADPCM, Midi, SP-Midi

## Audio Recording

Recording time: upto 60 seconds

## Audio Capturing

Voice recording: Yes, AMR

## Still Picture Playback

Picture Compression Format: BMP, GIF (87a & 89a), JPEG  
 Slide show: No

## Still Picture Capturing

Image sensor type: CMOS  
 Digital zoom: x2 and x4  
 Picture file format: JPEG  
 Picture Mode: Economy, Normal, Super fine  
 Special effects preview mode: Grey scale, Sepia, Blue effect  
 Camera: Integrated  
 Preview frame rate: 15 frames/second  
 Picture resolution: VGA (640x480)  
 Sensitivity: min 5 lux

## Connectivity

Headphone: 2.5 mm  
 Synchronisation PC organizer: Lotus Notes, MS Outlook  
 Wireless connections: Infrared  
 Modem Capabilities: CSD (Voice, Data), GPRS

## Convenience

Buttons and controls: 4-way navigation key and enter, Customized hot key  
 Call Management: Call Cost, Call Counters, Call Forwarding, Call on Hold, Call Time, Call Waiting\*, Caller ID\*, Conference Call, Emergency Call, Explicit Call Transfer, Microphone mute, Missed Calls, Multi-party call, Received Calls  
 Clock/Version: Analogue, Digital  
 Ease of Navigation: Animated Carroussel, Color Carroussel  
 Ease of Use: Blinking Lights, Dedicated Headset plug, Hands free mode, Hot Keys, Vibra Alert, Screen Saver Digital Clock  
 Ease To Experience: Demo Mode  
 Games and applications: Agenda, Alarm Clock, Calculator, Euro Converter, Infusio - Exen v2, Calendar  
 Personalisation/Customization: Downloadable Animated GIF, Downloadable Picture, Downloadable Ringtones, Exchangeable Covers, Fotocall, Screen Saver, Wallpaper  
 Volume control  
 Speech Recognition: Conversation Recording, Voice Command, Voice Dial, Voice Memo, Voice Recognition  
 Language available: UI: Chinese Simplified, Chinese Traditional, Czech, Danish, Dutch, English, Finnish, French, German, Greek, Hungarian, Hebrew, Indonesian, Italian, Lithuanian, Norwegian, Polish, Portuguese, Romanian, Russian, Slovak, Spanish, Swedish, Thai, Turkish  
 Language available: T9 input: Chinese Simplified, Chinese Traditional, Czech, Danish, Dutch, English, Finnish, French, German, Greek, Italian, Norwegian, Polish, Portuguese, Spanish, Swedish, Turkish  
 Multimedia: BeDJ, Foto Talk  
 Personal Info Management: Daylight saving, Time Zone, Smart Phonebook, Vcard Exchange  
 Embedded Games: 2

## Accessories

Optional accessories: Battery 720 mAh, Carry case, Cigarette lighter adapter, Deluxe headset, Exchangeable covers, Necklace, Universal car kit, Wrist wrap  
 Standard Package Includes: Battery, CD ROM (Mobile Phone Tools), Charger, Handset, International Guarantee, SAR information leaflet, User Manual

