

PHILIPS

Mobile Phone

535

CT5358



Snap, Talk & Send

FotoTalk: add voice to your pictures

Capture and share your life

- Integrated VGA digital camera
- Digitally zoom up to 4 times
- TFT display with 65,536 gorgeous colors

Add Emotion to your Messages

- MMS (Multimedia Messaging Service)
- FotoTalk adds voice to your MMS pictures
- Special effects for creative picture personalization

Maximize your Multimedia Experience

- Mix your own polyphonic melodies and ringtones with BeDJ
- 32-tone rich polyphonic melodies

Highlights

Integrated VGA digital camera

The integrated digital camera with VGA resolution (640x480 pixels) allows you to take high-quality pictures anytime, anywhere with your phone, then send them via MMS or email, or store the pictures in your phone's memory.

Digital zoom x4

Easily zoom the picture in and out up to 4 times, composing better and more meaningful pictures by capturing the right detail from the overall scene. In preview mode, activate the zoom function to take pictures of distant objects or to concentrate attention on a specific part of the picture.

65K color TFT display

Brilliant 65K color TFT display offers high contrast and high brightness with 65,536 gorgeous colors and ultra fine pitch for clear, bright color graphics and photos.

MMS messaging

MMS (Multimedia Messaging Service) allows you to use your mobile phone to send and receive pictures, video, and audio files with your text messages.

FotoTalk

FotoTalk allows you to instantaneously send pictures and recorded voice messages via MMS to friends and family. Access the camera application via camera hard key or multimedia menu to choose FotoTalk, then take a picture, record your voice, and go to MMS to finalize and send the message.

Special effects

Special effects provide you with several modifications that can be applied in order to personalize camera images: sepia, gray scale, edge, digital, embossed, or negative colors. Choose one of the special effects in camera

preview mode, take the picture, then save the photo in phone screen resolution format e.g. 128x160 pixels.

BeDJ

The amazing BeDJ feature allows you to easily create, enjoy, and share your own music mixes anytime, anywhere for unlimited creativity with this real, portable mixing studio. Create your own sounds using predefined styles provided by famous international DJs, your phone's own polyphonic ring tones, or by downloading content via WAP, infrared, or MMS to mix up to 9 different tracks in real time.

32-tone polyphonic melodies

32-tone polyphonic melodies can create simultaneous tones of different notes using MIDI format for more natural and realistic musical results, sounding just like a small orchestra of different instruments for outstanding sound effects.



Specifications

Dimensions

Handset weight: 95
Antenna: Integrated
Form Factor: Candy bar
Handset dimensions: 101x44x19
Handset volume: 79
Handset Color: Black Motion, Red Lens, Blue Focus, Silver Digit

Power

Battery Capacity: 720 mAh
Charging time: less than 2 hours hr
Standby time: up to 300 hrs
Talk time: up to 6 hrs
Battery Type: Lithium-ion

Picture/Display

Brightness: 120 cd/m²
Lines of text: 8
Main Display Resolution: 128x128 pixel
Main Display Technology: TFT
Main Display Colors: 65536

Sound

Ringers: Polyphonic (32 tones)

Audio Playback

Audio supported formats: AMR, ADPCM, Midi, SP-Midi

Audio Recording

Recording time: upto 60 seconds

Audio Capturing

Voice recording: Yes, AMR

Still Picture Playback

Picture Compression Format: BMP, GIF (87a & 89a), JPEG
Slide show: No

Still Picture Capturing

Image sensor type: CMOS
Digital zoom: x2 and x4
Picture file format: JPEG
Picture Mode: Economy, Normal, Super fine
Special effects preview mode: Grey scale, Sepia, Blue effect
Camera: Integrated
Preview frame rate: 15 frames/second
Picture resolution: VGA (640x480)
Sensitivity: min 5 lux

Connectivity

Headphone: 2.5 mm
Synchronisation PC organizer: Lotus Notes, MS Outlook
Wireless connections: Infrared
Modem Capabilities: CSD (Voice, Data), GPRS

Convenience

Buttons and controls: 4-way navigation key and enter, Customized hot key
Call Management: Call Cost, Call Counters, Call Forwarding, Call on Hold, Call Time, Call Waiting*, Caller ID*, Conference Call, Emergency Call, Explicit Call Transfer, Microphone mute, Missed Calls, Multi-party call, Received Calls
Clock/Version: Analogue, Digital
Ease of Navigation: Animated Carroussel, Color Carroussel
Ease of Use: Blinking Lights, Dedicated Headset plug, Hands free mode, Hot Keys, Vibra Alert, Screen Saver Digital Clock
Ease To Experience: Demo Mode
Games and applications: Agenda, Alarm Clock, Calculator, Euro Converter, Infusio – Exen v2, Calendar
Personalisation/Customization: Downloadable Animated GIF, Downloadable Picture, Downloadable Ringtones, Exchangeable Covers, Fotocall, Screen Saver, Wallpaper
Volume control
Speech Recognition: Conversation Recording, Voice Command, Voice Dial, Voice Memo, Voice Recognition
Language available: UI: Chinese Simplified, Chinese Traditional, Czech, Danish, Dutch, English, Finnish, French, German, Greek, Hungarian, Hebrew, Indonesian, Italian, Lithuanian, Norwegian, Polish, Portuguese, Romanian, Russian, Slovak, Spanish, Swedish, Thai, Turkish
Language available: T9 input: Chinese Simplified, Chinese Traditional, Czech, Danish, Dutch, English, Finnish, French, German, Greek, Italian, Norwegian, Polish, Portuguese, Spanish, Swedish, Turkish
Multimedia: BeDJ, Foto Talk
Personal Info Management: Daylight saving, Time Zone, Smart Phonebook, Vcard Exchange
Embedded Games: 2

Accessories

Optional accessories: Battery 720 mAh, Carry case, Cigarette lighter adapter, Deluxe headset, Exchangeable covers, Necklace, Universal car kit, Wrist wrap
Standard Package Includes: Battery, CD ROM (Mobile Phone Tools), Charger, Handset, International Guarantee, SAR information leaflet, User Manual

