

# PHILIPS

## Xenium

### Xenium

Champion

Black + Gray



CTX333BLK



## Power unlimited

### With dual SIM

Pack on more power to grab the spotlight with the Philips Xenium Champion. With its battery strength of up to 50 days of standby time and up to 16 hours of talk time, as well as Dual Sim cards, this phone is definitely a winner.

#### **Always on, always connected**

- Up to 50 days standby time

#### **Safe and convenient**

- Dual SIM for 2 groups of contacts

#### **Multimedia essentials**

- 6.1 cm (2.4") QVGA 262K color TFT display for vivid graphics
- Radio Data System for station information and data services
- Enjoy Bluetooth stereo music
- Capture your memories with 3 megapixel camera

# Highlights

## Up to 50 days standby time



The phone can be on and in standby mode continuously for up to 50 days on a single charge.

## Dual SIM



Organize your life better and keep your contacts separate by using 2 different phone numbers. With Dual SIM, you don't need to carry 2 phones around.

## 6cm/2.4" QVGA 262K TFT display



Add fun and excitement to vivid and colorful graphics and photos with your phone's 6.1 cm (2.4") QVGA 262K color TFT display. Enjoy excellent image quality and response time right at your fingertips!

## Radio Data System (RDS)

The Radio Data System (RDS) lets you tune into radio stations without having to remember the frequencies. In standard mode, RDS displays the station name instead of the transmission frequency, facilitating quick and easy tuning. RDS also allows stations to send text messages such as news and station information directly to the radio display. Commonly used in Europe, RDS text is sent out on the same frequency the radio station

broadcasts on. You can choose either the basic RDS display (station name) or subscribe to additional text-based services.

## Bluetooth stereo music

Your Philips mobile phone supports A2DP Bluetooth Profile. It lets you enjoy your favorite tunes wirelessly and in high quality stereo music from your Bluetooth headphones.



# Specifications

## Accessories

**Standard Package Includes:** Battery, CD ROM (Mobile Phone Tools), Charger, Handset, Stereo Headset, User Manual, USB data cable

## Audio Capturing

**Voice recording:** AMR, WAV

## Audio Playback

**Audio supported formats:** AMR, Midi, MP3, SP-Midi, AAC, WAV, AAC+, WMA

## Connectivity

**Headset:** Via 3.5mm jack connector

**Modem Capabilities:** CSD (Voice, Data), GPRS

**PC Link:** USB 2.0

**Serial connections:** USB-Jack cable

**Bluetooth profiles:** A2DP, Handsfree

**Bluetooth version:** 2.1

## Convenience

**Buttons and controls:** Side keys, Soft keys, 4-way navigation key and enter

**Call Management:** Call Forwarding, Call on Hold, Call Time, Call Waiting\*, Caller ID\*, Conference Call, Emergency Call, Microphone mute, Missed Calls, Multi-party call, Received Calls, Blacklist

**Clock/Version:** Analogue, Digital, International clock

**Ease of Use:** Hands free mode, In-flight mode, Keypad Lock, Softkeys, Vibra Alert, Dual SIM cards

**Games and applications:** Agenda, Alarm Clock, Calculator, Calendar, Stopwatch, Currency converter, International converter

**Language available:** **T9 input:** English, Russian

**Language available:** **UI:** English, Russian

**Multimedia:** FM Radio

**Personal Info Management:** Time Zone, International clock, Task list, SD card back-up, Smart Phonebook, Safeguard

**Personalisation/Customization:** Downloadable Animated GIF, Downloadable Java Applications, Downloadable Picture, Downloadable Ringtones, Wallpaper, Ringtones

**Text input:** T9

**Vibrator**

**Volume control**

## Dimensions

**Antenna:** Integrated

**Form Factor:** Candy bar

**Handset color:** Black + Grey

**Handset dimensions:**

119.5mm\*50.6mm\*15.8mm

**Handset weight:** 118.5g

## Green Specifications

**Lead-free soldered product**

**Packaging material:** Carton

**User manual:** Recycled paper

## Network Features

**GPRS (Rx+Tx):** Class 12, class B and C

**GSM band:** 900, 1800, 1900, 850 MHz

**Messaging:** Concatenated SMS (Long SMS), E-mail, MMS, Multimedia Message Service, SMS CB (Cell Broadcast), SMS (Short Message Service), SMS multi-target, Predefined SMS

**Services:** SIM Toolkit / Release 99, WAP 2.0

**Voice Codec:** FR/EFR/AMR/HR

**EDGE**

## Picture/Display

**Diagonal screen size (inch):** 2.4 inch

**Main Display Colors:** 262K

**Main Display Resolution:** 240x320 pixel

**Main Display Technology:** TFT

## Power

**Battery Capacity:** 2000mAh

**Battery saving manager:** Auto switch on/off

**Battery Type:** Lithium-ion

**Standby time:** Dual sim up to 50 days

**Talk time:** Up to 16 hours

## Sound

**Ringers:** MP3 ringer, Polyphonic (64 tones),

Voice memo ringer, AMR ringer

**Equalizer settings:** Classical, Dance, Pop, Rock, Bass, Normal, Treble, Party

## Still Picture Capturing

**Camera:** Integrated

**Image sensor type:** CMOS

**Picture file format:** JPEG

**Picture Mode:** Normal, Self-timer mode,

Continuous, Best shot

**Picture resolution:** VGA (640x480), 2M

(1600x1200), 3M (2048x1536), QVGA

(320x240), 1M (1280x960)

**Special effects preview mode:** Gray invert,

Grey scale, Sepia, Sepia blue, Sepia green

**Image quality:** Fine, Good, Normal

## Still Picture Playback

**Picture Compression Format:** BMP, GIF, JPEG

**Rotation:** 90 degree steps

**Slide show**

## Storage Media

**Memory Card Types:** Micro SD

**User memory:** 40 MB

**Maximum memory card capacity:** 32 GB

## Video Capturing

**Video format:** 3GP, H.263, MPEG4

**Video resolution:** QCIF

**Video mode:** Auto, Night

## Video Playback

**Compression formats:** MPEG4, H.263, 3GP

**Frame rate (fps):** 30

**Resolution (pxl):** 320x240

