



Philips  
Mobile Phone

760

CT7608

# Twist and Shoot

## 1.3 Megapixel digital camera phone

It's a camera, it's a phone, yes it's a Philips 760. This dual form factor camera phone combines all the functionalities you would expect from a true digital camera to capture the absolute highlights. Give it a try, it's a real head turner.

### **Capture and share your life**

- Store up to 70 high-definition photos in your phone
- MMS (Multimedia Messaging Service)
- TV SlideShow

### **Designed for snapshots**

- 180° swivel hinge
- Real digital cam design
- Super-bright flash
- Multi-shot for continuous pictures

### **Connect and enjoy**

- WAP
- Java 2.0 technology

# PHILIPS

# Highlights

## Real digital cam design

'Real digital cam design means that the phone's exterior looks like a high-quality digital camera, but underneath is a fully functional mobile phone with integrated megapixel camera.

## 180° swivel hinge

'The 180° swivel hinge allows you to use your mobile display just like a real digital camera preview screen.

## Multi-shot

Multi-shot for continuous pictures allows you to use a single click to take a sequence of photos to capture movement. Select continuous shooting: time and interval.

## Super bright torch light

'Super-bright flash is a light generated by LED to take pictures in low light conditions, such as night. Manually activate and deactivate the

super-bright flash by pressing and releasing the "+" or "-" volume side key (super-bright flash is automatically de-activated once the photo has been taken).

## MMS messaging

MMS (Multimedia Messaging Service) allows you to use your mobile phone to send and receive pictures, video, and audio files with your text messages.

## TV SlideShow

TV SlideShow allows you to display pictures from your phone's photo album directly on a TV screen for the fun of sharing pictures from your phone's camera with friends and family. Simply connect your mobile phone and TV with the TV Link accessory to run an automatic or manual slideshow.

## Up to 70 high resolution pics

You can use the phone's built-in memory to store up to 70 high-resolution, high-definition photos (1280 × 1024 pixels each). Simply take and store photos until the phone's built-in memory of 18 MB is full, then download or delete them

## WAP

Wireless Application Protocol (WAP) version 1.2.1 is a standardized way for a mobile phone to talk to a server in the mobile phone network to connect your phone to WAP-enabled web sites, allowing you to access comprehensive information whenever you need it.

## Java 2.0

Java 2.0 technology allows you to enhance and personalize your phone with new games and applications simply by downloading them.



# Specifications

## Picture/Display

- Main Display Resolution: 128x160 pixels
- Main Display Technology: TFT
- Main Display Colors: 65536
- Lines of text: 8

## Still Picture Capturing

- Camera: Integrated
- Picture resolution: 1.3M
- Digital zoom: x2, x4
- Picture file format: JPEG
- Picture Mode: Normal, Night mode, Self-timer mode
- Special effects preview mode: Grey scale, Sepia, Edge, Digital, Embossed, Negative color
- Sensitivity: min 5 lux
- Preview frame rate: 25 frames/second
- Image sensor type: CMOS

## Still Picture Playback

- Picture Compression Format: BMP, GIF, GIF (87a & 89a), JPEG
- Picture Enhancement: Edit photos (colors, filters), Frames & Icons, Rotate
- Slide show

## Storage Media

- Built-in memory (RAM): 32
- User memory: 18 MB

## Connectivity

- Modem Capabilities: CSD (Voice, Data), GPRS, SMS
- Headset: Via bottom connector
- Serial connections: USB-Bottom connector cable
- Synchronisation PC organizer: Lotus Notes, MS Outlook
- Wireless connection: Infrared

## Network Features

- GPRS (Rx+Tx): Class 10 (4+2), Class B

- Messaging: Concatenated SMS (Long SMS), E-mail, Predefined messages (SMS,MMS), EMS / release 4, Quick SMS, MMS, Multimedia Message Service, SMS CB (Cell Broadcast), SMS (Short Message Service)
- Services: SIM Toolkit / Release 99, OTA provisioning (WAP,MMS), WAP Browser Teleca2.0, WAP 1.2.1
- Voice Codec: FR/EFR/AMR
- GSM band: 900, 1800 MHz

## Power

- Battery Capacity: 720 mAh
- Battery Type: Lithium-ion
- Standby time: up to 560 hrs
- Talk time: up to 4 hrs 40 min
- Charging time: less than 2.5 hours hour(s)
- Electrical Enhancements: Back-up battery

## Convenience

- Language available: UI: Arabic, Chinese Simplified, Chinese Traditional, Croatian, Czech, Danish, Dutch, English, Finnish, French, German, Greek, Hebrew, Hungarian, Indonesian, Italian, Lithuanian, Norwegian, Polish, Portuguese, Romanian, Russian, Slovak, Spanish, Swedish, Thai, Turkish
- Ease of Use: Hands free mode, Hot Keys, Keypad Lock, Screen Saver Digital Clock, Vibra Alert
- Call Management: Call Cost, Call Counters, Call Forwarding, Call on Hold, Call Time, Call Waiting\*, Caller ID\*, Conference Call, Emergency Call, Explicit Call Transfer, Microphone mute, Missed Calls, Multi-party call, Received Calls
- Buttons and controls: 4-way navigation key and enter, Customized hot key, Camera key, Side keys
- Volume control
- Clock/Version: Analogue, Digital, International clock
- Multimedia: Foto Talk
- Speech Recognition: Conversation Recording, Voice Command, Voice Dial, Voice Memo, Voice Recognition

- Embedded Games: 4
- Games and applications: Agenda, Alarm Clock, Calculator, Calendar, Euro Converter, Infusio - Exen v2, Java MIDP 2.0
- Ease To Experience: Demo Mode
- Ease of Navigation: Active Flip, Animated Color Matrix
- Language available: T9 input: Chinese Simplified, Chinese Traditional, Czech, Danish, Dutch, English, Finnish, French, German, Greek, Hebrew, Italian, Norwegian, Polish, Portuguese, Spanish, Swedish, Turkish
- Personal Info Management: Daylight saving, Time Zone, Smart Phonebook, Vcard Exchange
- Personalisation/Customization: Downloadable Animated GIF, Downloadable Java Applications, Downloadable Picture, Downloadable Ringtones, Fotocall, Wallpaper

## Sound

- Ringers: Polyphonic (64 tones)

## Audio Capturing

- Voice recording: Yes, AMR

## Audio Playback

- Audio supported formats: ADPCM, AMR, Midi, SP-Midi

## Audio Recording

- Recording time: upto 60 seconds

## Dimensions

- Product dimensions (WxDxH): 91.4x44x24.8 mm
- Handset Color: Swing Blue, Twist Grey
- Form Factor: Clam shell
- Antenna: Integrated
- Product volume: 92 cm<sup>3</sup>
- Product weight: 104 g kg

# Specifications

## Green Specifications

- Chemical composition: Lithium
- Lead-free soldered product
- Packaging material: Carton
- Packaging type: Giftbox

## Accessories

- Standard Package Includes: Battery, CD ROM

(Mobile Phone Tools), Charger, Handset, International Guarantee, SAR information leaflet, User Manual, USB data cable

- Optional accessories: Carry case, Cigarette lighter adapter, Deluxe FM headset, Deluxe headset, TV Link, Universal car kit, Necklace



Issue date 2023-12-26

Version: 2.0.3

© 2023 Koninklijke Philips N.V.  
All Rights reserved.

Specifications are subject to change without notice.  
Trademarks are the property of Koninklijke Philips N.V.  
or their respective owners.

[www.philips.com](http://www.philips.com)