



Philips  
Xenium

9@9t

CT7568

## Incredible Battery Life

Don't just say it, write it!

The Philips Xenium 9@9t provides the power you need to stay connected and take care of business. Thanks to the touch screen, you can navigate and easily enter SMSs in handwriting recognition mode.

### Always ready

- Up to 1 month of standby time
- Up to 8.5 hours of talk time

### Quick and easy messaging

- On-screen handwriting recognition
- Touch screen

### Maximize your Multimedia Experience

- 1.3 megapixel camera for clear, sharp picture quality
- MP3 playback and ringtones for a superior audio experience
- Mini SD card expansion slot for extra memory/data storage

**PHILIPS**  
sense and simplicity

# Highlights

## Up to 1 month standby time

The phone can be on and in standby mode continuously for up to 1 month on a single charge.

## Up to 8.5 hours talk time

The phone can support up to 8.5 hours talk time on a single charge.

## Handwriting recognition

The intuitive and fast way to write text messages. Simply write on the touch screen as you would write on a piece of paper to have the phone convert your handwriting into an SMS (Short Message Service) text message. The feature has built-in handwriting recognition capability in both Chinese

(traditional and simplified) and English (Roman alphabet).

## Touch screen

Use the touch screen and integrated stylus to switch to an interface that is simple, intuitive, and comfortable to use. The easy-to-use touch screen lets you quickly navigate menus, write SMS, personalize and give emotion to your pictures, play games, and access other applications.

## 1.3 megapixel camera

Capture your most precious memories with the clearest, sharpest picture quality imaginable through stunning 1.3 megapixel resolution. Press camera side key to take

vibrant pictures to use for wallpaper and fotocall, or to send later via MMS.

## MP3 playback and ringtones

Use the data cable or an external memory card to transfer MP3 music files to your phone for a superior audio experience on the go. You can also personalize your ringtone with a selection from your MP3 files.

## Mini SD card expansion slot

Store more of the pictures, videos, and music files that matter to you by inserting a mini SD card into the built-in expansion card slot of your phone.



# Specifications

## Dimensions

- Form Factor: Candy bar
- Antenna: Integrated
- Handset dimensions: 108 x 46.5 x 17 mm
- Handset volume: 82 cc
- Handset weight: 85 g
- Handset color: Silver touch, Classic black

## Power

- Talk time: up to 8.5 hours
- Standby time: up to 850 hrs
- Charging time: less than 2.5 hr
- Battery capacity: 1100 mAh
- Battery Type: Li-ion
- Electrical Enhancements: Back-up battery

## Still Picture Capturing

- Camera: Integrated
- Picture resolution: 1.3M
- Digital zoom: x2, x4, x8
- Picture Mode: Normal, Night mode, Self-timer mode
- Picture file format: JPEG
- Image sensor type: CMOS
- Sensitivity: min 5 lux
- Special effects preview mode: Grey scale, Sepia, Edge, Digital, Embossed, Negative color

## Picture/Display

- Main Display Technology: CSTN
- Main Display Colors: 65536
- Main Display Resolution: 128x160 pixel
- Lines of text: up to 7
- Touch panel

## Still Picture Playback

- Picture compression format: BMP, GIF, GIF (87a & 89a), JPEG
- Picture enhancement: Edit photos (colors, filters), Frames & Icons, Rotate, Tag it
- Slide show

## Sound

- Ringers: Polyphonic (40 tones), MP3 ringer

## Audio Capturing

- Voice recording: Yes, AMR

## Audio Playback

- Audio supported formats: AMR, Midi, SP-Midi, MP3

## Audio Recording

- Recording time: up to 30 minutes

## Storage Media

- User memory: 20 MB

## Network Features

- Messaging: Concatenated SMS (Long SMS), E-mail, Predefined messages (SMS,MMS), EMS / release 4, Quick SMS, MMS, Multimedia Message Service, SMS

- CB (Cell Broadcast), SMS (Short Message Service), QQ instant messaging
- Services: SIM Toolkit / Release 99, OTA provisioning (WAP,MMS), WAP 1.2.1
- GPRS (Rx+Tx): Class 10 (4+2), Class B
- Voice Codec: FR/EFR/AMR
- GSM band: 900, 1800, 1900 MHz

## Convenience

- Call Management: Call Cost, Call Counters, Call Forwarding, Call on Hold, Call Time, Call Waiting, Caller ID, Conference Call, Emergency Call, Explicit Call Transfer, Microphone mute, Missed Calls, Multi-party call, Received Calls
- Personal Info Management: Daylight saving, Time Zone, Smart Phonebook, Vcard Exchange
- Personalisation/Customization: Downloadable Animated GIF, Downloadable Java Applications, Downloadable Picture, Downloadable Ringtones, Fotocall, Wallpaper
- Speech Recognition: Conversation Recording, Voice Command, Voice Dial, Voice Memo, Voice Recognition
- Clock/Version: Analogue, Digital, International clock
- Ease of Use: Hands free mode, Hot Keys, Screen Saver Digital Clock, Vibra Alert
- Ease of Navigation: Animated Color Matrix, Touch panel
- Buttons and controls: 4-way navigation key and enter, Customized hot key, Camera key
- Volume control
- Ease To Experience: Demo Mode
- Games and applications: Agenda, Alarm Clock, Calculator, Calendar, Java MIDP 2.0, International converter, Voice reminder if appointment, Handwriting recognition, Lunar Calendar
- Embedded Games: 1
- Multimedia: Foto Talk

## Connectivity

- Headset: Via jack connector
- Serial connections: USB-Bottom connector cable
- Modem Capabilities: CSD (Voice, Data), GPRS, SMS
- Synchronisation PC organizer: Lotus Notes, MS Outlook
- Wireless connections: Infrared

## Accessories

- Standard Package Includes: Battery, CD ROM (Mobile Phone Tools), Charger, International Guarantee, SAR information leaflet, User Manual, Stylus, Standard Headset
- Optional accessories: Carry case, Cigarette lighter adapter, Deluxe headset, Universal car kit, USB data cable + PC software

## Green Specifications

- Heavy metals: Pb free
- Packaging material: Carton



Issue date 2009-04-12

Version: 4.0.7

12 NC: 9961 400 05728  
EAN: 87 12581 33816 9

© 2009 Koninklijke Philips Electronics N.V.  
All Rights reserved.

Specifications are subject to change without notice.  
Trademarks are the property of Koninklijke Philips Electronics N.V. or their respective owners.

[www.philips.com](http://www.philips.com)

\* MP3 playback supported from Mini SD-card (not included)