



Philips
Mobile Phone

399

CT0399BLK

Enjoy multimedia and easy messaging

The writing's on the screen! The Philips 399 features an ultra-intuitive touch screen and handwriting recognition for effortless messaging. With large color TFT display, MP3 playback and video capture, it's your ideal mobile companion.

Multimedia - anytime, anywhere

- Large 262K color TFT display for vivid, colorful graphics
- MP3 playback and ringtones for a superior audio experience
- Video capture and playback in MPEG4 and H263 format
- MicroSD memory card slot for extra memory/ data storage

Quick and easy messaging

- On-screen handwriting recognition
- Touch screen

PHILIPS
sense and simplicity

Specifications

Dimensions

- Antenna: Integrated
- Form Factor: Candy bar
- Handset color: Matt Black, High Glossy Black, Red
- Handset dimensions: 102 x 49 x 13 mm
- Handset weight: 80g

Picture/Display

- Diagonal screen size (inch): 2.6 inch
- Main Display Colors: 262K
- Main Display Technology: TFT
- Resolution: 240 x 320 pixels
- Touch panel

Network Features

- GSM band: 900, 1800 MHz
- Messaging: Concatenated SMS (Long SMS), EMS / release 4, MMS, Multimedia Message Service, Predefined messages (SMS, MMS), SMS multi-target, WAP OTA provisioning
- Services: SIM Toolkit / Release 99
- Voice Codec: FR/EFR/HR

Still Picture Capturing

- Camera: Integrated
- Digital zoom: x4
- Image sensor type: CMOS
- Picture Mode: Night mode, Self-timer mode, Continuous
- Picture resolution: VGA (640x480), QVGA (320x240), 120x160, SXGA (1280x1024)
- Special effects preview mode: Grey scale, Sepia, Embossed, Negative color, Blue effect, Reversed, Sketch, Blackboard, Whiteboard, Green effect
- White balance: Automatic, Cloudy, Incandescent, Fluorescent, Daylight, Tungsten
- Picture quality: Normal, Fine, Superfine

Still Picture Playback

- Picture Compression Format: BMP, GIF (87a & 89a), JPEG

Video Recording

- Compression formats: MPEG4, H.263
- Resolution (pxl): 160x120

Sound

- Ringers: MP3 ringer, Polyphonic (64 tones)

Audio Playback

- Audio supported formats: AMR, Midi, MP3

Audio Capturing

- Voice recording: Yes, AMR

Storage Media

- Built-in memory capacity: 11MB
- Memory Card Types: Micro Secure Digital (SD)
- Memory management: Memory status

Convenience

- Buttons and controls: Soft keys, 4-way navigation keys
- Call Management: Call Cost, Call Forwarding, Call Time, Call Waiting, Caller ID, Emergency Call, Microphone mute, Missed Calls, Multi-party call, Received Calls
- Clock/Version: International clock
- Ease of Use: Hands free mode, Keypad Lock, Softkeys, Vibra Alert
- Embedded Games: 2
- Games and applications: Alarm Clock, Calculator, Calendar, Stopwatch, ENG-CHN and CHN-ENG dictionary, Handwriting recognition, International converter, Female calendar, Weight management
- Language available: UI: Chinese Simplified, Chinese Traditional, English
- Personal Info Management: Time Zone, International clock
- Personalisation/Customization: Downloadable Picture, Downloadable Ringtones, Screen Saver, Wallpaper, Ringtones
- Vibrator

Power

- Battery capacity: 820 mAh
- Standby time: Up to 240 hours
- Talk time: Up to 3 hrs
- Battery Type: Li-ion

Accessories

- Standard Package Includes: Battery, Charger, USB data cable, Deluxe stereo headset

Connectivity

- Bluetooth
- Headset: Via mini USB connector
- Bluetooth profiles: A2DP, Headset, Object push profile

Highlights

Large 262K color TFT display

Put the fun and excitement of the most vivid and colorful graphics and photos right at your fingertips with the large 262K color display that features excellent image quality and response time.

MP3 playback and ringtone

Use the USB data cable to transfer MP3 music files to your phone for a superior audio experience on the go. You can also personalize your ringtone using your MP3 files.

Video capture and playback

The video capture function lets you record precious moments in MPEG4 or H263 format. Play it back on your phone or PC.

MicroSD memory card slot

You can now enjoy extra capacity and storage of multimedia files by inserting a MicroSD memory card into the built-in memory card slot of your phone.

Handwriting recognition

The intuitive and fast way to write text messages. Simply write on the touch screen as you would write on a piece of paper to have the phone convert your handwriting into an SMS (Short Message Service) text message. The feature has built-in handwriting recognition capability in both Chinese (traditional and simplified) and English (Roman alphabet).



Issue date 2009-11-06

Version: 1.0.1

12 NC: 8670 000 33865
EAN: 87 12581 37731 1

© 2009 Koninklijke Philips Electronics N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips Electronics N.V. or their respective owners.

www.philips.com