

slim & brilliant

- *Active Clamshell*
- *Visual Call system*
- *32 Polyphonic melodies*
- *Incredible storage (SMS, EMS & phonebook)*

*precious
+ elegant*



PHILIPS

Mobile Phone E-GSM 900/I800



PHONE FEATURES

- **Visual Call System** A complete visual lighting effect informs you when you receive a call. The bunny on the front of the product blinks with 3 different colours (red, orange and green). Each colour can be associated to phonebook groups so that you identify who is calling even when the clamshell is closed or in silent mode. Also, the light belt illuminates with a smooth white backlight around the product when a call is received.
- **Active Clamshell** When activated, this feature allows you to pick up an incoming call by simply opening the phone.
- **Extended SMS storage** You can store Up to 100 SMS and EMS in your phone memory and reuse them later.
- **Polyphonic ringers** 32 polyphonic ringtones with 30 melodies.
- **Downloadable** polyphonic ringtone melodies (Network dependent) Allows you to select extra melodies you prefer and download them to your phone.
- **Audio quality** The mobile include Enhanced Full Rate (EFR), Full Rate (FR) and Half Rate (HR) transmission vocoders to obtain better audio quality and coverage compatibility (network dependant).
- **EMS release 4©** Allow you to receive and send formatted texts, melodies, images and use received melodies as ringtones.
- **Fotocall** With a user selectable picture and/or melody associated with a defined group in your phonebook you will be able to see/hear who's calling.
- **New game engine** With Infusio V2 (Operator dependent) a wide choice of new downloadable games is at your disposal. When you play a game you can publish your score via SMS, challenge other players and win prizes!
- **Email** Direct access to email services from your phone. You can set up two email accounts on your phone, allowing you to have personal and business email addresses. Supports POP3 and SMTP.

- **Picture applications** Using email you can send and receive B&W images in JPEG format, for use as screensavers.
- **File manager** You can choose how to allocate the available memory in the phone between names, SMS in phone, pictures, games, melodies, ...etc
- **WAP 1.2.1** Wireless Application Protocol. Access a world of services wherever you are. The latest W@P version with additional security for mobile transactions.
- **Voice recognition** Voice dial/command just say a name or a word to dial a number from the names list or to activate a specific function in your phone.
- **Smart Phonebook** Under each name, up to 5 phone numbers, 1 e-mail address and a note can be stored.
- **Personal Organiser** Plan all your meetings and events in your calendar and set your phone to remind you of them, using the alarm function.
- **Concatenated SMS** Write long SMS by connecting 5 pages + attachments when sending (up to 50 pages -SIM dependent on receipt)
- **Flash Dial and Hot keys** Press and hold on a digit key to activate a particular function or to dial your most frequently used telephone numbers.
- **T9™ Text Input** Predictive Text input to write emails and SMS - Chinese and most European languages are available.
- **Volume** Ringer: high, medium, low, silent, increasing mode.
Earpiece: adjust for comfortable volume during call.
- **Graphic Display** 8 lines of text, full graphic display, and blue backlight
- **Philips active Carousel** The optimised unique Philips carousel concept with animated icons, allows intuitive use of the phone.
- **Calculator & Euro converter**
- **Call list** The 30 last dialled, received or missed calls are automatically stored for redial.

* : Battery life measurements are approximate and depend on the operator's network configuration. Specifications provided based on Pmax, No DTx, DRx = 9

SERVICES

- Caller ID
- Call Waiting
- Call forwarding
- Call on hold
- Short Message Service (SMS)
- Voice Mail
- CPHS features compliant (without ALS)
- Multi-party call
- Explicit Call transfer
- Call Time and Cost Meters
- Emergency Call

OPERATOR FEATURES

- WAP 1.2.1 / 5.0.3 open wave browser.
- EMS release 4©
- SIM Lock
Keeps consumers on networks for dedicated operator and service providers.
- SIM TOOLKIT

CHINESE FEATURES

- Western Horoscope
Get your star sign predictions daily, or in advance and be prepared for a very different day, every day.
- Lunar Calendar
Input the Solar date (day-month-year) and the corresponding Lunar date will be provided.

GENERAL INFORMATION

Specifications

- Mode: E-GSM 900/I800 Mhz
EFR/FR/HR vocoder

Performances standard battery

- up to 4h00 Talk Time
- up to 400 hours Standby Time

Size

- 78*43*18.5 mm

Volume/Weight

- 65cc/79g

Handset Colour Options

- EMEA: Shining red – Lacquer white – Sparkling blue – Brilliant silver – Metal natural – Metal yellow – Metal black

Available Languages

- Native MMI: English, Czech, Dutch, French, German, Greek, Hungarian, Italian, Polish, Portuguese, Russian, Chinese simplex, Chinese traditional, Slovakian, Spanish, Thai*, Turkish.
* : not available in wap MMI.

- T9 available with: English, Dutch, French, German, Italian, Portuguese, Chinese simplex, Chinese traditional, Spanish, Thai.

Standard Package includes

- Handset
- Battery
- Charger
- User Manual
- International Guarantee
SAR value

Accessories

- Battery: Standard 600mAh
- Chargers: Cigarette Lighter Adaptor
- Car Kits: Compact Car Kit
- Personal Access: Deluxe Headset
- Carry case



© 2003 Philips France. All rights reserved.

RCS Nanterre N° B 402 805 527. The information and specifications included are subject to change without prior notice. Philips tries to ensure that all information in this document is correct, but does not accept liability for any error or omission. This document is not meant to be contractual.