

Philips  
Mobile Phone

535

CT5358



## Snap, Talk & Send

FotoTalk: add voice to your pictures

### **Add Emotion to your Messages**

- FotoTalk adds voice to your MMS pictures
- MMS (Multimedia Messaging Service)
- Special effects for creative picture personalization

### **Maximize your Multimedia Experience**

- 32-tone rich polyphonic melodies
- Mix your own polyphonic melodies and ringtones with BeDJ

### **Capture and share your life**

- TFT display with 65,536 gorgeous colors
- Digitally zoom up to 4 times
- Integrated VGA digital camera

# PHILIPS

# Specifications

## Picture/Display

- Main Display Resolution: 128x128 pixels
- Main Display Technology: TFT
- Main Display Colors: 65536
- Brightness: 120 cd/m<sup>2</sup>
- Lines of text: 8

## Still Picture Capturing

- Camera: Integrated
- Picture resolution: VGA (640x480)
- Digital zoom: x2 and x4
- Picture file format: JPEG
- Picture Mode: Economy, Normal, Super fine
- Special effects preview mode: Grey scale, Sepia, Blue effect
- Sensitivity: min 5 lux
- Preview frame rate: 15 frames/second
- Image sensor type: CMOS

## Still Picture Playback

- Picture Compression Format: BMP, GIF (87a & 89a), JPEG
- Slide show: No

## Storage Media

- Built-in memory (RAM): 8
- User memory: 1.5 MB

## Connectivity

- Modem Capabilities: CSD (Voice, Data), GPRS
- Headphone: 2.5 mm
- Synchronisation PC organizer: Lotus Notes, MS Outlook
- Wireless connection: Infrared

## Network Features

- GPRS (Rx+Tx): Class 10 (4+2), Class B
- Messaging: Concatenated SMS (Long SMS), E-mail, EMS / release 4, MMS, Multimedia Message Service, Predefined messages (SMS, MMS), Quick SMS, SMS CB (Cell Broadcast), SMS (Short Message Service)
- Services: WAP 1.2.1, WAP Browser Teleca 2.0, SIM Toolkit / Release 99, OTA provisioning (WAP, MMS)
- Voice Codec: FR/EFR/AMR

## Power

- Battery Capacity: 720 mAh
- Battery Type: Lithium-ion
- Standby time: up to 300 hrs
- Talk time: up to 6 hrs
- Charging time: less than 2 hours hour(s)

## Convenience

- Language available: UI: Chinese Simplified, Chinese Traditional, Czech, Danish, Dutch, English, Finnish, French, German, Greek, Hebrew, Hungarian, Indonesian, Italian, Lithuanian, Norwegian, Polish,

- Portuguese, Romanian, Russian, Slovak, Spanish, Swedish, Thai, Turkish
- Ease of Use: Blinking Lights, Dedicated Headset plug, Hands free mode, Hot Keys, Screen Saver
- Digital Clock, Vibra Alert
- Call Management: Call Cost, Call Counters, Call Forwarding, Call on Hold, Call Time, Call Waiting\*, Caller ID\*, Conference Call, Emergency Call, Explicit Call Transfer, Microphone mute, Missed Calls, Multi-party call, Received Calls
- Buttons and controls: 4-way navigation key and enter, Customized hot key
- Volume control
- Clock/Version: Analogue, Digital
- Multimedia: BeDJ, Foto Talk
- Speech Recognition: Conversation Recording, Voice Command, Voice Dial, Voice Memo, Voice Recognition
- Embedded Games: 2
- Games and applications: Agenda, Alarm Clock, Calculator, Calendar, Euro Converter, Infusio - Exen v2
- Ease To Experience: Demo Mode
- Ease of Navigation: Animated Carroussel, Color Carroussel
- Language available: T9 input: Chinese Simplified, Chinese Traditional, Czech, Danish, Dutch, English, Finnish, French, German, Greek, Italian, Norwegian, Polish, Portuguese, Spanish, Swedish, Turkish
- Personal Info Management: Daylight saving, Time Zone, Smart Phonebook, Vcard Exchange
- Personalisation/Customization: Downloadable Animated GIF, Downloadable Picture, Downloadable Ringtones, Exchangeable Covers, Fotocall, Screen Saver, Wallpaper

## Sound

- Ringers: Polyphonic (32 tones)

## Audio Capturing

- Voice recording: Yes, AMR

## Audio Playback

- Audio supported formats: ADPCM, AMR, Midi, SP-Midi

## Audio Recording

- Recording time: upto 60 seconds

## Dimensions

- Handset Color: Black Motion, Blue Focus, Red Lens, Silver Digit
- Form Factor: Candy bar
- Antenna: Integrated
- Handset dimensions: 101x44x19
- Handset volume: 79
- Handset weight: 95

# Highlights

## Accessories

- Integrated digital camera with VGA resolution (640x480 pixels) allows you to take high quality pictures anywhere. You can either save the pictures in your phone's internal MMS or email, or store the pictures in your optional accessories: Battery 720 mAh, Carry case, Cigarette lighter adapter, Deluxe headset, Digital cable, etc.
- Digital cable: Necklace, Universal car kit, Easy zoom: the picture in and out up to 4 times, composing better and more meaningful pictures by capturing the right detail from the overall scene. In preview mode, activate the zoom function to take pictures of distant objects or to concentrate attention on a specific part of the picture.

## 65K color TFT display

Brilliant 65K color TFT display offers high contrast and high brightness with 65,536 gorgeous colors and ultra fine pitch for clear, bright color graphics and photos.

## MMS messaging

MMS (Multimedia Messaging Service) allows you to use your mobile phone to send and receive pictures, video, and audio files with your text messages.

## FotoTalk

FotoTalk allows you to instantaneously send pictures and recorded voice messages via MMS to friends and family. Access the camera application via camera hard key or multimedia menu to choose FotoTalk, then take a picture, record your voice, and go to MMS to finalize and send the message.

## Special effects

Special effects provide you with several modifications that can be applied in order to personalize camera images: sepia, gray scale, edge, digital, embossed, or negative colors. Choose one of the special effects in camera preview mode, take the picture, then save the photo in phone screen resolution format e.g. 128x160 pixels.

## BeDJ

The amazing BeDJ feature allows you to easily create, enjoy, and share your own music mixes anytime, anywhere for unlimited creativity with this real, portable mixing studio. Create your own sounds using predefined styles provided by famous international DJs, your phone's own polyphonic ring tones, or by downloading content via WAP, infrared, or MMS to mix up to 9 different tracks in real time.

## 32-tone polyphonic melodies

32-tone polyphonic melodies can create simultaneous tones of different notes using MIDI format for more natural and realistic musical results, sounding just like a small orchestra of different instruments for outstanding sound effects.



Issue date 2023-12-26

Version: 1.0.3

© 2023 Koninklijke Philips N.V.  
All Rights reserved.

Specifications are subject to change without notice.  
Trademarks are the property of Koninklijke Philips N.V.  
or their respective owners.

[www.philips.com](http://www.philips.com)