

PHILIPS

Mobile Phone

568

CT5688



Your compact Video phone!

MMS your video-clips

Make someone a movie star and share moments of his life with your friends! The Philips 568 is compact with a stylish, sophisticated design. It's incredibly light and enables you to record and share video clips of your wonderful lifetime.

Capture and share your life

- MMS video to record and share exciting multimedia messages
- Video capture
- Integrated VGA digital camera

Enrich your sound experience

- 40-tone rich polyphonic melodies
- Ringtone with a voice you select

Stay connected

- Triband phone GSM900/1800/1900
- Java 2.0 technology
- WAP 2.0

Highlights

MMS video

MMS video lets you record and share exciting multimedia messages with your friends and family just by attaching a video clip.

Video capture

The video recording function lets you capture precious moments in motion at 4, 6, or 9 frames per second.

Integrated VGA digital camera

The integrated digital camera with VGA resolution (640x480 pixels) allows you to take high-quality pictures anytime, anywhere with your phone, then send them via MMS or email, or store the pictures in your phone's memory.

40-tone polyphonic melodies

40-tone polyphonic melodies can create simultaneous tones of different notes using MIDI format for more natural and realistic musical results, sounding just like a small orchestra of different instruments for outstanding sound effects.

Voice ringtones

Voice ringtones lets you use your phone's built-in recording function in AMR format to create a voice clip from a loved one or other source to use as a fun and memorable ringtone.

Triband phone GSM900/1800/1900

GSM mode including 900MHz, 1800MHz and 1900MHz gives your phone worldwide coverage.

Java 2.0

Java 2.0 technology allows you to enhance and personalize your phone with new games and applications simply by downloading them.

WAP 2.0

WAP 2.0 optimizes the usage of packet-based connection technology with higher bandwidths to more easily connect your phone to WAP-enabled web sites, allowing you to access comprehensive information whenever you need it.



Specifications

Dimensions

Handset weight: 87g
 Handset dimensions: 99.5 x 44 x 19.5 mm
 Handset volume: 82cc
 Form Factor: Candy bar
 Antenna: Integrated
 Handset Color: Arrow Silver, Deep Black

Picture/Display

Main Display Technology: CSTN
 Main Display Colors: 65536
 Main Display Resolution: 128x160 pixel
 Brightness: 95 cd/m²
 Lines of text: 8

Still Picture Capturing

Camera: Integrated
 Picture resolution: VGA (640x480)
 Digital zoom: x2, x4
 Picture Mode: Economy, Normal, Super fine, Night mode
 Preview frame rate: 15 frames/second
 Picture file format: JPEG
 Image sensor type: CMOS

Still Picture Playback

Picture Compression Format: BMP, GIF, GIF (87a & 89a), JPEG
 Picture Enhancement: Create albums, Rotate Slide show

Video Capturing

Video format: 3GP, H.263
 Video resolution: Sub-QCIF

Video Playback

Compression formats: H.263, 3GP
 Frame rate (fps): 10, 8
 Resolution (pxl): 128x160, 128x96

Video Recording

Compression formats: H.263, 3GP
 Frame rate: 9, 4, 6 fps
 Resolution (pxl): 128x96

Sound

Ringers: Polyphonic (40 tones)

Audio Capturing

Voice recording: Yes, AMR

Audio Playback

Audio supported formats: AMR, Midi, SP-Midi

Audio Recording

Recording time: up to 36 seconds

Storage Media

Built-in memory (RAM): 8
 User memory: 3.2 MB

Network Features

Messaging: Concatenated SMS (Long SMS), E-mail, EMS / release 4, MMS, Multimedia Message Service, SMS CB (Cell Broadcast), SMS (Short Message Service)
 Services: SIM Toolkit / Release 99, OTA provisioning (WAP, MMS), WAP Browser Openwave 6.1
 GPRS (Rx+Tx): Class 10 (4+2), Class B
 Voice Codec: FR/EFR/HR
 GSM band: 900, 1800, 1900 MHz

Convenience

Call Management: Call Cost, Call Counters, Call Forwarding, Call on Hold, Call Time, Call Waiting*, Caller ID*, Conference Call, Emergency Call, Explicit Call Transfer, Microphone mute, Missed Calls, Multi-party call, Received Calls
 Personal Info Management: Smart Phonebook
 Personalisation/Customization: Downloadable Animated GIF, Downloadable Java Applications, Downloadable Picture, Downloadable Ringtones, Fotocall, Screen Saver, Wallpaper
 Speech Recognition: Voice Memo
 Clock/Version: Digital, International clock
 Ease of Use: Dedicated Headset plug, Hands free mode, Hot Keys, Keypad Lock, Screen Saver Digital Clock, Vibra Alert
 Ease of Navigation: Animated Color Matrix
 Buttons and controls: 4-way navigation key and enter, Customized hot key
 Volume control
 Ease To Experience: Demo Mode
 Games and applications: Agenda, Alarm Clock, Calculator, Calendar, Java MIDP 2.0
 Embedded Games: 3

Connectivity

Headphone: 2.5 mm
 Serial connections: USB-Jack cable
 Modem Capabilities: GPRS, SMS

Accessories

Standard Package Includes: Battery, Charger, Handset, User Manual
 Optional accessories: Carry case, Deluxe headset, Normal battery pack, USB data cable + PC software

Power

Talk time: Up to 4 hrs
 Standby time: Up to 300 hrs
 Charging time: less than 2.5 hr
 Battery Capacity: 900 mAh
 Battery Type: Lithium-ion
 Electrical Enhancements: Back-up battery

