

PHILIPS

Xenium

9@9q

CT9A9QBLK



Incredible battery life

Stay in style and ahead of the trends with the beautifully compact Philips Xenium 9@9q. Jazz up your life with this sleek mobile companion that gives you the power to stay connected and in fashion ... always!

Always on, always connected

- Up to 1 month of standby time
- Enjoy up to 22 hours of music playback
- Up to 8 hours of talk time

Designed for you

- Sleek, fashion-forward design to show the world your style
- Cool, white illuminated LED alert to reveal phone status.

Maximize your Multimedia Experience

- Large 262K color TFT display for vivid, colorful graphics
- Video capture and playback in MPEG4 and H263 format
- MicroSD memory card slot for extra memory/ data storage
- Enjoy Bluetooth stereo music

Stay connected

- Enhanced Data rates for GSM Evolution

Highlights

Up to 1 month standby time

The phone can be on and in standby mode continuously for up to 1 month on a single charge.

EDGE

EDGE provides up to three times the data capacity of GPRS, allows you to enjoy higher speed access to Internet and WAP, content download, email as well as fast sending/reception of MMS messages.

Subscribe the GPRS service with your network operator and set up the GPRS profile in your EDGE enabled phone.

MicroSD memory card slot

You can now enjoy extra capacity and storage of multimedia files by inserting a MicroSD memory card into the built-in memory card slot of your phone.

Bluetooth stereo music

Your Philips mobile phone supports A2DP Bluetooth Profile. It lets you enjoy your favorite tunes wirelessly and in high quality stereo music from your Bluetooth headphones.

Up to 8 hours talk time

The phone can support up to 8 hours conversation on a single charge.



Specifications

Dimensions

Product weight: 0.086 kg
Product dimensions (WxDxH): 46.5x18.3x99.3
Form Factor: Clam shell
Antenna: Integrated
Handset color: Phantom Black

Picture/Display

Main Display Technology: TFT
Main Display Colors: 262K
Main Display Resolution: 176x220 pixel
Lines of text: 6
Brightness: 240 cd/m²
Diagonal screen size: 2 inches

Still Picture Capturing

Camera: Integrated
Picture resolution: 176x220, VGA (640x480), 768x1024, SXGA (1280x1024)
Picture Mode: Night mode, Self-timer mode, Continuous
Picture file format: JPEG
Image sensor type: CMOS
Special effects preview mode: Sepia, Blue effect, B&W
Picture quality: Normal, Fine, Superfine

Still Picture Playback

Picture Compression Format: BMP, GIF, GIF (87a & 89a), JPEG, WBMP
Slide show

Video Capturing

Image sensor resolution: 1.3 M pixel
Video resolution: QCIF
Frame rate: 12.5 fps
Video format: H.263, MPEG4
Image sensor type: CMOS

Video Playback

Compression formats: MPEG4, H.263
Frame rate (fps): 15
Resolution (pxl): 176x144

Sound

Ringers: MP3 ringer, Polyphonic (64 tones), Voice memo ringer

Audio Capturing

Voice recording: Yes, AMR

Audio Playback

Audio supported formats: AMR, Midi, MP3, SP-Midi, WAV, AAC

Storage Media

Memory Card Types: Micro SD
Maximum memory card capacity: 2 GB
Memory management: Memory status, Dynamic memory allocation
User memory: 10.5 MB

Network Features

GPRS (Rx+Tx): Class 10 (4+2), Class B
GSM band: 900, 1800, 1900 MHz
Messaging: Concatenated SMS (Long SMS), E-mail, MMS, Multimedia Message Service, SMS CB (Cell Broadcast), SMS (Short Message Service), SMS multi-target, Predefined SMS
Services: OTA provisioning (WAP, MMS), SIM Toolkit / Release 99, WAP 2.0
Voice Codec: FR/EFR/AMR/HR
EDGE

Convenience

Call Management: Call Forwarding, Call on Hold, Call Time, Call Waiting*, Caller ID*, Conference Call, Emergency Call, Microphone mute, Missed Calls, Multi-party call, Received Calls, Firewall
Personal Info Management: Daylight saving, Time Zone, Smart Phonebook, Safeguard, International clock
Personalisation/Customization: Downloadable Picture, Downloadable Ringtones, Fotocall, Wallpaper, Ringtones
Speech Recognition: Conversation Recording, Long voice memo
Clock/Version: Digital, International clock
Ease of Use: Hands free mode, Hot Keys, In-flight mode, Softkeys, Vibra Alert
Ease of Navigation: Active Flip
Buttons and controls: 4-way navigation key and enter, Customized hot key, Soft keys
Language available: T9 input: Chinese Simplified, Chinese Traditional, English, French, Russian, Turkish
Language available: UI: Chinese Simplified, Chinese Traditional, English, French, Indonesian, Romanian, Russian, Thai, Turkish, Vietnamese, Ukrainian
Games and applications: Alarm Clock, Calculator, Calendar, Euro Converter, Java MIDP 2.0, Lunar Calendar, Stopwatch, Countdown timer
Embedded Games: 2

Connectivity

Headset: Via mini USB connector
Wireless connections: Bluetooth
Bluetooth profiles: A2DP, Handsfree, Headset, Object push profile, File transfer profile

Green Specifications

Lead-free soldered product

Accessories

Standard Package Includes: Handset, Battery, Charger, Stereo Headset, USB data cable, CD ROM (Mobile Phone Tools), User Manual

Power

Talk time: up to 8 hrs
Standby time: up to 1 month
Charging time: 3 hr
Battery Capacity: 890
Battery Type: Lithium-ion
Battery saving manager: Auto switch on/off

