



Philips  
Mobile Phone

362

CT3622

## Let me Dazzle you!

Look and performance, a perfect convergence: the Philips 362 camera phone. Endowed with a multi-shot digital camera, super bright light and progressive 4x digital zoom, it's ready to capture your every moment.

### Designed for snapshots

- Integrated VGA digital camera
- Super-bright flash
- Digital continuous zoom for better pictures
- Multi-shot for continuous pictures

### Share digital photos

- MMS (Multimedia Messaging Service)
- Infrared for close-range information exchange
- TV SlideShow

### Connect and enjoy

- Java 2.0 technology
- Embedded games for fun with your phone
- WAP
- E-mail to stay connected wherever you are

# PHILIPS

sense and simplicity

# Highlights

## Integrated VGA digital camera

The integrated digital camera with VGA resolution (640x480 pixels) allows you to take high-quality pictures anytime, anywhere with your phone, then send them via MMS or email, or store the pictures in your phone's memory.

## Super bright torch light

'Super-bright flash is a light generated by LED to take pictures in low light conditions, such as night. Manually activate and deactivate the super-bright flash by pressing and releasing the "+" or "-" volume side key (super-bright flash is automatically de-activated once the photo has been taken).

## Continuous zoom

Continuous digital zoom lets you easily and smoothly zoom the picture in and out from the original, composing better and more meaningful pictures by capturing the right detail at the right distance from the overall scene.

## Multi-shot

Multi-shot for continuous pictures allows you to use a single click to take a sequence of

photos to capture movement. Select continuous shooting: time and interval.

## MMS messaging

MMS (Multimedia Messaging Service) allows you to use your mobile phone to send and receive pictures, video, and audio files with your text messages.

## Infrared

Infrared is the simplest wireless technology for information exchange at close range, allowing easy sharing of images, backgrounds, songs, and phonebook contacts with friends and family and enabling wireless access to the internet through your PC.

## TV SlideShow

TV SlideShow allows you to display pictures from your phone's photo album directly on a TV screen for the fun of sharing pictures from your phone's camera with friends and family. Simply connect your mobile phone and TV with the TV Link accessory to run an automatic or manual slideshow.

## Java 2.0

Java 2.0 technology allows you to enhance and personalize your phone with new games and applications simply by downloading them.

## Embedded games

Embedded games use the bright color screen and keypad to turn your mobile phone into a game station. Simply go to the dedicated submenu to start playing your favorite game.

## WAP

Wireless Application Protocol (WAP) version 1.2.1 is a standardized way for a mobile phone to talk to a server in the mobile phone network to connect your phone to WAP-enabled web sites, allowing you to access comprehensive information whenever you need it.

## E-mail

Electronic mail is another way to stay connected to your contacts with your mobile phone by sending and downloading e-mails as easily as if you were in front of your PC.



# Specifications

## Dimensions

- Handset dimensions: 100 x 45 x 18 mm
- Handset volume: 75 cc
- Handset weight: 83 g
- Form Factor: Candy bar
- Antenna: Integrated
- Handset Color: Dazzling Silver, Luminous Black

## Picture/Display

- Main Display Colors: 65536
- Main Display Resolution: 128x160 pixel
- Main Display Technology: CSTN
- Brightness: 120 cd/m<sup>2</sup>
- Lines of text: 8

## Still Picture Capturing

- Flash: built-in
- Camera: Integrated
- Picture resolution: VGA (640x480)
- Image sensor type: CMOS
- Preview frame rate: 15 frames/second
- Sensitivity: min 5 lux
- Digital zoom: Continuous up to x4
- Special effects preview mode: Grey scale, Sepia, Edge, Digital, Embossed, Negative color
- Picture Mode: Normal, Night mode, Self-timer mode, Multi-shot
- Picture file format: JPEG

## Still Picture Playback

- Picture Compression Format: BMP, GIF, GIF (87a & 89a), JPEG
- Picture Enhancement: Frames & Icons
- Rotation: 90 degree steps
- Slide show

## Sound

- Ringers: Polyphonic (16 tones)

## Audio Capturing

- Voice recording: Yes, AMR

## Audio Playback

- Audio supported formats: AMR, Midi

## Audio Recording

- Recording time: up to 60 seconds

## Storage Media

- Built-in memory capacity: 16
- User memory: 4 MB

## Network Features

- Messaging: Concatenated SMS (Long SMS), E-mail, EMS / release 4, MMS, Multimedia Message Service, Predefined messages (SMS, MMS), Quick SMS, SMS CB (Cell Broadcast), SMS (Short Message Service), SMS multi-target, QQ instant messaging
- Services: OTA provisioning (WAP, MMS), SIM Toolkit / Release 99, WAP 2.0, Internet on mobile, DRM (forward lock), WAP browser Teleca Obigo 3.0
- GPRS (Rx+Tx): Class 10 (4+2), Class B

- Voice Codec: FR/EFR/AMR
- GSM band: 900, 1800 MHz

## Convenience

- Call Management: Call Cost, Call Counters, Call Forwarding, Call on Hold, Call Time, Call Waiting, Caller ID, Conference Call, Emergency Call, Explicit Call Transfer, Microphone mute, Missed Calls, Multi-party call, Received Calls
- Personal Info Management: Smart Phonebook, Vcard Exchange, Safeguard, International clock
- Personalisation/Customization: Downloadable Animated GIF, Downloadable Java Applications, Downloadable Picture, Downloadable Ringtones, Fotocall, Screen Saver, Wallpaper
- Speech Recognition: Conversation Recording, Voice Command, Voice Dial, Voice Recognition, Long voice memo
- Clock/Version: Analogue, Digital, International clock
- Ease of Use: Hands free mode, Hot Keys, Keypad Lock, Screen Saver Digital Clock, Vibra Alert, Softkeys
- Buttons and controls: 4-way navigation key and enter, Customized hot key
- Games and applications: Agenda, Alarm Clock, Calculator, Calendar, Java MIDP 2.0, Lunar Calendar, Exen Game Extensions (EGE), International converter, Java JTWI 1.1, Voice reminder if appointment
- Embedded Games: 4
- Text input: T9, T9 user database, Character counter

## Connectivity

- Headset: Via bottom connector
- Serial connections: USB-Bottom connector cable
- Modem Capabilities: CSD (Voice, Data), GPRS, SMS
- PC Link: USB 1.1
- Synchronisation PC organizer: Lotus Notes, MS Outlook
- Wireless connections: Infrared

## Accessories

- Standard Package Includes: Battery, Charger, Handset, International Guarantee, SAR information leaflet, User Manual
- Optional accessories: Car cradle, Carry case, Cigarette lighter adapter, Deluxe FM headset, Deluxe headset, Necklace, Stereo FM handsfree headset, TV Link, Universal car kit, USB data cable + PC software

## Green Specifications

- Lead-free soldered product

## Power

- Talk time: up to 6 hrs
- Standby time: up to 400 hrs
- Charging time: less than 2.5 hours hr
- Battery capacity: 750 mAh
- Battery Type: Li-ion
- Battery saving manager: Auto switch on/off



Issue date 2012-01-20

Version: 3.0.5

12 NC: 9961 400 04777

© 2012 Koninklijke Philips Electronics N.V.  
All Rights reserved.

Specifications are subject to change without notice.  
Trademarks are the property of Koninklijke Philips  
Electronics N.V. or their respective owners.

[www.philips.com](http://www.philips.com)