Discover Your Phone



Philips continuously strives to improve its products. Therefore, Philips reserves the rights to revise this user guide or withdraw it at any time without prior notice. Philips provides this user guide "as is" and does not accept, except as required by applicable law, liability for any error, omission or discrepancy between this user guide and the product described. The device is meant to be connected to GSM/GPRS networks.

How to ...

Switch the phone On/Off	Long press and release .
Enter your PIN code	Enter your PIN code using the keypad and press $\textcircled{-}$ to confirm.
Lock/unlock the keypad	Long press (*.86).
Make a call	Enter the phone number using the keypad and press \odot .
End a call	Press .
Answer a call	When the phone rings, press $oxdot$.
Activate/ deactivate handsfree mode	During a call, press —Loudsp. to activate the handsfree mode. When there is an incoming call, press —Options, then select Accept with handsfree and press —O.
Mute a call	When the phone rings, press Silent.

Reject a call	When the phone rings, press .
Adjust conversation volume	Press volume side keys to adjust the volume during a call.
Adjust ring volume	When the phone is in idle mode, press ⊗ > Settings > Sounds > Ring volume to adjust the ring volume of an incoming call.
Access all calls list	Press in idle mode.
Access Main Menu	Press ⊗ in idle mode.
Go to previous menu	Press <u>Back</u> when browsing menu or in editing mode.
Quickly return to idle when browsing menus	Short press ⊡.

Soft keys

The left and right soft keys (\bigcirc and \bigcirc) are located at the top of the keypad area. Pressing the soft keys allows you to select the option displayed on the screen directly above them, including options during a call. The functions of the soft keys change according to the current context.

Operations of the headset

The following operations are applicable to headsets with only one key.

When you enter a phone number in idle mode, short press the headset key to dial the number. To stop dialing, long press the headset key.

During a call, short press the headset key to record or stop recording; long press to hang up the phone. When there is an incoming call, press the headset key to answer the call; long press to reject the call.

Main Menu

You can access different features of your Xenium X520 phone from the main menu. The following table summarizes the structure of the main menu, what the icons represent and the page number on which you

can obtain more information regarding the menu functions.

Entertainment	Browser	Media player
page 20	page 21	page 24
Camera	Messages	My Favorites
<u>o</u> .	Page 33	
page 28	page 33	page 46
Business	Contacts	Profiles
	↓ E	22
page 50	page 56	page 59
Connectivity	Calls	Settings
O		*
page 61	page 64	page 68

Press \odot in idle mode to access the main menu and press $_{\bullet}$, $_{\bullet}$, $_{\bullet}$ or $_{\bullet}$ to navigate through the icons and lists,

or press • - • keys, and • or • keys to access the options and functions directly. You can also press • to set the browse style as List or Grid.

When navigating through a list, the scrolling bar on the right of the screen will indicate your current position in the list. Press

Select to access the corresponding options of the selected item in the list. Press

Back to return to the previous menu.

Menu without SIM

If you do not have a SIM card, those menu items whose functions that cannot work without a SIM will be greyed out and not accessible.

Setting hot keys

You can configure the , , , , , = and = to access your favorite features.

Majority of the hotkeys have been preset and configured. To check the hotkey settings, go to Settings > General > Shortcuts. To change the hot key settings, press the key you wish to change and press @ Change, then select a feature to be associated with the numeric key from the following list:

Alarm

Bluetooth

Calculator

Calendar

• View calls	• Camera
• Contacts	• Create message
• Firewall	• Flight mode
• Games	 Homepage
• Inbox	 Languages
• Menu	 Messages
Meeting	• Music
• My Favorites	• Profiles
• Ringtones	• Shortcuts
• Tasks	• Unit converter
• Flash dial	 Voice recorder
• Secretary OTG	• Empty

Numeric keys ..., ..., and have been preconfigured as the default keys to enter "+", access voice mailbox, activate Meeting profile and unlock the keypad respectively, and cannot be modified.

Table of contents

١.	Getting Started	. 7
	Inserting the SIM card	. 7
	Charging the the phone	. 9
	Using the AC power	. 9
	Using the backupower TM	. 9
	Recharging the AAA battery	
	Inserting a micro SD Card	
2.	Calling	
	Switch on the phone	
	Switch off the phone	
	Make a call	
	Options during a call	
	Mute or unmute a call	
	Adjust speaker/earpiece volume	
	Call recording	
	End a call	
	Make an international call	14
	Make an emergency call	15
	Make a second call (Network dependent)	
	Make a Conference Call (Network	
	dependent)	15
	Switch calls (Network dependent)	
	, , ,	

	Call Handsfree	
	IP Dial (if available)	. 16
	Answer a call	. 16
	Reject a call	. 16
	Answer a second call (Network	
	dependent)	. 16
	Contact Picture	. 16
3.	Text entry	. 18
	Select text entry methods	. 18
	Enter text	
4.	Entertainment	. 20
	Games	. 20
	JAVA	. 20
5.	Browser	
	WAP	2
	Push Inbox	
5 .	Media Player	. 24
	FM radio	
	Music player	
7.	Camera	
•	Camera	
	Carriera	

Video recorder	30
8. Messages	33
Create message	33
Inbox	
Sent	37
Outbox	38
Drafts	39
My favourites	39
Spam box	40
SIM archive	40
Templates	41
Email	41
Advanced	43
Voice mail	44
Settings	44
9. My Favorites	46
Pictures	46
Sounds	47
Videos	48
Others	49
Memory status	49
10. Business	50
Calendar	50
Alarm	
Calculator	51
Voice recorder	52

Secretary OTG	52
Stopwatch	52
Countdown	
Unit converter	53
Firewall	53
Task	
II. Contacts	56
New contacts	56
View contacts	57
View groups	57
Special numbers	58
Advanced	
12. Profiles	
I3. Connectivity	
	61
I3. Connectivity	61 61
I3. Connectivity	61 61 62
I3. Connectivity Bluetooth USB function Using PhilipsPhoneTools	61 61 62 62
Bluetooth	61 61 62 62 64
Bluetooth	61 61 62 62 64
I 3. Connectivity Bluetooth USB function Using PhilipsPhoneTools I 4. Calls View calls Call options	61 61 62 62 64 64
I 3. Connectivity Bluetooth USB function Using PhilipsPhoneTools I 4. Calls View calls Call options Clear history	61 62 62 64 64 64 67
I 3. Connectivity Bluetooth USB function Using PhilipsPhoneTools I 4. Calls View calls Call options Clear history I 5. Settings	61 62 62 64 64 64 67
I 3. Connectivity Bluetooth USB function Using PhilipsPhoneTools I 4. Calls View calls Call options Clear history Transfer backupower	61 62 62 64 64 64 67 68
I 3. Connectivity Bluetooth USB function Using PhilipsPhoneTools I 4. Calls View calls Call options Clear history I 5. Settings	61 62 62 64 64 67 68 68

Sounds	71
Connectivity	7I
Icons & Symbols	73
Precautions	75
Troubleshooting	81
Philips Authentic Accessories	83
Trademark Declaration	84
Specific Absorption Rate Information	85
Limited Warranty	86
Declaration of conformity	

I. Getting Started

Please read the safety instructions in the "Precautions" section before use.

Before you start using your phone, you must insert a valid SIM card supplied by your GSM operator or retailer. The SIM card contains your subscription information, your mobile telephone number, and a small quantity of memory in which you can store phone numbers and messages (for more information, see "Contacts" on page 57).

Inserting the SIM card

Remove the back cover

Make sure that the phone is switched off. Hold the phone with the front facing downwards and slide the back cover upwards as shown below.



Remove the battery

Lift the battery up from the bottom as shown below.



You may lose all your personal settings if you remove the battery when the phone is switched on.

Insert the SIM card

Make sure that the clipped corner of the SIM card is facing the correct direction and the metallic contacts are facing downwards. Slide the SIM card into the card slot until it stops. When you remove your SIM card the first time, make sure that you smoothen the edges, otherwise you may have difficulty sliding in the card.



Replace the battery

With the metallic contacts facing upwards, press the battery down into its slot until it locks into place.



Replace the back coverSlide the back cover down into its slot until it stops.



When inserting the battery, be careful not to damage the metallic connectors of the SIM card slot.

Charging the phone

Your phone is powered by a rechargeable main battery and a smartcavityTM that supports the backupowerTM technology. You can use the backupowerTM feature to keep your phone running when the AC charger is inconvenient.

Using the AC power

Once the main battery and battery cover are installed, you can charge the phone. Plug in the connector as shown below. Then plug the other end into an AC power socket.



On the idle screen, the two battery symbols indicate the state of charging, the left one for the main battery and the right one for the AAA battery. During charging, the left indicator will scroll and it

takes more than 3 hours to fully charge the main battery.

If you do not intend to use your phone for several days, we recommend that you remove the battery.

You can use the phone while it is charging. If the battery is completely flat, the battery icon will only reappear after a few minutes of charging.

Using the backupowerTM

The backupowerTM technology accepts either a standard AAA battery or a rechargeable AAA battery.

One Energizer Lithium AAA battery can provide extra talk time or and extra stand-by time.

Use quality batteries to ensure that the battery can be correctly detected by your phone. Your phone is by-packed with an Energizer Lithium AAA battery (non-rechargeable battery), the world's longest-lasting AAA battery used in high tech devices.

Insert an AAA battery

- A key comes with the supplied phone strap. Use the key to loosen the AAA battery cap on the smartcavityTM.
- Take off the battery cap by hand, and put in the battery.





Tighten the battery cap by hand. Stop tightening the cap when it is secure (at the groove).



When an AAA battery is inserted, the AAA battery cap cannot be pushed inside completely. There will be a protrusion at around 5mm.

Remove the AAA battery if you will not use it for power transfer for a long time.

Charge your phone using the AAA battery The detection of AAA battery starts after you insert the AAA battery into the smartcavityTM. During the detection process, a question mark appears on the right battery symbol.

- Check that the AAA battery has sufficient power (the right battery symbol is not in red).
- 2. Automatic charging:
- If the main battery is low, the AAA battery in the smartcavity[™] will charge the main battery automatically. The message "Transferring" is displayed.

Manual charging:

- Select Settings > Transfer backpower to start charging.
- Select Stop transferring backpower to stop charging.

When the main battery voltage reaches 4.0V, the AAA battery will automatically stop charging the main battery.

No audible alert or message is given by your phone if the backpower transfer happens at the time that your phone is turned off.

Use the AAA battery in time of drained main battery

If the main battery is drained and your phone cannot be powered on, you can insert a full capacity AAA battery into the smartcavityTM. It will automatically charge the main battery and your phone can be powered on again. The time needed for charging depends on the remaining power of

the main battery. The lower the voltage, the longer is takes to wake up the main battery.

Recharging the AAA battery

If you have put a rechargeable AAA battery in the smartcavity TM, you can charge both the main battery and AAA battery using the AC power charger(see "Using the AC power" on page 9). Charging of AAA battery starts after the main battery is fully charged. If any of the main battery or rechargeable AAA battery is full, only the other one will be charged.

Your phone accepts disposable Alkaline, Lithium batteries and rechargeable Nickel Metal Hydride (NiMH) batteries. We recommend that you use Energizer batteries.

Remove the non-rechargeable AAA battery from the smartcavityTM before you plug the charger into the AC power socket.

Disconnect your charger from the AC power after the rechargeable AAA battery is fully charged.

Inserting a Micro-SD card

You can expand the memory of your phone by adding a Micro-SD card.

 Gently slip the card into the micro SD card slot, with the gold contacts facing downwards.



Press the card until it is locked in place. To remove the card, press the card to unlock it first.

X520 can support up to 2GB micro SD card.

2. Calling

This chapter describes the features and options related to making and receiving calls.

Switch on the phone

Long press

to switch on the phone.

You may set a security code (PIN code) on your phone to protect it from unauthorized use. If you have set a security code, you will be prompted to enter the corresponding security code when you switched on the phone.

- Enter the PIN code. If you have entered the wrong number, press

 Clear to clear it.
- Press ⊕. The phone will validate the PIN code and commence network registration.
- Once a network name is displayed on the screen, you are ready to make or answer a call. If there is no network name on the screen, you need to re-register.

If you enter a wrong PIN code 3 times in succession, your SIM card will be blocked. To unblock it, you must request the PUK code from your operator. If you enter a wrong PUK code 10 times in succession, your SIM card will be permanently blocked and cannot be used

anymore. If this happens, please contact your network operator.

Switch off the phone

At all times, you can long press \odot to switch off the phone.

Make a call

You can make a call only when the network name appears on the screen.

- I. Enter the phone number.
- Press
 to dial the number or press
 Options
 to enter options menu, then select Dial.

Speed dial

On the idle screen, you can call a contact in your phonebook by long pressing a numeric key. To assign a speed dial key to a contact:

- I. Go to Settings > General > Speed dial.
- 2. Select one of the locations (2... to 9....).
- Assign to the location a contact from your phonebook.

Options during a call

During a call, you can press \bigcirc to activate/cancel *Loudsp.* or press \bigcirc *Options* to carry out the following operations:

- Put the call on Hold
- Mute/Unmute the call
- Record phone conversation (which includes 3 sub-options: Record both, Record the opposite party and Record own)
- Make a New call
- End the current call

Mute or unmute a call

During a call, press © Options and select Mute or Unmute. If you select Mute, the microphone will be deactivated.

When you switch from one call to another, muting will be cancelled.

Adjust speaker/earpiece volume

During a call, call on hold or call waiting, you can press + or - side key to increase or decrease the volume (if you are not browsing the call options menu).

When the volume has been set, the call volume will take effect immediately and the settings will be applied to your subsequent calls.

Call recording

During a call, press ① Options and select Record to access the 3 recording options; namely, Record both (default), Record the opposite party and Record own (applicable to two-party calls or multi-party calls). When you end the call, the recording will stop and save automatically in AMR format under My files > Sounds.

There is no limit to the length of the recording; the recording will stop only when you press key to stop the recording, when there is insufficient memory, or when the call has ended.

End a call

Press To end a call.

Make an international call

- 1. Long press on the screen.
- 2. Enter the country code.
- 3. Enter the area code (normally without the 0 in front), followed by the phone number.

4. Press - to call directly.

Make an emergency call

You can make an emergency call anytime, irrespective of whether the mobile phone has been registered on the network.

- I. In idle mode, enter the emergency call number (specific number in the caller's country)
- 2. Press -.

Note that an emergency call will not be stored in the call record.

Make a second call (Network dependent)

You can make a second call by putting the current call on hold:

 During a call with Party A, you can enter Party B's number using the keypad. Press

to dial Party B's number. Party A will be put on hold automatically.

Make a Conference Call (Network dependent)

Your phone supports multi-party call of up to five members. The screen will display *Conference call* during the multi-party call.

When there is a call waiting while you are already on the phone, you can carry out the following operations to establish the multi-party call:

- Select Conference Call from the call menu. The two calls will be combined and a conference call is established.

During the multi-party call, you can answer a new incoming call or add a new member to the call by dialing the new member (the ongoing multi-party call will be put on hold automatically). Once the call is established, select *Establish conference call* from the call menu to add the new member to the multi-party call (you can add up to five members).

If you wish to separate one member from the call, you can select Split conference call during the multi-

party call. To disconnect a member from the call, select *End call in conference*.

Switch calls (Network dependent)

When you have one active call and one call on hold, you can press Θ Swap to switch between the two calls.

Call Handsfree

During a call, press -Loudsp..

IP Dial (if available)

You may select *IP dial*. When you select *IP dial* option, the mobile phone will automatically add the *IP* special service number preset by you in front of the phone number and then make the *IP* dial.

Answer a call

Press (-) to answer a call.

Reject a call

Press - to reject a call.

Answer a second call (Network dependent)

If you have activated *Call waiting*, you will be alerted when there is a second incoming call. You can:

- Press

 to answer the second call. The current call will be put on hold automatically.
- Press
 to reject the second call and continue with your current call.
- Conference call
- Transfer call
- Loudsp.End all calls

MuteEnd call

- RecordView contact
- Menu

Contact Picture

This feature allows you to link a contact in your phonebook to a photo you have taken using the camera function, or a picture you have downloaded via WAP or data cable. During a call, if the other party's name card is linked to a picture, the incoming call background will display the

corresponding picture. This feature is referred to as *Contact picture*.

Contact picture is only available on the phone memory. The photo size should not be larger than 176 x 220 pixels.

Calling

3. Text entry

Your mobile phone supports a number of text entry modes, including T9 input, multi-tap input, numeric input and symbol input.

Select text entry methods

- During text editing, press **repeatedly to select your desired inputs:
 - Abc / abc / ABC : for English entry
 - : for numeric entry
 - : Pinyin input for Simplified Chinese
- Long press to switch the T9 English input on or off.
- 3. To enter a symbol and punctuations, press

The text editor remembers the last input method you have used before you exit the editing screen. When you access the editor again, it will automatically select the last input method you have used.

Depending on the language you select for your phone, the supported input methods may vary.

Enter text

- 1. Select your desired text entry methods.
- .. Enter text by using the alphanumeric keypad.

 2. to 9. To input letters (T9 input)

 Press repeatedly to input the desired letter (multi-tap input)
 - to 🖘 To enter strokes (stroke input)
 - To browse candidate words (T9 input/multi-tap input)
 - To browse the candidate words on the previous/next page (T9 input/multi-tap input)
 - Select To confirm the selection
 - To input a space
 - ☐ Clear Short press to clear a letter, long press to clear all entries. If necessary, press ☐ Back to exit the input mode first.

T9[®] input



T9[®] predictive text input is an intelligent editing mode for messages, which includes a comprehensive dictionary. It allows you to quickly enter text. You need to press only

once on the key corresponding to each letter needed to spell a word: keystrokes input are analyzed and the word suggested by $T9^{\circledR}$ is displayed at the pop-up window.

Examples: how to enter the word "home":

- Press 4..., 6..., 6..., 3.... The screen displays the first word of a list: Good.
- 2. Press to scroll and select Home.
- 3. Press Select to confirm.

Multi-tap input (ABC/Abc/abc)

Press the keys that are marked with the corresponding letter you wish to enter. Press once to get the first letter on the key, press twice quickly to get the second letter and so on until the letter you want is displayed on the screen.

Example: how to enter the word "home":

Press a_{m} , a_{m} (GH/) a_{m} , a_{m} ,

Stroke input

The principle of stroke input is to dissect and separate every stroke of a Chinese character according to sequence. When you wish to input the character, press the keys corresponding to the

required strokes according to sequence to get the desired character. The stroke input method in this phone classifies a Chinese character into 5 basic strokes: (horizontal, vertical, left falling stroke, right falling stroke and over-down) as well as a special stroke. When the stroke you need does not correspond to the 5 basic strokes, replace it with the special stroke.

Text entry I

4. Entertainment



This section describes the games and additional tools installed on your mobile phone.

Some of the features described here are dependent on the configuration of your mobile phone, the country in which you purchased your mobile phone, and/or your service provider.

Games

Default games

This menu features games that are pre-installed in your mobile phone. Press @ to enter the main menu from idle mode and select Entertainment > Games.

Java

Your mobile phone features a Java run-time environment, which allows you to run Java applications, such as games downloaded from the network. You can also download games and other

applications via WAP or USB and run them in the lava environment.

When installing games via a USB data cable, make sure that the application files are under the same file folder as the .jar and .jad files.

20 Entertainment

5. Browser



Your phone comes with a WAP browser. You can obtain news, sports and weather information, as well as services from the internet via the WAP browser.

This feature is available only if your subscription includes WAP access services. The settings have been pre-configured (depends on country variants) and you do not need to modify them. For more information, please contact your network operator.

WAP

Normally, the phone would have been preconfigured. If you wish to add or modify the configuration parameters, you need to obtain the necessary information from your network operator before you proceed. Philips is not liable to give prior notification nor shall it bear any consequences for any failures arising from changes of configuration made by you or by the network operator. Please check with your network operator for the most updated information.

Нотераде

Select this menu to access the homepage directly. You can also set the homepage address in the settings menu.

Bookmarks

You can save the current web page or the web pages that you frequently visit to the *Bookmarks* list, manage and organize them.

When you enter the menu, a list of bookmark entries is displayed. To connect to the web address of a particular bookmark entry, select an entry using \star or \star and press Θ .

If there are no existing entries, you can select the following options to add and manage your bookmarks:

Add bookmark Edit the title and web address.

Browser 2

To add a new bookmark:

Go to Bookmark menu Press @ to enter the main menu from idle

mode and select Browser > Bookmarks.

Select Add bookmark Add a new bookmark Press @. Enter the Address and

Title of bookmark and press @

Save.

To edit a bookmark:

Go to Bookmark menu

Press @ to enter the main menu from idle mode and select Browser > Bookmarks.

Select a bookmark you wish to edit

Press • or • and press Options. Then select Edit and press @Select.

Edit the bookmark

Edit the Title and URL of the bookmark and press ⊚.

Enter address

Enter the web address and press @ to connect, press Back to return to previous web page.

History

This menu allows you to quickly access the last web page you have visited.

- When you enter this menu, the web pages you have previously visited will be listed.
- 2. Select a web page on the list and press @. Then press Options to access the following:

Open Info

Navigate

Fxit

Go to

History

Save as

Send as SMS

Settings

This menu allows you to configure the web settings for web browsing. Your phone may have been preconfigured with the settings of a specific network operator. If you are a subscriber of the network operator, you may start using your WAP browser immediately. Otherwise, you need to re-configure the settings.

Philips is not liable to give prior notification nor shall it bear any consequences for failures arising from changes in configuration made by

22 Browser you or by the network operator, or changes in WAP address or contents made by the internet content provider. Please check with your network operator and your internet content provider for the most updated information.

The following options are available:

WAP profiles Allows you to configure the WAP

profiles.

Clear cache Allows you to set the Clear cache.

Clear history Allows you to remove the web

history.

Options Allows you to Show images, Exit info

or Enable cookies.

Push Inbox

Allows you to check your Push messages and configure your Push settings, such as select whether or not to accept Push messages, delete push messages, etc.

Browser 23

6. Media player



FM radio

This menu allows you to listen to the radio on your phone. Connect the headset connector to your phone. There are 2 ways to tune to a station: auto tune and manual tune.

Auto tune

Press A to enable auto search. The auto search icon lights up. The scanning of radio stations starts. The search will stop once a nearest station is found and the screen will show the frequency where it stops. Press · or · to tune to the next available station.

When you select Auto preset, the channel will be searched automatically. When the auto preset is in process, all the keys are made unavailable except \odot and \odot .

Manual tune

Press A to disable auto search. The auto search icon dims. Press • or • for tune to a radio station.

Keys operation

The keypad operations during radio broadcast are as follows:

Key	Operation
•	Short press to start/stop radio playback.
-	Exit the radio menu and return to the idle mode.
·or›	Short press to select the previous or next radio station from the preset list.
Volume side keys	Adjust the volume. Once you have set the volume, the settings will be saved until the next time you adjust it again.
Options	Open options menu.
⊝ Back	Return to previous menu.
FM radio op	tions menu
	Save the current radio frequency to selected presets

Saved as	Save the current radio frequency to
preset	selected presets.

24 Media player Preset Show list of radio frequency presets. When you highlight on a stations

preset station, you can select to Play, Rename or Clear the selected

station.

Auto presets Scan the radio frequency

automatically and save it to the

preset channel list.

Off Stop the radio.

Play in background Allows you to listen to the radio station when you exit the radio

application.

RDS (dependent on the radio station service)

The feature RDS (Radio Data System) is a service that allows FM stations to send additional information along with the regular FM radio signal. When you are listening to an RDS station, received text information rolls on the screen. including station name, program type (for example, News, Sports, and Info), and frequency. A pop-up window appears when radio text messages are received

Music player

This feature allows you to download music from the network, save the audio files, edit your playlist, and play music. The phone supports audio files in MP3 and AAC format. However, only MP3 format is supported with the bluetooth headset.

Tracks

This feature allows you to play downloaded music in your Phone memory or Memory card (under Sounds folder). From the listed tracks, use 4/v to select the music file you want to play and then press Open to open the music player to play the selected track or press

Options.

Options Description

λdd playlist Open the playlist, select a playlist and add the selected track to the

playlist.

Delete track Delete the selected track.

Details View detailed information of the

selected track.

Playlists

The stored playlists are displayed on the screen. To create a new playlist, select New playlist. Enter the

Media player 2.5 playlist name and press Θ . Then use 4/4 to select a playlist, press Θ . Then press Θ Edit and select the tracks that you want to add to the playlist. Then press Θ Done to confirm and store the songs in the playlist.

You can create up to 10 playlists. You can press *⊙Open* to open the music player to play the selected track or press *⊙Options*.

Options Description
Edit playlist Edit the playlist.

Rename Modify the playlist name.

playlist

Delete Delete the current playlist.

playlist

Tracks Modify the play sequence of the sequence current playlist.

Details View detailed information of the selected file.

Artists

A list of singer names is displayed on the screen. You can press 1/2 to select a certain artist and press to display all tracks of the selected artist.

From the listed tracks, use 1/2 to select the music file you want to play. You can press Open to open

the music player to play the selected track or press

Options.

Options Description

Add to playlist

Open the playlist, select a playlist and add the selected track to the

playlist.

Delete

Delete the selected track.

track

Delete Delete all tracks of the same artist.

artist

Details View detailed information of the

selected track.

Description

Last played

List the last 10 tracks you have played, and the last played track is displayed at the top of the list.

Settings

The available options include:

Options Play in background

Allows you to listen to the music when you exit the music player

application. You can select Ask

first, Always or Never.

26 Media player

Play mode	Select between Repeat one, Repeat all, Shuffle and repeat, Shuffle or Off.
Help	Display descriptions on how to use the music player.
Refresh all lists	All tracks stored in the phone memory and the memory card will be refreshed.

Now playing

The screen displays the last played song. This function enables you to go on playing the last playlist you were listening to.

Keys operation

The keypad operations during music playback are as follows:

Key	Operation
©K)	Short press to start/pause/resume the music playback.
· or ·	Short press to select the previous song/next song. Long press to fast rewind/fast forward the track during playback.

	saved until the next time you adjust it again.
Options	Open options menu.
⊕Back	Return to previous menu. When you exit the music player, the music playback will stop.
Press - Option operations:	ns to carry out the following
Play in background	Allows you to listen to the music when you exit the music player application. You can select Ask first, Always or Never.
Add to playlist	Open the playlist, select a playlist and add the selected track to the playlist.
Play mode	Select between Repeat one, Repeat all, Shuffle and repeat, Shuffle or Off.
Off	Turn off the music player.
Details	View detailed information of the selected track.

Adjust volume. Once you have set

the volume, the settings will be

Media player 27

▲ or ▼

7. Camera



Camera

Your mobile phone features a 2.0 mega pixel digital camera that allows you to take pictures and record videos, store them in your phone and memory card, use them as wallpaper or send them to your friends.

Please ensure that the camera lens is clean before you take pictures, as small dust particles can strongly affect the picture quality.

Camera mode

Consult the table below on how to carry out some common operations with your camera.

How to ...

Launch Camera

Press ⊚ to enter the main menu from the idle mode and select *Camera*. Then switch to the camera mode.

Zoom in/out Press 4/v.

Only available for picture resolution of 640*480 or below.

Adjust Press A/v side keys.

Brightness level is -3 to +3.
Default level is 0.

Take a picture

The picture will be automatically saved and stored in My Favorites > Pictures.

Exit from Camera and return to the idle mode Press - key or -Back twice.

At any point in time, you can press \bigcirc key to cancel the current operation and return to the idle mode.

Press @.

28 Camera

Camera	option	menu

When the camera mode is activated and before a picture is taken, you can change a number of settings by pressing ①Options.

Options	Description
Picture resolution	Select image size: 1600*1200, 1280*1024, 1024*768, 640*480 and 176*220.
Picture quality	Select image quality: Superfine, Fine and Normal.
	The last selected value will remain active until you change it again.
View picture	View the pictures taken.

Camera Color effects: Off (default), B&W, Mode Sepia, Blue or Red.

The selected color effect will be displayed on the screen in real time.

Night mode: On or Off Self-timer: On or Off

The time limit is 8 seconds.

Multishot: On or Off

Three pictures can be taken at the same time.

Advanced

Storage location: My files or Memory card

Default name: modify the default name of the photo.

Photo preview option menu

Once you have activated the camera, simply press • to take a picture. The picture is automatically saved and displayed on the screen. You can press •

Frequency: 50Hz or 60Hz

Camera 29

to Send the picture via Bluetooth or via MMS, or Options to carry out the following operations:

Options	Description
Delete	Delete the current picture.
Rename	Change the name of the picture.
Capture	Return to the viewfinder screen to take a new picture.
Set as contact picture	Link the picture to a contact in your mobile phone so that the picture will be displayed when the contact calls you.
	Available for picture resolution of 176*220 only.
Details	View detailed information of the picture.

When there is not enough memory space, you will not be able to save the picture and you will be prompted with a warning message. You have to delete existing pictures before you can store new ones.

Video recorder

This option allows you to record short videos. You can play the video, store it in your phone or in the memory card. You can also send the video to your friends via MMS or Bluetooth.

How to	
Launch Video recorder	Press © to enter the main menu in idle mode and select <i>Camera</i> . Then, press • or • to switch to the video mode.
Adjust	Press ₄/▼ side keys.
brightness	Brightness level is -3 to +3. Default level is 0.
Record a video	Press $\ensuremath{ ilde{\odot}}$ key once. Press again to stop recording.
	The video will be automatically saved and stored in My Favorites > Videos.
Exit from Video mode	Press key or Back twice.

30 Camera

and return to idle mode

Video option menu

When the video mode is activated and before you start recording, you can change a number of settings by pressing ①Options.

Options

Description

Video quality

Select video quality: Fine or Normal.

The last selected value will remain active until you change it again.

View video View the recorded videos.

Video mode

Color effect: Off (default), B&W, Sepia, Blue, or Red

The selected color effect will be displayed on the screen.

Video format: MPEG-4 or H263 Frames per second: 5, 10 or 15 frame per second. Advanced

Storage location: My files or Memory card.

Default name: modify the default name of the video

Mute: On or Off

If you select On, sound will not be recorded.

Video length: MMS (default) or Unlimited.

If you select MMS, the size of the recorded video will be smaller than the currently specified maximum MMS size. Recording will stop when reaching the maximum MMS size and the video will be stored automatically. If you select Unlimited, there will be no restrictions on the size of the recorded video. The maximum size shall be determined by the memory capacity of your mobile phone or the memory card.

Camera 3

Video Playback

Once you have activated the video mode, simply press \odot to start recording. Press again to stop recording. The video is automatically saved and the last recorded scene is displayed on the screen. You can press \odot *Play/Pause* to play the recorded video or pause the playback, or press \odot *Options* to carry out the following operations:

Options	Description
Send	Send the recorded video: Via Bluetooth and Via MMS.
Delete	Delete the recorded video.
Record new	Return to video mode to record a new video clip.
Details	View detailed information of the recorded video.

When there is not enough memory space, you will not be able to save the recorded video and you will be prompted with a warning message.

32 Camera

8. Messages



Create message

SMS

SMS enables you to send text messages to the other party, which is a convenient and affordable mode of communication. You can use the SMS menu to send messages to another handphone or a device that is capable of receiving SMS. Your phone can store up to 1000 messages. Once you have reached 1000 messages, the screen will flash an icon to alert you. You need to delete some messages in order to receive new ones.

Create, edit and send SMS

You need to enter the correct message centre number before you can send SMS. The number can be obtained from your network operator.

- 1. In idle mode, press @ to enter the main menu.
- Select Messages > Create Message > SMS and press ⊕. The SMS editing screen will appear.

 Enter the SMS content in the SMS editor and press

 Options to carry out the following operations:

Clear text Delete the text on the editing

screen.

Save Save as draft: save the SMS as draft.

Save as template: save the SMS as

template.

Insert contact Insert the contact from the

phonebook list.

Use template Insert a preset message.

Exit editor Exit from the SMS editor.

Spell word for T9 input: Add to the memory

the words you frequently input.

Help Displays the shortcuts for editing.

If your SMS is not sent successfully, you can resend it. If your SMS cannot be sent successfully after several attempts, please check if your SMS center number has been set correctly.

When editing SMS, for certain reasons (such as an incoming call, out of battery), you are forced

Messages 33

to exit from the SMS editing screen before you managed to send or save your message successfully, the edited message will be saved automatically. The next time you enter the SMS editor, the message will be displayed on the screen.

MMS (network dependent)

Your phone allows you to send and receive multimedia messages, known as MMS, which features texts, pictures, sound and video clips. MMS can comprise one or several slides. Whether you send it to an e-mail address or to another mobile phone, the MMS will be played as a slide show.

Your phone can support 50 MMS (maximum 100KB).

Before you can send MMS, you need to enter the correct MMS Center number and ensure that the network profile of your MMS has been correctly configured. You can obtain such information from your network operator.

Create, edit and send MMS

- 1. In idle mode, press

 to enter the main menu.
- Select Messages > Create Message > MMS and press ⊕. The MMS editing screen will appear.

Insert object Insert picture, video, melody, page or object.

Only a picture, a melody and a video can be inserted on one page. If 3 of them exist at the same time, only one can be saved.

Edit subject Edit the subject of the MMS.

Preview Preview the current MMS.

Page timing Set play time of the MMS slides. The default value is 30 seconds.

Save Save as draft: save the MMS as draft.

Save as template: save the MMS as

template.

Exit editor Exit from the MMS editor.

Spell word for T9 input: Add to the memory the words you frequently input.

Help Displays the shortcuts for editing.

When there is more than one page, you can press
 to view the different pages of the MMS. At the

34 Messages

same time, the title bar at the top of the screen will display the current page you are viewing and the total number of pages in your MMS.

4. Press @ Send to access the next option menu:

Contacts	Select the contact from the <i>Contacts</i> list.
Groups	Select the group from the <i>Groups</i> list.
Phone number	Enter the phone number of the recipient.
Recently list	Select from the list of recipients you received the messages from.
Email address	Enter the e-mail address of the recipient.

Inbox

The Inbox stores the messages you have received.

I. In idle mode, press ⊚ to enter the main menu.

- 2. Select Messages > Inbox and press ⊕.
- If there are messages in the *Inbox*, they will be listed on the screen in the order they were received (the most recent message will appear at the top of the list).

4. Press △/• to select a message. When a message is selected, its contents will be displayed on the screen. Press ⊚View to view the selected messages or press ⊙Options to carry out the following operations:

Reply	The sender's number will be used as the destination number automatically and the message editor will be activated. Enter your reply and send the message.
Forward	When you select Forward, the contents of the selected message will appear in the message editor. You may edit the message before sending.
Delete	Delete the message from the

Delete	Inbox.
Add to blacklist (for SMS only)	When you add the contact to the blacklist, you will not receive call/ message from this contact anymore.
Archive to SIM	Copy the selected message to SIM

archive.

Messages 35

Move to my favourites	Move the selected message to My favourites.	operation:	to carry out the following s:
Details	View information of the message such as date, time and sender.	Forward	When you select Forward, the contents of the selected message will appear in the message editor.
Dial	Extract the sender's number from the message and dial the number.		You may edit the message before sending.
Smart search (for SMS	Search the messages by sender's name, number or time.	Delete	Delete the message from the <i>Inbox</i> .
only) Select multiple	You can choose to Select one by one or Select all. You can press ⊚ to Select/Undone the operations on multiple messages. Checkboxes will be marked on the left of the selected message. Press ⊡Options to delete the selected messages, or you can move them to My favourites.	Extract numbers	Opens the list of numbers available in the message. In this list, the — option opens a pop-up window showing the following options: • Save • Update existing • Dial • Send message When you add the contact to the
message d	o enter the next screen whereby the etails will be displayed. Press @Reply age by SMS or MMS or press	blacklist Archive to SIM	blacklist, you will not receive call/ message from this contact anymore. Copy the selected message to SIM
		rucinie to sim	archive.

Move to my	Move the selected message to My
favourites	favourites.
Move to spam box	Move the selected message to spam box.
Details	View information of the message such as date, time and sender.
Dial	Extract the sender's number from

S - --- 4

Sent

The Sent box allows you to save the messages you have sent successfully.

the message and dial the number.

- I. In idle mode, press $\ensuremath{ ilde{\otimes}}$ to enter the main menu.
- 2. Select Messages > Sent and press ⊚.
- If there are messages in the Sent box, they will be listed on the screen.
- Press */* to select a message. When a message is selected, its contents will be displayed on the screen. Press @View to view the selected

mesage, or press <a>Options to carry out the following operations:

Resend Resend the selected message.

Forward When you select Forward, the contents of the selected message will appear on the message editor. You may edit the message before

Delete the message from Sent.

sending.

Archive to Copy the selected message to SIM sIM archive.

Move to my favourites Move the selected message to My favourites.

Details View information of the message such as date and time

Select You can select several messages one multiple by one or all at once. You can press

by one or all at once. You can press ⊚ to select/cancel the operations on multiple messages. Checkboxes will be marked on the left of the selected message. Press ⊙Options to delete the selected messages, or you can move them to My favourites.

5. Press ⊗ to enter the next screen whereby the message details will be displayed. Press ⊗Resend to resend the selected mesage, or press ○Options to carry out the following operations:

Forward When you select Forward, the contents of the selected message will appear on the message editor. You may edit the message before sending.

Delete Delete the message from the Outbox.

Archive to SIM archive.

Move to my favourites favourites.

Move the selected message to My favourites.

Details View information of the message such as date and time.

Outhox

The *Outbox* allows you to save the messages you have not sent successfully.

- I. In idle mode, press $\ensuremath{ ilde{\Theta}}$ to enter the main menu.
- 2. Select Messages > Outbox and press ⊚.
- 3. If there are messages in the *Outbox*, they will be listed on the screen.

4. Press */* to select a message. When a message is selected, its contents will be displayed on the screen. Press @View to view the selected message, or press @Options to carry out the following operations:

Resend Resend the selected message.

When you select Forward, the contents of the selected message will appear on the message editor. You may edit the message before sending.

Delete Delete the message from Sent.

Move to my Move the selected message to My favourites favourites.

Details View information of the message such as date and time

Select
Multiple

You can select several messages one by one or all at once. You can press
to select/cancel the operations on multiple messages. Checkboxes will be marked on the left of the selected message. Press Options to delete the selected messages, or you can move them to My favourites.

 Press ⊗ to enter the next screen whereby the message details will be displayed. Press ⊗Forward to edit the selected message or press ⊙Options to carry out the following operations.

Resend the selected message.

Delete the message from the Outbox.

Move to my
favourites

Move the selected message to My
favourites.

Details View information of the message

such as date and time.

Drafts

List the messages that were created and saved but were not sent, and messages that were saved before you were able to save or send them when you exit from the message editor.

Select a message from the *Drafts* box and press @View, or press ©Options to: Send, Edit, Delete, view Details or Select multiple. If you press @View, the subsequent procedures would be similar to the Inbox operations.

My favourites

This menu contains all the messages received and saved in the phone memory via *Move to my favourites* option.

- 1. In idle mode, press @ to enter the main menu.
- 2. Select Messages > My favourites and press ⊚
- 3. If there are messages in *My favourites*, they will be listed on the screen.
- Press _{*}/_{*} to select a message. When a message is selected, its content will be displayed on the screen. Press ⊕View to view the selected messages or press ⊕Options to carry out the following operations:

Details View information of the message such as date, time and sender.

Reply

The sender's number will be used as the destination number automatically and the message editor will be activated. Enter your reply and send the message.

Forward When you select Forward, the contents of the selected message will appear in the message editor. You may edit the message before sending.

Delete	Delete the message from My Favourites.	Forward	When you select <i>Forward</i> , the contents of the selected message will
Restore location	Move the message to the original location where the message is sent or		appear in the message editor. You may edit the message before sending.
	received.	Delete	Delete the message from My
Dial	Extract the sender's number from		Favourites.
	the message and dial the number.	Restore	Move the message to the original
Select multiple	You can select several messages one by one or all at once. You can press	location	location where the message is sent or received.
	⊕ to select/cancel the operations on multiple messages. Checkboxes will be marked on the left of the selected message. Press □ Options to delete	Dial	Extract the sender's number from the message and dial the number.
		Spam bo	×

the selected messages. 5. Press @ to enter the next screen whereby the

details will be displayed. Press -Options to carry out the following operations:

View information of the message Details such as date, time and sender.

The sender's number will be used as Reply the destination number automatically and the message editor will be activated. Enter your reply and send the message.

This menu allows you to filter messages after the firewall has been set. When the firewall is activated. any message from a person on your blacklist will go to the spam SMS box automatically.

SIM archive

In the menu, you can see the read and unread messages saved in the SIM Card. Press @View to

view the selected messages or press Options to carry out the following operations:

Options	Description		
Reply	Reply the message.		
Forward	Forward the message to other recipients.		
Delete	Delete the message.		
Add to blacklist	When you add the contact to the blacklist, you will not receive call/message from this contact anymore.		
Move to my favourites	Move the selected message to My favourites.		
Details	View information of the message, such as date, time and sender, etc.		
Dial	Call the sender of the message.		
Select multiple	You can press ⊕ to select/cancel the operations on multiple messages. Checkboxes will be marked on the left of the selected message. You can delete the selected messages.		

Templates

This menu allows you to select a message saved as a SMS or MMS template. You can create, send, modify and delete your preset messages.

Email

Your phone can send and receive e-mail messages, provided this service is included in your subscription. You must already have an e-mail account and have received the settings from your e-mail service provider. In some cases, your mobile phone service provider may also provide an e-mail service.

Create e-mail

To write an e-mail, select *Email* > *Create*. Enter the address (*To*), a copy (*Cc*), or blind copy (*Bcc*), *Subject* and the e-mail *Content*. When you have finished writing your e-mail, press — to access the following:

Save the message in the draft box

without sending it.

Send Send the e-mail.

Inbox

This menu allows you to connect to your mailbox and download the e-mail headers. Press
to Receive the e-mails. You may then select an e-mail header and press to access the following options: View, Delete, Reply, Reply all, Forward, Delete all, Receive.

Drafts

The menu lists all the e-mails you have saved but not sent. Press \bigcirc to: *Edit, View, Delete, Delete all.*

Outbox

The menu lists all the e-mails you have sent. Press

to: Edit, View, Delete, Delete all.

Check mail

The menu allows you to connect to your mailbox and to download the e-mails. This might bring up a message requesting airtime. Select Yes to continue and receive new e-mails.

Settings

This menu allows you to edit e-mail's Account Settings or Activate one of the available profiles by pressing . Use 1/2 key to access the menu list, press or numeric keypad to edit the content. In the editing screen, press to return, press to

Save and \odot to Clear. You may edit the following details:

Menu Description

Profile name To name the profile.

E-mail address To enter an e-mail address.

User ID To enter a login name.

Password To enter the password.

Number of To define the number of mails mails received at a time.

mails received at a time

Incoming To set the POP information used

server to receive e-mails.

Outgoing To set the SMTP information used

server to send e-mails.

SMTP To turn on/off the authentication.

Type To select POP3 or IMAP.

Exit

You will be exited from the e-mail menu.

Advanced

Cell Info

This is a network service which allows you to receive text messages of various contents, such as news, traffic, etc. These messages are provided by the network to the subscribers within a certain network area. If this service is available, the network will provide you with the broadcast channel numbers. It gives you access to the options listed below.

Options	Description
Reception	Select to turn on/off the reception of new cell broadcast messages.
Topics	Add, change or delete channels. <add new="">: Press @Add to add a new channel. Change: Edit a channel number. Delete: Delete a channel in the channel list.</add>

Memory status

This feature allows you to see how much memory space remains for messages in your phone and SIM card.

SMS timer

You may set a specific time to send an edited text message to a particular contact.

This menu allows you to select Add to send text messages at specific times and display such messages in a list on the screen.

Select Add to enter into the SMS editing screen. Press \odot to open the contacts list and select a contact, or enter the phone number directly and set message sending options. You can set the date and time to send the message.

When you select a message from the list of text messages configured for sending at specific times, you can press @View to view the details of the message or press @Options to carry out the following operations:

Delete	Delete the message.
Delete all	Delete all messages.

When you enter a message detail screen, you can press \bigcirc Send to send the message to the recipient

directly or press \bigcirc *Option* to carry out the following operations:

Edit You can edit the contents, contact

or date.

Delete the message.

Voice mail

This menu allows you to set your voice mailbox number and listen to voice messages your correspondents have left for you.

You can forward your calls to your voice mailbox (the phone number for callers to leave a message) via the Call forwarding feature.

Call voice mail

When you receive a voice mail, the phone will send you an alert. You can then call your voice mailbox number to retrieve your voice mail.

In idle mode, long press to call your voice mailbox directly. If the number is empty, you will be prompted to enter the number.

Voice mail number

Generally, you can obtain two sets of numbers from your network provider:

 number for the caller to leave a message (this number can also used for call forwarding) number for you to retrieve your voice messages

Settings

SMS

Select Messages > Settings > SMS to open the list of SMS accounts. Press © Reset to edit the SMS settings:

Service center number

This menu allows you to save and edit the SMS service center number of your home network. If the service center number is empty, you will not be able to send any SMS.

Validity period

Allows you to select the duration by which your messages will be stored in the service center. You can select from: I hour, 12 hours, I day, I week and Maximum (default). Press 4/+ to select a value.

This option is useful when your recipient is not connected to the network and is not able to receive your messages immediately.

This feature is subscription dependent.

Delivery report

You can select \odot to set this option *On* or *Off.* This option allows you to set whether or not to notify

you the send status of your messages: successfully sent to the recipient, or not sent successfully.

This feature is subscription dependent.

Signature

You can select \odot to set this option On or Off (Default is Off). If set to On, it opens an editor where you can enter your signature. The signature will be added to the end of your message before it is sent to your recipient.

If the SMS is too long after adding the signature, the signature will be ignored.

Storage location

You can press @Change to change the preferred storage location of your messages: SIM card (Default) or Mobile phone.

Send and Save

You can select \odot to set this option On or Off. This option allows you to set whether or not to save the sent messages.

MMS

This menu allows you to set your MMS center and personalize your MMS settings. The options include:

Profiles

You can select or edit the parameters.

Sender visibility

You can press @Change to set this option On or off. It is used to set if your identity will be visible when MMS is sent.

Priority

This option allows you to set the priority level of your MMS. You can set Low, Normal (default) or High.

Delivery report

You can press \bigcirc Change to set this option On or off. When it is set to On, a report will be sent to notify you if the MMS has been delivered to the recipient.

Read report

You can press \bigcirc Change to set this option On or off. When it is set to On, a report will be sent to notify you if the MMS has been read by the recipient.

Expiry time

Allows you to select the duration by which your MMS will be stored in the MMS center. You can choose from 6 hours, 12 hours, 1 day, 1 week or Maximum (default).

Retrieval

Allows you to select *Automatic*, *Deferred*, *Auto in home network* when downloading MMS messages.

9. My Favorites



This menu allows you to store the files in different folders (*Pictures, Sounds, Videos, Others*) to facilitate more efficient management of files in your phone and the memory card. In addition, you can obtain information regarding your phone and memory card, such as the availability of free memory, memory utilized and total memory size via the *Memory status* option.

Pictures

When you enter this menu, the photos which you have taken using the phone's camera as well as pictures you have downloaded via MMS, WAP, BT, or USB will be displayed in a list.

- Select My Favorites > Pictures and press
 ⊕ to enter the menu.
- Press @View/Open to view the selected picture/ open the selected folder or press
 ☐ Options to

carry out the following operations to a selected file:

Options	Description
Send	Send the selected file: <i>Via bluetooth</i> or <i>Via MMS</i> .
Advanced	Cut: Similar to copy, but the original file will be deleted. Copy: Copy the selected file to another folder.
Rename	Modify the name of the selected file.
Details	Display detailed information of the selected photo, such as last modification time, file size, etc.
Use	As contact ID: If you select this option, the phonebook list will be displayed. After you have selected a contact from the phonebook, press Select to associate the picture to the selected contact.
	Only available for picture of

176*220 or smaller.

As wallpaper: If the selected photo is 176*220 or smaller, it will be displayed as wallpaper in its original size.

Delete

Delete the selected picture.

Slide show

If you select this option, the screen will display the full screen view of all the pictures in the form of slideshow every 4 seconds. Press any key to exit from the slide show mode.

Change view

You can select to view the pictures in List view. Grid view or Full screen.

Sort

Sort the pictures and folders by name or date.

Select multible Select one by one: select the picture one by one and then Cut, Copy or Delete them.

Select all: select all the pictures and then Cut, Copy or Delete them.

3. The folder options include:

Rename Modify the name of the selected

folder

Details Display detailed information of the

selected folder.

Delete Delete the selected folder.

Change view Select List view or Grid view.

Sort the pictures and folders by Sort

name or date.

Sounds

When you enter this menu, the sounds which you have stored or downloaded via MMS. WAP, BT, or USB will be displayed in a list.

- 1. Select My Favorites > Sounds and press ⊚ to enter the menu.
- 2. Press @Play/Open to play the selected audio file/ open the selected folder or press -Options to carry out the following operations to a selected file:

Send	The available options are: Via bluetooth and Via MMS.
Advanced	Cut: Similar to copy, but the original file will be deleted. Copy: Copy the selected file to another folder
Use	You can set the audio file: as ringtone or as contact ID.
Rename	Modify the name of the selected file.
Details	Display detailed information of the selected audio file, such as last modification time, file size, etc.
Delete	Delete the selected audio file.
Change view	Select List view or Grid view.
Sort	Sort the audios and folders by name or date.
Select multiple	Select one by one: select the audio files one by one and then Cut, Copy or Delete them. Select all: select all the audio files and then Cut, Copy or Delete them.

3. The folder options and their operations are the same as *Pictures* menu.

Videos

When you enter this menu, the videos which you have recorded using the phone's camera as well as videos you have downloaded via MMS, WAP, BT, or USB will be displayed as a list.

- Select My Favorites > Videos and press
 ⊕ to enter the menu.
- Press @Play/Open to play the selected video/ open the selected folder or press _Options to carry out the following operations to a selected file:

Options	Description
Send	Send the selected file: <i>Via bluetooth</i> or <i>Via MMS</i> .
Advanced	Cut: Similar to copy, but the original file will be deleted. Copy: Copy the selected file to another folder.
Rename	Modify the name of the selected file.

Details	Display the detailed information of the selected video, such as last modification time, file size, etc.
Delete	Delete the selected video.
Change view	You can select to view the video files in <i>List view</i> or <i>Grid view</i> .
Sort	Sort the videos and folders by name, date, or size.
Select multiple	Select one by one: select the videos one by one and then Cut, Copy or Delete them. Select all: select all the videos and then Cut, Copy or Delete them.

The folder options and their operations are the same as *Pictures* menu.

Videos are played in the middle of the screen. A status bar is displayed at the top of the screen. The keypad operations when playing videos are as follows:

Key	Operation
(ox)	Start/pause the playback.
•	Long press to rewind.

- Long press to fast forward.
- Exit/return to an upper menu level.
- Return to idle screen.

Others

You can save all other files into this folder. The file and folder options and their operations are the same as the *Pictures* menu.

Memory status

All memory capacity, used memory capacity and free memory capacity between all memory capacity used in both the mobile phone and memory card will be displayed.

Settings

The phone has a micro SD memory card slot to increase the phone's memory. The phone supports FAT16 and FAT32 format for IGB capacity, and supports FAT32 format for 2GB capacity. You can select *Uninstall* to safely remove memory card from the phone, and select *Format* to format it.

For 2GB capacity, in order to ensure the card can be recognized by the phone, please connect the card to a computer and format it to FAT32 before using it for the first time with X520.

10. Business



Calendar

This menu displays the calendar. You can select Day view, Week view or Month view. You can create new appointments, view appointments list, delete or modify appointments in the calendar. The calendar stores the alarm date and time of every event. If the current date and time correspond with the date and time of the event, the phone will emit an alarm (if needed), and the screen will display a prompt to indicate that a new event has arrived.

You can create a maximum of 30 events. The list will display part of the contents. Once you have selected an event, you can press

to view the detailed information.

- Enter the menu. Press ⊕ to access View or press ⊕ to access the options menu.
- 2. The options include: View week, New event, Go to date, Advanced.

New event

The list of events will be displayed. When you add a new event, you need to enter the corresponding

information of the event, such as subject, location, start date, start time, end date, end time, reminder and repeat method.

If the memory space for events is full, the phone will prompt you that there is no more space.

When you edit date and time, the phone will display the default or the selected date and time. You can edit or confirm them directly.

The maximum length of an event is 100 characters.

Reminder

On time, 5 min. before, 15 min. before, 1 hour before and 1 day before.

Repeat method

The phone provides the following repeat methods: Once, Daily, Weekly, Monthly and Annually.

When you change the date and time of your phone, the next alert will be repeated based on the modified date and time of the phone.

When you switched off the phone, the organizer alert will be postponed until the next time you

switch on the phone. For repeated events, only the latest one will be alerted.

Alarm

This phone supports 24-hour alarm.

The available options are:

escription

Simple alarm

A simple alarm rings only once. Set the alarm status to *On* or *Off* by pressing @*Change*. When it is set to *On*, you need to specify the alarm time and press @ to confirm.

Reccurent alarm

A recurrent alarm rings according to the day you specify in a week. Set the alarm status to *On* or *Off* by pressing ©*Change*. When it is set to *On*, you need to specify the *Time* and *Repetition*. For example, if you select Sunday and Monday, the alarm clock will ring every Sunday and Monday. Then press © to confirm.

Alarm tone

Select an alarm tone.

Snooze Select On or Off.

Calculator

Your mobile phone has a built-in calculator. Enter the numbers with the keypad.

Options	Description
•	Addition
•	Subtraction
•	Multiplication
•	Division
(ax)	Equals
*.4	To toggle between negative and positive figures.
⊙Options > %	Add a percentage symbol.
OptionsModular	Calculate a remainder of a division.
#aB	Add a decimal point.
The maximus	m length of the numbers and the

The maximum length of the numbers and the result is 9 digits. The result of the calculator is indicative.

Business 51

Voice recorder

This menu allows you to record a voice memo. From the main menu, select Business > Voice recorder. Then you can press \bigcirc to set the MMS size and select the Storage location. When you set the MMS size On, the recording will stop if it exceeds the MMS size limit.

To start recording, press *⊗*Record. During the process, the recorded time will be displayed in real time. To stop recording, press *⊗* and the file will be saved in *My Favorites* > Sounds. Then you could press *⊗* to play the recorded file or press *⊙*Options to access the following options:

Options	Description
New episode	Make another recording.
Delete	Delete the selected file.
Send	Send the selected file.
Rename	Change the name of the selected file.

Secretary OTG

This menu allows you to make long recordings. From the main menu, select Business > Secretary OTG.

To start recording, press
New. During the process, the recorded time will be displayed in real time. To stop recording, press and the file will be saved. Then you can edit the start date, start time, and reminders for this recording. Other available options are:

Options	Description
Delete	Delete the selected file.
Send	Send the selected file.
Rename	Change the name of the selected file.
Edit	Edit the start date, start time and reminders of the selected file.
Details	View the detailed information of the selected file.

Stopwatch

Your phone features a stop watch and the minimum unit is 0.1 second.

The starting time is 00:00.0, in the format "mm:ss.n", where mm stands for minutes of the watch, which can be any number from 0 to 59; ss stands for seconds, a number between 0 and 59; n stands for 0.x second, x being any number from 0 to 9. The stopwatch will start the timing when you press @Start. You can pause the timing, press @Pause, to resume, press @Go, to stop the timing, press ©Stop.

Countdown

This feature is very similar to the alarm clock, except that you will be alerted of the remaining time, and the phone will emit an alarm at the end of the count-down. The alarm tone is the same as your alarm clock.

The minimum time is I minute. The format of the time is *hh:mm:ss*, and the maximum time input is 23 hours 59 minutes 59 seconds.

You can edit the time timer and start the countdown by pressing $\bigcirc Go$. To stop countdown, press $\bigcirc Pause$, to reset, press $\bigcirc Reset$. You can exit the menu by pressing the $\bigcirc Back$.

The count-down timer will switch on automatically and emit an alarm at the end of

the count-down even if your phone is in idle mode.

Unit converter

This application allows you to convert many types of units such as time, exchange rate, area, energy, mass, power, pressure, temperature and volume. Select the type of unit and input the figure and then press Θ *Change* to calculate the result.

Press (840) key to enter the decimal point.

Firewall

This function provides a simple and quick method for you to avoid nuisance calls and SMS. Blacklist contains a list of phone numbers from which you do not wish to receive calls or SMS.

Select *Business* > *Firewall* > *Set* and choose between the following options:

- Status: Status icon, Event or None.
- Activate: On or Off.

To add the phone numbers into the black list, select *Black list*, select *Add new*, then you can carry out the following operations:

Business 53

Option	Operation	task and press options:	⊚Select to access the following
New number	Open the phone number editor, enter the new number and save the number into the black list.	Туре	Allow you to create a <i>Phone Call</i> or <i>Task</i> .
Contacts	Open the phonebook list and select	Subject	Create a subject for your task.
	a phone number for saving into the black list.	Call number (Available	Enter the phone number directly, or press @Select for:
the black list, following ope		only in Phone call)	Contacts: Display the list of contacts for calling. Enter number: Enter the number.
Change	Open the phone number editor, to edit the selected number in the black list.	Display on idle	Set On or Off to choose whether the event will display on screen in
Delete	Delete the selected number in the		idle mode.
Task	black list.	Set Reminder	Set On or Off to choose whether you want to receive the alert. When it is set to On, you need to
This manu all	ows you to create store and manage		set the alert date and time. Press 🐵

This menu allows you to create, store and manage events in your task list.

Create task

This menu allows you to create a new task. There are 2 types of tasks: Phone Call and Task. Select New After you have finished editing, press @ to save your new task.

to confirm.

54 Business

Manage task

This menu allows you to manage your tasks . Select a task, then press \odot to *View* the task or *Call* the contact (depending on if it is the *Task* or *Phone Call*) or press \bigcirc *Option* to access the following options:

Mark as (not) Mark a tick on the task as done or

done untick for not done.

Edit the selected task.

Delete the selected task.

Delete all tasks on the list.

11. Contacts



Your phone features two phonebooks. The SIM phonebook is located on your SIM card and the number of entries you can store depends on the SIM card. The second phonebook (Smart phonebook) is integrated in the phone memory and the maximum number of name cards you can store is 2000 (a namecard can consist of a name, 4 phone numbers, groups, email address, address, etc.). The SIM card is the default phonebook, but the entries in the two phonebooks are combined, sorted and displayed as a list. When you add a new contact to your phonebook, the new contact will only be added to the phonebook you have selected.

You can store up to 2000 name cards, provided other features in the phone such as Calendar, Sounds, Pictures, and Videos, etc. did not use up a large amount of the phone's memory space.

New contact

To create a new SIM/phone contact:

Enter new contact

Press @ and select New Contact.

Enter contact details

Enter the following for SIM card contacts:

- Name
- Number

Enter the following for onboard phonebook contacts:

- Name
- General
- Mobile
- Home
- · Work and etc

Store the new contact

Press ⊗ Save.

To create a contact, you must enter at least a phone number.

Most of the fields are free-text, which means you can enter alphanumeric data using the text entry functions of your mobile phone (for more

56 Contacts

information on text entry, see "Text entry" on page 18).

View contacts

In the phonebook, you can display the details of a contact by selecting it. Then press $\bigcirc View$ to view the details of the selected contact or press $\bigcirc Options$ to carry out the following operations:

Options	Description
New contact	Create a new contact.
Send message	Send an SMS or MMS to the contact.
Call	Call the contact.
Edit before call	Change the contact's information before calling the contact.
Call nandsfree	Call the contact by handsfree mode.
Delete	Delete the contact.
Add to blacklist	Add the contact into the blacklist.

Contact	via MMS or via Bluetooth.
Copy to phone/SIM	Copy the SIM/phone entry to phone/SIM.
Move to phone/SIM	Similar to copy, but the source record will be deleted after copying.
Select	Select one contact at a time or

select all contacts.

Sand the colocted records via SMS

View groups

The View groups feature allows you to organize your contacts so that you can send messages to all the members of the group. From the Contacts menu, select View groups and the list of groups is displayed.

View

multiple

Select a group and Θ *View* to display the group members or press Θ *Options* to access the following group options:

Options	Description
Rename	Rename the group.

Contacts 57

Send message Send an SMS or MMS to

members of a group.

Reset Restore the group to default

settings.

Special numbers

This menu allows you to keep a list of useful numbers such as your own numbers, service numbers, voicemail and SOS numbers.

Options Description

My number View, edit or clear your own

phone number.

Emergency Display the emergency phone

number.

Voice mail Dial the number for your

voice mail service provider.

Service numbers This entry of the SIM phonebook allows you to select one of the available

services provided by your operator and to copy it into the selected phonebook.

Advanced

This menu provides you with advanced features so that you can view and edit your contacts:

Options Description

Choose contact list Default list: Switch contact

list between SIM, Phone or

All.

Default location: Select the location to store new contact entry: Phone or SIM

card.

Copy contact Copy to SIM: Copy all entries

to SIM.

Copy to phone: Copy all

entries to Phone.

Move contact Move to SIM: Move all

entries to SIM.

Move to phone: Move all

entries to Phone.

Delete all contacts Delete SIM entries: Delete all entries saved in SIM card

Delete phone entries: Delete all entries saved in Phone.

58 Contacts

12. Profiles



Your mobile phone has been preconfigured with the following modes:

- Personal (default) Car
- Flight
- Home Meetings
- etings Outdoor

Silent

You can activate and modify all the modes, except the Flight mode and Silent mode. These 2 modes can only be activated and viewed.

The profiles and their respective parameters are as follows:

Personal	Ring volume	Level 6
	Ringtones	Default
	Alert type	Vibrate and ring
	Key sound	On
	Backlight level	Level 3

Car	Ring volume	Level 8
	Ringtones	Default
	Alert type	Vibrate and ring
	Key sound	On
	Backlight level	Level 4
Flight	Ring volume	No volume
	Alert type	None
	Key sound	Off
	Backlight level	Level 3
Home	Ring volume	Level 4
	Ringtones	Default
	Alert type	Vibrate and ring
	Key sound	On
	Backlight level	Level 3

Profiles 59

Meetings	Ring volume	Silence
	Ringtones	Default
	Alert type	Vibrate
	Key sound	Off
	Backlight level	Level 2
Outdoor	Ring volume	Level 9
	Ringtones	Default
	Alert type	Vibrate and ring
	Key sound	On
	Backlight level	Level 4
Silent	Ring volume	No volume
	Alert type	None
	Key sound	Off
	Backlight level	Level 2

Profile selection

To select a different profile:

Go to Profiles Press ⊚ to enter the main menu from the idle mode and select

Profiles.

Select the Press • or •, and press @ Select profile to activate the selected profile.

Modify the Press Modify. You can modify profile the settings of the profile.

Modify settings

Key sound

The available options include:

Options Description

Ring volume Select from 9 volume levels.

Select the ringtone for Call

Select the ringtone for Calls, Alarm, Calendar, Messages or Cell

info.

Alert type Select an alert type: Ring only,

Vibrate only, Vibrate and ring, Vibrate then ring or Silent.

Set the key sound On or Off.

Backlight level Select a backlight level from

level I to level 4.

60 Profiles

13. Connectivity



This menu provides you with more features to set up a connection with these external devices.

Bluetooth

Your phone supports Bluetooth wireless technology, allowing connection to a compatible Bluetooth device. To ensure interoperability between other Bluetooth devices, please check with the manufacturers of other devices. The Bluetooth connection can be subjected to interference from obstructions such as walls or other electronic devices.

To use Bluetooth connection, the device with which you want to establish a connection must support Bluetooth function. Please contact the device's manufacturer or its accompanied documentation.

Establish a Bluetooth connection

To activate, press ⊕ to enter the main menu from the idle mode and then select *Connectivity* > *Bluetooth*. On the Bluetooth screen, select *Activate*. Next, select *Search for devices*. When the list of

devices appears, select the device you wish to establish a connection with.

If you do not intend to use the Bluetooth feature for some time, you should deactivate it in order to conserve battery power.

Bluetooth menu

Options	Description
Activate	Turn Bluetooth feature on or off.
Search for devices	Search for the external devices that you can connect to.
My devices	Display the bluetooth devices that you can connect to.
Settings	Select to display more features: • My name: edit the name of the device • Visibility: choose to show or hide the device by selecting On or Off • My profiles: lists the phone's available profiles

When searching for a device, you are presented with a list of any devices discovered within the range of your Bluetooth-enabled phone. As soon as you select a device and a connection is made, you

Connectivity 61

are prompted to enter a passkey in order to pair with the device. This passkey is supplied by the manufacturer of the other Bluetooth device. Refer to its documentation for further information. The passkey feature ensures that only legitimate connections are allowed to connect either to your device or to the selected device.

USB Function

Connect your phone to a PC via USB cable, and your phone will then behave like a USB drive. With your phone, you can access files on your memory card. You can upload and download music, videos and pictures via the USB cable, and the size of file transfer is unlimited until your memory is full.

When copying files from your PC to phone, first insert a Micro-SD memory card into your phone.

When the transfer is finished, please make sure that you safely remove your device based on the instruction of your computer.

Using PhilipsPhoneTools

Besides, your phone can perform PC connections with the supplied PhilipsPhoneTools. PhilipsPhoneTools offers instant sychronization between your phone and your computer, and enables you to backup your mobile phone data and recover the data saved in the computer, receive SMS and edit your mobile phone contacts

Installing PhilipsPhoneTools on your PC

- Insert the supplied PhilipsPhoneTools into the CD drive.
- 2. Run the Setup.exe program.
- Make selections as prompted, and installation starts automatically.

During the installation, interruption may occur when your PC system detects the new software. Press Continue Anyway repeatedly until the installation resumes.

Connecting your Phone to the PC

- Check that the Phone Setup wizard starts. If necessary, double click the PhilipsPhoneTools icon
- 2. Connect your phone to the PC as prompted.

62 Connectivity

On your phone, select Connectivity > USB function > PC Sync from the main menu.
 A functional menu appears on your PC screen.

Connectivity 63

14. Calls



Most options described in this chapter are operator and/or subscription dependent and require either a PIN2 code or a phone code. For more information on PIN codes, see "Transfer backupower" on page 68.

View calls

This menu provides you with a list of calls you have missed, answered and made. The calls include All calls, Missed calls, Answered call, Outgoing calls and Rejected calls, which are displayed in chronological order with the most recent call at the top of the list. Select a call from one of the lists and press Dial to call or pr

Options	Description
View	View the detailed information of the selected call.
Save	Save the number if the number is not in the contacts list.

Save to existing	Save the number in the current the contacts list.
Send messages	Send a message to the selected number. You can send by SMS or MMS.
Delete	Delete the selected number from the list.
Delete all	Delete all numbers from the list.
Dial	Call the selected number.
Add to blacklist	To add the phone number into the blacklist, see "Firewall" on page 53.
Edit number	Open the contacts list and edit the number if it is in the contacts list.

Call options

before

dialing

This menu allows you to configure the call settings:

Options Description

64 Calls

Auto Turn Auto answer on/off. When this function is on, the incoming call will be answered automatically in 10 seconds.

Any key answer on/off. When this function is on, you can answer incoming calls by pressing any key,

except $oldsymbol{\boxdot}$ and $oldsymbol{\boxdot}$.

Minute reminder

Select On or Off to activate or deactivate the minute reminder during a call. The default is Off and the default setting is 45 seconds.

Call services

The available options include:

- Call time: Display the duration of your calls and their charges: Total incoming calls, Total outgoing calls and Total calls.
- Call waiting: Select Enable or Cancel, or check Status.

This feature is network/ subscription dependent.

- Own ID: Select Show ID or Hide ID or Set by network to display or not your phone number or identity to the called party.
- Caller ID: To check your operator setting of showing the identity of your caller.

This feature is network/ subscription dependent.

Calls

 Cost settings: This option is available only when the charge information is included in your SIM card. You can view information of the current call and all recent calls. You need to enter the PIN2 code to manage maximum cost credit and unit rate. Call forward Set the following call divert options: All calls, If no reply, If out of reach, If busy.

- When All calls is on, all incoming calls will be diverted to the pre-set number without any reminder.
- When If no reply is on, incoming calls will be diverted if the user does not answer.
- When If out of reach is on, incoming calls will be diverted to the pre-set number when the user is not connected to the network.
- When If busy is on, calls will be diverted if the user is already online or the call is rejected.
- You can also check the Status of your call diverts or Cancel all call diverts.

66 Calls

Call barring

This menu allows you to limit the use of your phone to specific calls by preventing the reception or making of different types of calls. To activate call barring, you need to enter a communication limit code. This PIN2 code will then be sent to the network for validation.

Note that this operation only supports GSM calls.

The types of calls you can bar are as follows:

- · All outgoing calls
- · All international calls
- · Only here & home
- All incoming calls
- · Incoming if abroad

You can also check the *Barring status* of your call barring or *Cancel barring*.

Restricted dialing

This menu allows you to set the password to prevent the phone from being used by another person.

IP number

Dial IP prefix of your network operator.

Clear history

This menu allows you to clear the call history in:

Delete all/Missed calls/Answered calls/Outgoing calls/
Rejected calls. Press ⊚Select to confirm deletion and

⊚Back to cancel deletion.

15. Settings



You can configure your Xenium X520 mobile phone to best suit your usage preference. You can configure the following settings: *Transfer backupower*, *General*, *Display*, *Sounds* and *Connectivity*.

Enter the menu

Press (e) to enter the main menu from idle mode and select Settings.

Select a settings

Press • or •.

Transfer backupower

By taking the advantage of the backupower TM technology, this menu allows you to transfer power from an AAA battery to the main battery in your phone. see "Using the backupower TM" on page 9

General

This menu allows you to configure some general settings:

Options

Description

Languages

Set the display language of the phone.

Time &

- Display time: Select On or Off.
 When you select On, the time information will be displayed in the idle screen.
- Set time: Set the time in the format HH:MM.
- Set date: Set the date.
- Time format: Set the time format as 24 hours or 12 hours.
- Date format: Set the date format as YYYY/MM/DD, YYYY.MM.DD, DD.MM.YYYY, YYYY-MM-DD or DD-MM-YYYY.

- International clock: Go to the international clock menu and change the time zone.
- Power-on time: Set a time for the phone to be switched on. You can select On or Off. When you select On, you need to enter the time you want your phone to be switched on.
- Power-off time: same as above.

Security

PIN protection: Select On or Off.
 When you select On, you need to enter the PIN code when you switch on the phone.

The default PIN code is network dependent on your service provider. Please contact your service operator for the PIN information.

- Change PIN/PIN2: You can modify the password for PIN, PIN2, safeguard and phonelock.
- Safeguard: You can safeguard important information such as messages, contacts on your phone by activating safeguard. You can also change the safeguard password.
- Change safeguard password: You can modify the password for PIN, PIN2, safeguard and phonelock.

The default safeguard password is 1234.

Auto Select to activate this feature after 60 seconds, 30 seconds or 15 seconds. keybad lock or select Off. Shortcuts Displays a list of shortcut features. You can set a new shortcut key by establishing a link between a certain feature and a navigation key. You can also change or delete an existing shortcut key. Speed dial Call a contact by long pressing a numeric key (see "Speed dial" on page 13). Default Set the default storage location: Phone memory or Memory card for storage different applications. Memory You can check the memory status of Contacts, Messages and My Favorites. status You can also check the memory status of Memory card if it is inserted. Mainmenu Select the browse style as List or style Grid. Restore your phone settings to the **Factory**

default values.

settings

Display

You may configure your phone with different display settings:

Options Description

Wallpaper Turn the wallpaper display On or

Off.

Themes Select from 2 themes

Backlight level Select from 4 backlight levels. You can select the backlight level by

pressing • or • keys. Press

to

confirm.

Backlight Select

Select the backlight duration from 60 seconds, 30 seconds and 15

seconds.

Greeting

Turn greetings *On* or *Off.* When you select *On*, you can edit the greeting

message.

The maximum length of greetings is 20 Chinese words or 40 English characters.

Sounds

You can set your phone to operate with different sound profiles.

Options Description

Alert type You can select Ring only, Vibrate only,

Vibrate & ring, Vibrate then ring or Silent.

Ringtones Select the ringtone for Calls, Alarm,

Calendar, Messages and Cell info.

Ring volume

Key sound

Select from 9 volume levels.

Turn the key sound On or Off.

Shutter Select from 3 shutter sounds. You sound can also select Off.

Lowbattery Turn the warning On or Off.

alert

If you have downloaded your own ring tones and have selected such a ring tone to be the alarm alert, then after you set the alarm and switched off the phone, the alert tone will be changed back to the original factory settings. This does not apply if the ring tone you have

chosen is one that comes as default with your phone.

Connectivity

Call options

For more information, see "Call options" on page 64.

Message settings

For more information, see "Settings" on page 42.

Network settings

The network name will be displayed on the idle screen. If the phone is not able to identify the network name, it will display the country code and the network code of the unknown network.

Select network

It will vary according to the search mode you have selected. If you select *Auto*, the network will be searched automatically. If you select *Manual*, the search will commence only when you confirm to start searching.

Search mode

You can select Auto or Manual.

Preferred networks

Preferred network list is stored in the SIM card. It specifies the priority by which your phone will register to the available network during automatic registration.

- 1. In idle mode, press @ to enter the main menu.
- Select Settings > Connectivity > Network settings > Preferred networks
- 4. Press */* to select a certain network.
- You can then press ⊕ to Insert or press
 —Option and select to Add to end or Delete the
 selected network.

Browser

Various parameters relative to browser can be set under this option, including WAP profiles and Push messages.

Connections

GPRS profiles

This menu allows you to configure a GPRS (General Packet Radio Service) connection to the network. The available GPRS settings are:

Options Description

Profile name To name the current profile APN To enter GPRS APN.

Login To enter a login name.

Password To enter the password.

GPRS info

This feature allows you to monitor the amount of data transferred during GPRS connection.

72 Settings

Icons & Symbols

In idle mode, several icons and symbols can be displayed on the main screen. The status, network and battery icons are displayed all the time. The rest of the icons are displayed if the feature is available, and not displayed if the feature is unavailable.

If the network symbol is not displayed, it implies that the network is currently unavailable. You may be in a bad reception area; moving to a different location may help.



Network - Network icon comprises of 2 portions. The left portion indicates whether or not your phone is already registered with a network, and the right portion indicates signal strength in 5 levels (from no signal to strongest).



Battery - Indicates battery level with 5 battery level indicator bars. During charging, a scrolling icon will be displayed.



International roaming - Displayed when your phone is registered to a network other than your own.



Whether to log on GPRS - There are 2 GPRS status which are mutually exclusive: GPRS network is available but not in use; or GPRS network is available and in use. The icon will be displayed only when you have logged on to GPRS.



MMS - Indicates there is a MMS message.



WAP Push message - Indicates there is a WAP push message. Go to Browser > Push Indicates there is a way in the push Indicates there is a way in the push Indicates th



Voicemail- Indicates voice messages that have not been heard



Alarm Clock - Indicates that the alarm clock is activated



Vibration - Your phone will vibrate when there is an incoming call or when the alarm clock rings.



Firewall - Indicates that firewall feature is activated

Icons & Symbols 7.

Missed call - Indicates there is a missed call. Call forward - Indicates that the call forward function is activated. Silence - Indicates that silent mode is activated. Auto answer - Indicates that Auto answer is on. Keypad Locked - Indicates that the keypad is locked. Memory card - Indicates the memory card is in use. Bluetooth - Feature is activated.

Precautions

Radio Waves

Your cellular mobile phone is a low power radio transmitter and receiver. When it is operating, it sends and receives radio waves. The radio waves carry your voice or data signal to a base station that is connected to the telephone network. The network controls the power at which the phone transmits.

- Your phone transmits/receives radio waves in the GSM frequency (850/900 / 1800 / 1900 MHz).
- The GSM network controls transmission power (0.01 to 2 watts).
- Your phone complies with all relevant safety standards.
- The CE mark on your phone shows compliancy with European electromagnetic compatibility (Ref. 89/336/EEC) and low voltage directives (Ref. 73/23/EEC).

Your cellular mobile phone is your responsibility. To avoid damage to yourself, to others or to the phone itself, read and follow all the safety instructions and make them known to anyone

borrowing your phone. Furthermore to prevent unauthorized use of your phone:



Keep your phone in a safe place and keep it out of small children's reach.

Avoid writing down your PIN code. Try to remember it instead.

Switch off the phone and remove the battery if you are going to leave it unused for a long time.

Change your PIN code after purchasing the phone and to activate call restriction options.



The design of your phone complies with all applicable laws and regulations. However your phone may cause interference with other electronic

devices. Consequently you should follow all local recommendations and regulations when using your cellular phone both at home and when away. Regulations on the use of cellular phones in vehicles and aircraft are particularly stringent.

Public concern has been focused for some time on the possible health risks for users of cellular phones. The current research on radio wave technology, including the GSM technology, has been reviewed and safety standards have been drawn up to ensure protection from exposure to radio wave energy.

Your cellular telephone complies with all applicable safety standards and the Radio and Telecommunications Terminal Equipment Equipment Directive 1999/5/EC.

Always switch off your phone

Inadequately protected or sensitive electronic **equipment** may be affected by radio energy. This interference can lead to accidents.

Before boarding an aircraft and/or when packing the phone in your luggage: the use of mobile phones in an aircraft may be dangerous for the operation of the aircraft, disrupt the mobile phones network and may be illegal.



In hospitals, clinics, other health care centres and anywhere else where you may be in the close vicinity of medical equipment.



In areas with a potentially explosive atmosphere (e.g. petrol stations and also areas where the air contains dust particles, such as metal powders).

In a vehicle transporting flammable products (even if the vehicle is parked) or a vehicle powered by liquefied petroleum gas (LPG), check first that the vehicle complies with the applicable safety rules. In areas where you are requested to turn off radio transmitting devices, such as quarries or other areas where blasting operations are in progress.



energy.

Check with the vehicle manufacturer that electronic equipment used in your vehicle will not be affected by radio

Pacemakers

If you have a pacemaker:

- Always keep the phone more than 15 cm from your pacemaker when the phone is switched on, in order to avoid potential interference.
- Do not carry the phone in a breast pocket.
- Use the ear opposite to the pacemaker to minimize the potential interference.
- Switch off your phone if you suspect that interference is taking place.

Users of hearing aids

If you are a user of a hearing aid, consult your physician and hearing aid manufacturer to learn whether your particular device is susceptible to cellular phone interference.

Improved performance

In order to improve the performance of your phone, reduce radio energy emission, reduce battery consumption and ensure safe operation adhere to the following guidelines:

For the optimal and satisfactory operation of the phone, you are recommended to suse the phone in the normal operating position (when not using in hands-free mode or with a hands-free accessory).

- Do not expose your phone to extreme temperatures.
- Treat the phone with care. Any misuse will void the International Guarantee.
- Do not immerse the phone in any liquid; if your phone is damp, switch it off, remove the battery.
 and let them dry for 24hrs before using them again.
- To clean the phone, wipe it with a soft cloth.
- Placing and receiving calls consumes the same amount of battery energy. However, the mobile consumes less energy in idle screen when kept in the same place. When in idle screen and while you are moving, your phone consumes energy to transmit updated location information to the network. Setting the backlight for a shorter

period of time as well as avoiding unnecessary navigating in the menus will also help to save the battery's energy for longer phoning and stand-by performances.

Battery information

- Your phone is powered by a rechargeable battery.
- Use specified charger only.
- · Do not incinerate.
- Do not deform or open the battery.
- Do not allow metal objects (such as keys in your pocket) to short circuit the battery contacts.
- Avoid exposure to excessive heat (>60°C or 140°F), moisture or caustic environments.

You should only use Philips authentic battery and accessories, as the use of any other accessories may damage your phone and may be dangerous, and will

make all guarantees for your Philips phone null and void. The use of an incorrect type of battery may also cause an explosion.

Make sure damaged parts are replaced immediately by a qualified technician and that they are replaced with genuine Philips replacement parts.

- X520 is equipped with a backupowerTMsupported smartcavityTM.
- In the smartcavityTM, use the supplied Energizer Lithium AAA battery (L92), or quality batteries to ensure the charging performance.

Do not use your phone while driving



Speaking on the telephone while driving lowers your concentration, which can be dangerous. Adhere to the following guidelines:

- Give your full attention to driving. Pull off the road and park before using the phone.
- Respect the local regulations in countries where you drive and use your GSM phone.
 If you want to use your phone in a vehicle install
- If you want to use your phone in a vehicle, install the hands-free car kit which is designed for that purpose.
- Ensure that your phone and car kit do not block any air bags or other security devices fitted in your car.

The use of an alarm system to operate a vehicle's lights or horn to indicate incoming phone calls is prohibited on public roads in some countries. Check local regulations.

EN60950 Norm

In case of hot weather or after a prolonged exposure to the sun (e.g., behind a window or a windscreen), the temperature of your phone's casing might increase, especially when featuring a metallic finish. Be very careful in this case when picking up your phone and also avoid using it with an ambient temperature over 40°C.

For your phone, the socket-outlet shall be installed near the phone and shall be accessible.

Environmental care



Remember to observe the local regulations regarding the disposal of the packaging materials, exhausted batteries and old phone and please promote

recycling.

Philips has marked the battery and packaging with standard symbols designed to promote the recycling and appropriate disposal of your eventual waste.



The labelled packaging material is recyclable.



A financial contribution has been made to the associated national packaging recovery and recycling system.



The plastic material is recyclable (also identifies the type of plastic).

WEEE Marking in the DFU: "Information to the Consumer"

Disposal of your old product

Your product is designed and manufactured with high quality materials and components, which can be recycled and reused.



When this crossed-out wheeled bin symbol is attached to a product it means the product is covered by the European Directive 2002/96/EC
Please inform yourself about the local separate collection system for electrical and electronic products.

Please act according to your local rules and do not dispose of your old products with your normal household waste. The correct disposal of your old product will help prevent potential negative

consequences for the environment and human health.

FCC Compliance Statement

This equipment has been tested and found to comply with the limits for a Class B digital device. pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may harmful interference cause radio to communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- -- Reorient or relocate the receiving antenna.
- -- Increase the separation between the equipment and receiver.
- -- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Troubleshooting

The phone does not switch on

Remove/reinstall the battery. Then charge the phone until the battery icon stops scrolling. Unplug from charger and try to switch on the phone.

Your phone doesn't return to the idle screen Long press the hangup key or switch off the phone, check that the SIM card and the battery have been installed correctly and switch it on again.

The network symbol is not displayed

The network connection is lost. Either you are in a radio shadow (in a tunnel or between tall buildings) or you are outside the network coverage area. Try from another place, try to reconnect to the network (especially when abroad), check that the antenna in place if your mobile has an external antenna, or contact your network operator for assistance/information.

The display doesn't respond (or the display responds slowly) to key presses

The display responds more slowly at very low temperatures. This is normal and does not affect the operation of the phone. Take the phone to a warmer place and try again. In other cases, please contact your phone supplier.

Your battery seems to over heat

You might be using a charger that was not intended for use with your phone. Make sure you always use the Philips authentic accessory shipped with your phone.

Your phone doesn't display the phone numbers of incoming calls

This feature is network and subscription dependent. If the network does not send the caller's number, the phone will display *Call I* or *Withheld* instead. Contact your operator for detailed information on this subject.

You can't send text messages

Some networks don't allow message exchanges with other networks. First check that you entered the number of your SMS centre, or contact your operator for detailed information on this subject.

You have the feeling that you miss some calls

Check your call divert options.

The display shows INSERT SIM

Check that the SIM card has been inserted correctly. If the problem remains, your SIM card may be damaged. Contact your operator.

When attempting to use a feature in the menu, the mobile displays NOT ALLOWED

Some features are network dependent. Therefore, they are only available if the network or your subscription supports them. Contact your operator for detailed information on this subject.

Your phone is not charging

If your battery is completely flat, it might take several minutes of pre-charge (up to 10 minutes in some cases) before the charging icon is displayed on the screen.

Philips Authentic Accessories

Some accessories, such as a standard battery and a charger, are included as standard accessories in your mobile phone package. Additional accessories may also be provided or sold separately. Package contents may therefore vary.

To maximize the performance of your Philips phone and not to void the warranty, always purchase Philips Authentic Accessories that are specially designed for use with your phone. Philips Consumer Electronics cannot be held liable for any damages due to use with non authorized accessories.

Charger

Charges your battery in any AC outlet. Small enough to carry in a briefcase/handbag.

Data connect kit

Provides easy data connection to your Philips mobile phone. The USB cable enables high-speed communication between your phone and your computer. The provided software allows you to download pictures and melodies and to synchronize your contacts and appointments.

Deluxe Headset

The integrated answer button offers you a simple way to answer your calls. Simply answer an incoming call by pressing the button or long press to reject the incoming call.

Trademark Declaration



T9® is a trademark of Tegic Communications Inc.







PHILIPS and PHILIPS' Shield Emblem are registered trademarks of Koninklijke Philips Electronics N.V. manufactured by Shenzhen Sang Fei Consumer Communications Co., Ltd. under license from Koninklijke Philips Electronics N.V.

Specific Absorption Rate Information International standards

THIS MOBILE PHONE MEETS THE INTERNATIONAL RECOMMENDATIONS FOR EXPOSURE TO RADIO WAVES

Your mobile phone is a radio transmitter and receiver. It is designed and manufactured not to exceed the limits for exposure to radio frequency (RF) energy defined by the international standards. These recommendations have been established by the International Commission on Non-Ionizing Radiation Protection (ICNIRP) and, the Institute of Electrical and Electronics Engineers (IEEE) that forecast a substantial safety margin for assuring the protection of all persons, regardless of age and health.

The exposure recommendations for mobile phones use a measurement unit known as the Specific Absorption Rate (SAR). The SAR limit recommended by the ICNIRP for the mobile phones used by the general public is 2.0W/kg averaged over ten grams of tissue and, is 1,6W/kg averaged over one gram of tissue by IEEE Std 1528 for the head.

Tests for SAR have been conducted using recommended operating positions with the mobile phone transmitting at its highest certified power level in all tested frequency bands. Although the SAR is determined at the highest certified power level, the actual SAR levels of the mobile phone while operating are generally below the maximum SAR value. This is because the phone is designed to operate at multiple power levels so as to use only the power required to reach the network. In general, the closer you are to a base station antenna, the lower the power output.

While there may be differences between the SAR levels of various phones and at various positions, they all meet the international protection standards for exposure to radio waves.

The highest SAR value for this Xenium X520 model phone when tested for compliance against the standard was 1.04 W/kg for ICNIRP recommendation and 1.11 W/kg for IEEE Std 1528.

For limiting the radio waves exposure, it is recommended to reduce the mobile phone call duration or to use a headset. The purpose of those precautions is to take the mobile phone away from the head and the body.

For body worn operation, this phone has been tested and meets FCC RF exposure guidelines when used whit an accessory that contains no metal and that positions the handset a minimum of 1.5cm from the body. Use of other accessories may not ensure compliance with FCC RF exposure guidelines.

Limited warranty

I. What Does This Limited Warranty Cover?

Philips warrants to the original retail purchaser ("Consumer" or "You") that this Philips cellular product and all accessories originally provided by Philips in the sales package ("Product") are free from defects in materials, design and workmanship under normal use in accordance with the operating instructions and pursuant to the following terms and conditions. This limited warranty extends only to the Consumer for Products purchased and used in the original country of purchase. The limited warranty is valid only in Philips' intended country of sales of the product.

How Long is The Limited Warranty Period?

The limited warranty period for the Product extends for ONE (1) YEAR from the date of purchase of the Product, documented by valid proof of purchase. The limited warranty for original Philips rechargeable battery extends for six (6) months from the date of purchase.

 What Will Philips Do if The Product is Not Free From Material Defects in Materials and Workmanship During The Limited Warranty Period?

During the limited warranty period, Philips or its authorized service representative will, at its option either repair or replace, without charge for parts or labour, a materially defective Product with new or refurbished parts or Product and return such repaired or replaced Product to the Consumer in working condition. Philips will retain defective parts, modules or equipment.

Repaired or replaced Product will be covered by this limited warranty for the balance of the original limited warranty period or ninety (90) days from the date of repair or replacement whichever is longer. Repair or replacement of Product, at Philips' option is your exclusive remedy.

4. What is Not Covered By This Limited Warranty?

This limited warranty does not cover:

 a) Product that has been subjected to misuse, accident, shipping or other physical damage, improper installation, abnormal operation handling, neglect,

- inundation, fire, water or other liquid intrusion; or
- Product that has been damaged due to repair, alteration, or modification by anyone not authorized by Philips; or
- Product that has reception or operation problems caused by signal conditions, network reliability or cable or antenna systems; or
- d) Product defects or problems caused by uses with non-Philips products or accessories; or
- Product which warranty/quality stickers, product serial number or electronic serial number has been removed, altered or rendered illegible; or
- f) Product purchased, used, serviced, or shipped for repair from outside the original country of purchase, or used for commercial or institutional purposes (including but not limited to Products used for rental purposes); or
- g) Product returned without valid proof of purchase or which proof of purchase has been altered or is illegible.
- h) Normal wear and tear or Force Majeure.
- 5. How Do You Get Warranty Service?

- Return the Product to an authorized service center of Philips. You may contact the local Philips office for the location of the nearest authorized service center.
- b) The SIM card must be removed from the Product before it is given to Philips. Philips assumes no liability for damaged or loss of the SIM card or the data contained therein.
- c) If the Product failure is not covered by this limited warranty, or this limited warranty is inapplicable, void or invalid due to any terms and conditions stated herein, the Consumer will be charged for the cost of repair or replacement of the Product and all other related cost incurred in repairing or replacing the Product.
- d) IMPORTANT you are required to return the Product together with a valid proof of purchase which must identify the point of purchase, date of purchase, Product model and Product serial number clearly.
- Other Limitation: This Warranty is The Entire Agreement.

EXCEPT FOR THE EXPRESS WARRANTIES
SET FORTH ABOVE AND THOSE IMPLIED
BY LAW AND WHICH CANNOT BE
EXCLUDED OR MODIFIED BY

AGREEMENT. PHILIPS PROVIDES OTHER WARRANTY WHETHER EXPRESS OR IMPLIED (WHETHER BY STATUTE, UNDER THE OPERATION OF LAW OR OTHERWISE) AND SPECIALLY DISCLAIMS ANY WARRANTY OF SATISFACTORY **OUALITY MERCHANTABILITY OR FITNESS** FOR A PARTICULAR PURPOSE. PHILIPS' TOTAL LIABILITY FOR DAMAGES RELATING TO OR ARISING OUT OF THE PURCHASE OR USE OF THE PRODUCT. REGARDLESS OF THE TYPE OR CAUSE OF SUCH DAMAGE OR THE FORM OR CHARACTERISATION OF THE CLAIM ASSERTED (E.G. CONTRACT OR TOPIT), SHALL NOT EXCEED THE ORIGINAL PURCHASE PRICE PAID FOR THE PRODUCT.

HOWEVER IN NO EVENT SHALL PHILIPS BE LIABLE FOR ANY PUNITIVE, SPECIAL, INCIDENTAL. INDIRECT OR CONSEQUENTIAL DAMAGES (INCLUDING BUT NOT LIMITED TO THE LOSS OF USE. LOSS OF TIME. INCONVENIENCE. COMMERIAL LOSS, LOST PROFITS, LOST BUSINESS OPPORTUNITIES, COST OF SUBSTITUTION OF GOODS OR SERVICES. INVESTMENTS, DAMAGE TO GOODWILL OR REPUTATION, OR LOSS OF DATA AND CLAIMS BY THIRD PARTIES) RESULTING FROM PURCHASE OR USE OF THE PRODUCT, TO THE FULLEST EXTENT ALLOWED BY LAW, WHETHER OR NOT PHILIPS HAS BEEN ADVISED OF THE POSSIBILTY OF SUCH DAMAGES. THESE LIMITATIONS SHALL APPLY NOTWITHSTANDING THE FAILURE OF THE ESSENTIAL PURPOSE OF ANY LIMITED REMEDY.

This limited warranty represents the complete and exclusive agreement between the Consumer and Philips with respect to this cellular Product and it supercedes all prior agreements between the parties, oral or written, and all other communications between the parties relating to the subject matter of this limited warranty. No carrier, retailer, agent, dealer, employee, thereof, or employee of Philips is authorized to make modifications to this limited warranty and you should not rely on any such representation.

This limited warranty does not affect the Consumer's statutory rights under applicable national laws in force.

Declaration of conformity

We, Shenzhen Sang Fei Consumer Communications Co., Ltd. Il Science and Technology Road, Shenzhen Hi-tech Industrial Park, Nanshan District, Shenzhen 518057 China

declare under our sole responsibility that the product

Xenium X520

GSM/GPRS/EDGE 850/900/1800/1900 TAC: 35578902

to which this declaration relates, is in conformity with the following Standards:

SAFETY: EN 60950-1: 2006 HEALTH: EN50360: 2001:

EN62209-1: 2006

EMC: EN301 489-1 V 1.6.1; EN301 489-7 V 1.3.1; EN 301489-17 V1.2.1

SPECTRUM: EN 301 511 V9.0.2; EN 300 328 V1.7.1

We hereby declare that all essential radio test suites have been carried out and that the above named product is in conformity to all the essential requirements of Directive 1999/5/EC.

The conformity assessment procedure referred to in Article 10 and detailed in Annex V of Directive 1999/5/EC has been followed related to articles 3.1 and 3.2 with the involvement of the following Notified Body: CETECOM ICT Services GmbH, Unterturkhelmer Strabe6-10, 66117, Saarbrucken, Germany.

Identification mark: 0682

October 20, 2008

Quality Manager