

PHILIPS

Mobile Phone

535

CT5358



Snap, Talk & Send

FotoTalk: add voice to your pictures

Capture and share your life

- Integrated VGA digital camera
- Digitally zoom up to 4 times
- TFT display with 65,536 gorgeous colors

Add Emotion to your Messages

- MMS (Multimedia Messaging Service)
- FotoTalk adds voice to your MMS pictures
- Special effects for creative picture personalization

Maximize your Multimedia Experience

- Mix your own polyphonic melodies and ringtones with BeDJ
- 32-tone rich polyphonic melodies

Highlights

Integrated VGA digital camera

The integrated digital camera with VGA resolution (640x480 pixels) allows you to take high-quality pictures anytime, anywhere with your phone, then send them via MMS or email, or store the pictures in your phone's memory.

Digital zoom x4

Easily zoom the picture in and out up to 4 times, composing better and more meaningful pictures by capturing the right detail from the overall scene. In preview mode, activate the zoom function to take pictures of distant objects or to concentrate attention on a specific part of the picture.

65K color TFT display

Brilliant 65K color TFT display offers high contrast and high brightness with 65,536 gorgeous colors and ultra fine pitch for clear, bright color graphics and photos.

MMS messaging

MMS (Multimedia Messaging Service) allows you to use your mobile phone to send and receive pictures, video, and audio files with your text messages.

FotoTalk

FotoTalk allows you to instantaneously send pictures and recorded voice messages via MMS to friends and family. Access the camera application via camera hard key or multimedia menu to choose FotoTalk, then take a picture, record your voice, and go to MMS to finalize and send the message.

Special effects

Special effects provide you with several modifications that can be applied in order to personalize camera images: sepia, gray scale, edge, digital, embossed, or negative colors. Choose one of the special effects in camera

preview mode, take the picture, then save the photo in phone screen resolution format e.g. 128x160 pixels.

BeDJ

The amazing BeDJ feature allows you to easily create, enjoy, and share your own music mixes anytime, anywhere for unlimited creativity with this real, portable mixing studio. Create your own sounds using predefined styles provided by famous international DJs, your phone's own polyphonic ring tones, or by downloading content via WAP, infrared, or MMS to mix up to 9 different tracks in real time.

32-tone polyphonic melodies

32-tone polyphonic melodies can create simultaneous tones of different notes using MIDI format for more natural and realistic musical results, sounding just like a small orchestra of different instruments for outstanding sound effects.



Specifications

Picture/Display

Brightness: 120 cd/m²
Lines of text: 8
Main Display Colors: 65536
Main Display Resolution: 128x128 pixel
Main Display Technology: TFT

Sound

Ringers: Polyphonic (32 tones)

Audio Playback

Audio supported formats: ADPCM, AMR, Midi, SP-Midi

Audio Recording

Recording time: upto 60 seconds

Audio Capturing

Voice recording: yes, AMR

Still Picture Playback

Picture compression format: BMP, GIF (87a & 89a), JPEG
Slide show: no

Still Picture Capturing

Camera: Integrated
Digital zoom: x2 and x4
Image sensor type: CMOS
Preview frame rate: 15 frames/second
Picture file format: JPEG
Picture Mode: Economy, Normal, Super fine
Picture resolution: VGA (640x480)
Sensitivity: min 5 lux
Special effects preview mode: Grey scale, Sepia, Blue effect

Storage Media

Built-in memory capacity: 8
User memory: 1.5 MB

Connectivity

Headphone: 2.5 mm
Modem Capabilities: CSD (Voice, Data), GPRS
Synchronisation PC organizer: Lotus Notes, MS Outlook
Wireless connections: Infrared

Convenience

Buttons and controls: 4-way navigation key and enter, Customized hot key
Call Management: Call Cost, Call Counters,

Call Forwarding, Call on Hold, Call Time, Call Waiting, Caller ID, Conference Call, Emergency Call, Explicit Call Transfer, Microphone mute, Missed Calls, Multi-party call, Received Calls

Clock/Version: Analogue, Digital

Ease of Navigation: Animated Carroussel, Color Carroussel

Ease of Use: Blinking Lights, Dedicated Headset plug, Hands free mode, Hot Keys, Screen Saver Digital Clock, Vibra Alert

Ease To Experience: Demo Mode

Embedded Games: 2

Games and applications: Agenda, Alarm Clock, Calculator, Calendar, Euro Converter, Infusio - Exen v2

Language available: T9 input: Chinese Simplified, Chinese Traditional, Czech, Danish, Dutch, English, Finnish, French, German, Greek, Italian, Norwegian, Polish, Portuguese, Spanish, Swedish, Turkish

Language available: UI: Chinese Simplified, Chinese Traditional, Czech, Danish, Dutch, English, Finnish, French, German, Greek, Hebrew, Hungarian, Indonesian, Italian, Lithuanian, Norwegian, Polish, Portuguese, Romanian, Russian, Slovak, Spanish, Swedish, Thai, Turkish

Multimedia: BeDJ, Foto Talk

Personal Info Management: Daylight saving, Time Zone, Smart Phonebook, Vcard Exchange

Personalisation/Customization: Downloadable Animated GIF, Downloadable Picture, Downloadable Ringtones, Exchangeable Covers, Fotocall, Screen Saver, Wallpaper

Speech Recognition: Conversation Recording, Voice Command, Voice Dial, Voice Memo, Voice Recognition

Volume control

Accessories

Optional accessories: Battery 720 mAh, Carry case, Cigarette lighter adapter, Deluxe headset, Exchangeable covers, Necklace, Universal car kit, Wrist wrap

Standard Package Includes: Battery, CD ROM (Mobile Phone Tools), Charger, Handset, International Guarantee, SAR information leaflet, User Manual

Dimensions

Antenna: Integrated
Form Factor: Candy bar
Handset Color: Black Motion, Blue Focus, Red
Lens, Silver Digit
Handset dimensions: 101x44x19
Handset volume: 79
Handset weight: 95

Power

Battery capacity: 720 mAh
Battery Type: Li-ion
Charging time: less than 2 hours hr
Standby time: up to 300 hrs
Talk time: up to 6 hrs

Network Features

Voice Codec: FR/EFR/AMR
GPRS (Rx+Tx): Class 10 (4+2), Class B
Messaging: Concatenated SMS (Long SMS), E-mail, EMS / release 4, MMS, Multimedia Message Service, Predefined messages (SMS, MMS), Quick SMS, SMS CB (Cell Broadcast), SMS (Short Message Service)
Services: WAP 1.2.1, WAP Browser Teleca2.0, SIM Toolkit / Release 99, OTA provisioning (WAP, MMS)

