

# PHILIPS

Mobile Phone

E122

Red



CTE122RED



## Connect and play

Let easy chats, tunes, FM music and news keep you company when you are on the move. With its MP3 hotkeys, FM radio, as well as dual SIM feature, the Philips E122 will not let you miss out on any fun.

### Maximize your mobility

- Dual SIM for 2 groups of contacts

### Multimedia essentials

- Integrated digital camera
- MP3 playback and ringtones for a superior audio experience
- Enjoy FM music your way - out loud or via a headset
- LED flashlight - a handy light source in any dark situations
- MicroSD memory card slot for extra memory/ data storage

# Highlights

## Dual SIM



Organize your life better and keep your contacts separate by using 2 different phone numbers. With Dual SIM, you don't need to carry 2 phones around.

## Digital camera

The integrated digital camera with VGA resolution (640x480 pixels) allows you to capture precious moments of your life anywhere, anytime with your phone. Press camera key to take vibrant pictures and use as wallpaper and fotocall, or to send later via MMS.

## FM radio on the go

Enjoy the convenience of tuning in to FM radio the way you want – play it out loud through the phone's speaker or via your headset. Just plug in the headset, which acts as an antenna and select your listening option in the menu.

## Built-in LED flashlight

Why grope around in the dark for your keys or the light switch? Just rely on the handy built-in LED flashlight in your mobile phone to shed light on any situation.

# Specifications

## Network Features

**GPRS (Rx+Tx):** Class 12, class B and C

**GSM band:** 900, 1800 MHz

**Messaging:** SMS CB (Cell Broadcast), SMS (Short Message Service), SMS multi-target

**Services:** WAP 2.0

**Voice Codec:** FR/EFR/AMR/HR

**GSM band(Primary SIM):** 1800, 900 MHz

**GSM band(Secondary SIM):** 1800, 900 MHz

## Dimensions

**Antenna:** Integrated

**Form Factor:** Candy bar

**Handset color:** red

**Handset dimensions:** 104X46X12.5mm

**Handset weight:** 105g

## Picture/Display

**Diagonal screen size (inch):** 1.8 inch

**Main Display Colors:** 65536

**Main Display Resolution:** 128x160 pixel

**Main Display Technology:** TFT

## Still Picture Capturing

**Camera:** Integrated

**Image sensor type:** CMOS

**Picture file format:** JPEG

**Picture resolution:** VGA (640x480)

## Still Picture Playback

**Picture Compression Format:** BMP, JPEG

## Video Capturing

**Advanced settings:** Contrast, Saturation, Video quality, Remove flicker

## Video Playback

**Compression formats:** MPEG4, 3GP

## Audio Capturing

**Voice recording:** AMR

## Audio Playback

**Audio supported formats:** AMR, Midi, MP3

## Audio Recording

**Record your own voice**

## Sound

**Ringers:** MP3 ringer, Polyphonic (64 tones)

## Storage Media

**Memory Card Types:** Micro SD

**Memory management:** Memory status, Dynamic memory allocation

**Maximum memory card capacity:** 8 GB

## Convenience

**Buttons and controls:** 4-way navigation key and enter, Customized hot key, Soft keys, Dedicated music player keys

**Call Management:** Call Counters, Call Forwarding, Call on Hold, Call Time, Call Waiting, Emergency Call, Microphone mute, Missed Calls, Received Calls

**Clock/Version:** Digital

**Ease of Use:** Graphical User Interface, Hands free mode, Hot Keys, Keypad Lock, Softkeys, Vibra Alert, Dual SIM cards

**Embedded Games:** 3

**Games and applications:** Alarm Clock,

Calculator, Calendar

**Language available: UI:** English, Hindi

**Multimedia:** FM Radio

**Personalisation/Customization:** Screen Saver, Wallpaper, Ringtones

**Text input:** Character counter, Smart predictive input

**Vibrator**

**Volume control**

## Multimedia Applications

**Memory Card Access:** SD card slot

## Connectivity

### Bluetooth

**Headset:** Via 3.5mm jack connector

**Serial connections:** USB-miniUSB data cable

**Bluetooth profiles:** Handsfree, Headset, Object push profile, File transfer profile, A2DP (MP3 playback only)

## Accessories

**Standard Package Includes:** Battery, Charger, Headset, Stereo Headset, User Manual

## Power

**Battery capacity:** 750mAh

**Battery saving manager:** Auto switch on/off

**Battery Type:** Li-ion

**Standby time:** Up to 310 hours

**Talk time:** Up to 3.5 hours

## Green Specifications

**Lead-free soldered product**

**Packaging material:** Carton

**User manual:** Recycled paper

