

PHILIPS

Mobile Phone

E320

Red

CTE320RD



Where elegance meets intelligence

Epitomizing contemporary elegance, the Philips E320 has an external display, a 2.6 inch IPS display, dual Sim and a compact clamshell design. Not to mention a built-in 2 megapixel camera to perfectly capture those precious moments.

Multimedia essentials

- Capture your memories with 2 megapixel camera
- Enjoy FM music your way – out loud or via a headset
- MP3 playback and ringtones for a superior audio experience

Fabulous and practical

- Dual SIM for 2 groups of contacts
- Stylishly compact
- 2.6" QVGA IPS display for vivid graphics from any angle
- External OLED display for discreet control

Highlights

2 Megapixel camera



Capture and enjoy precious memories in clear and sharp picture quality with 2 megapixel resolution. Vibrant, colorful pictures are just a click away.

2.6" QVGA IPS display

Experience true scintillating color with the 2.6" QVGA screen on your Philip mobile phone. Built with IPS technology to give you the best views from any viewing angle, your phone will display vibrant colors and vivid images in all

your photos and graphics for endless multimedia fun and excitement. With bright colors and stunning visuals, what's not to like?

Dual SIM



Organize your life better and keep your contacts separate by using 2 different phone numbers. With Dual SIM, you don't need to carry 2 phones around.

External OLED display

Without flipping the phone open, view the time, missed call, SMS alerts, alarms, to-do list, radio station and track information

conveniently by simply pressing the volume keys '+' or '-'. It also lets you choose radio channels and music with ease.

FM radio on the go

Enjoy the convenience of tuning in to FM radio the way you want - play it out loud through the phone's speaker or via your headset. Just plug in the headset, which acts as an antenna and select your listening option in the menu.

MP3 playback and ringtones

Use the data cable or an external memory card to transfer MP3 music files to your phone for a superior audio experience on the go. You can also personalize your ringtone with a selection from your MP3 files.

Stylishly compact

Make a bold statement and express yourself with your Philips mobile phone that comes with a trendy design and sleek finish. Be a trend-setter, not a follower!

Specifications

Network Features

GPRS (Rx+Tx): Class 12, Class B
GSM band: 850, 900, 1800, 1900 MHz
Voice Codec: FR/EFR/AMR/HR

Dimensions

Form Factor: Clam shell
Handset color: Red
Handset dimensions: 107.2*51*17.3mm
Handset weight: 107.5g

Picture/Display

Diagonal screen size (inch): 2.6 inch
Main Display Colors: 262K
Main Display Resolution: 240x320 pixel

Still Picture Capturing

Camera: Integrated
Image sensor type: CMOS
Picture resolution: 2M (1600x1200)

Still Picture Playback

Picture Compression Format: BMP, GIF, JPEG, PNG, WBMP

Video Playback

Compression formats: FLV, MPEG4, H.263

Audio Playback

Audio supported formats: Midi, MP3, WAV, AMR

Convenience

Buttons and controls: 4-way navigation key and enter, Side keys
Language available: UI: English, Romanian, Russian, Ukrainian
Multimedia: FM Radio

Connectivity

Bluetooth: Bluetooth V2.1
Headset: Via 3.5mm jack connector-CTIA
Serial connections: USB-MicroUSB data cable
Wireless connections: Bluetooth

Accessories

Standard Package Includes: Battery, Charger, Handset, Standard Headset, User Manual, USB data cable

Power

Battery Capacity: 1000mAh
Battery Type: Lithium-ion

Audio Capturing

Voice recording: AMR, Yes

