



Philips HomeRun 3000
Series Aqua
Vacuum and Mop Robot

with charging station
Dark & Beluga Metallic
Connected to HomeRun App



XU3000/01

Daily wet & dry cleaning without effort

Enjoy a pristine clean every day, with far less effort. The robot delivers ultra-strong suction power and vacuums and mops in one go. The robot automatically boosts suction power when it has driven onto a carpet or rug.

Come home to a complete clean every day

- Removes more fine dust than vacuuming alone
- Ultra-strong suction power picks up large dirt
- Detects carpets and increases suction power automatically
- Maximum coverage of your floor: doesn't miss a spot

Designed around you

- Intuitive to use - ideal for first time users
- Clean each room, just the way you like it
- Control where the robot is allowed to clean

Your daily helper saves you time and effort

- Cleans up to 200 minutes on a single battery charge
- Also cleans in hard-to-reach areas

PHILIPS

Highlights

Vacuum and Mop in one go



The robot vacuums and mops hard floors in one go to tackle the fine layer of dust that builds up on floors every day. Removing more fine dust than vacuuming alone, so the soles of your feet will stay clean even if you walk around barefoot.

HomeRun app



The Philips HomeRun robot app has been designed to be user-friendly and intuitive - ideal for first time users. It features step-by-step guidance and helpful videos to ensure you're getting the very best out of your robot. The app communicates with your robot to control, report and update on its cleaning performance wherever you are, showing in real time where the robot has cleaned.

Strong suction power (Robbie)



Ultra-strong suction power (rigorously tested to reach up to 4000 Pa) can pick up large dirt, like crumbs. It takes care of the everyday dirt build-up underfoot, as well as removing finer dust from deep within crevices, carpets and rugs.

Long battery run time (Robbie)



The powerful 4800 mAh Li-Ion battery ensures a run time of up to 200 minutes of battery run-time, enough for up to 185 SqM. When the battery runs low, the robot will automatically return to the station to recharge. Once the battery is charged, it will return to the place where it has left off to resume the cleaning.

Bespoke cleaning plan



In the Philips HomeRun app, you can select on the map which room(s) should be cleaned in what order. For each room you can specify a

cleaning mode, for example Wet & Dry for a regular cleaning of hard floors in the living room, Dry to vacuum only in the bedroom and Intensive for a thorough cleaning of the kitchen. If you wish, you can finetune settings like suction power or wetness of the mop.

Carpet boost (Robbie)



The robot automatically boosts suction power when it has driven onto a carpet or rug to capture fine dust particles hidden deep inside the carpet. The robot has four different suction levels: Eco, for an efficient cleaning with low energy consumption and low noise level; Normal, for a regular cleaning and effective removal of fine dust on hard floors; High for a thorough cleaning of large floors; and Max, ideal for removing large clumps of dirt like crumbs.

Maneuverability (Robbie)



Thanks to its low height (96 mm) it cleans also in hard-to-reach areas under sofas, beds and other furniture. For a more thorough cleaning, the robot uses its side brush to sweep along edges, to bring dirt to the suction inlet. The robot can move around your home without manual help. It can effortlessly cross hurdles up to 17 mm, for example drive over door thresholds and onto carpets or rugs. Plus, three anti-drop sensors are located on the bottom of the robot to prevent it from falling from a height or down stairs.

Specifications

Robot highlights

- Vacuum and Mop in one go
- Mopping technology: Passive flat mop
- Suction power (maximum): 4000 Pa
- Type of navigation: 360° laser navigation (LiDAR)
- Small obstacle detection: No
- Battery capacity: 4800 mAh
- Battery run time (maximum): Up to 200 minutes
- Noise level (minimum): ≤66 dB
- Color: Dark & Beluga metallic

Docking Station

- Charging function
- Auto-Empty function: No
- Philips Dual Wave technology: No
- Type of dust bag: N/A
- Size of dust bag: N/A

App

- App name: Philips HomeRun
- Connect via Wi-Fi: Yes, dual band (2.4 GHz and 5 GHz)
- Connect via Bluetooth: No
- Languages in the app: English, German, French, Italian, Polish, Spanish, Turkish, Bahasa Malaysia, Bulgarian, Croatian, Czech, Danish, Dutch, Estonian, Finnish, Hungarian, Lettish, Lithuanian, Norwegian, Portuguese, Romanian, Slovak, Slovenian, Swedish, Vietnamese
- How to use videos
- Quick mapping function
- Multi-floor mapping: Yes, save up to 5 maps
- Select which room(s) to clean
- Select room cleaning sequence
- Select cleaning mode per room
- Cleaning modes: Wet & Dry, Dry, Intensive, Silent, Individual
- Suction power (levels): 4 levels: Eco, Normal, High, Max
- Mop wetness (levels): 4 levels: None, Low, Medium, High

- Cleaning path repetition: 1 pass or 2 passes
- Restricted cleaning areas: Virtual wall, No-Go zone, No-Mop zone
- Clean while you're away: real time map
- In-app alerts & notifications
- Cleaning report & history
- Maintenance dashboard
- Scheduled cleaning
- Child lock
- Contact Consumer Care: Phone

Wet cleaning

- Nr. of mop vibrations per minute: N/A
- Electric water tank to adjust wetness of the mop
- Lifiable mop: No
- Washable & wear resistant microfiber mop
- Can be used with detergents: No

Dry cleaning

- Carpet boost function
- Type of main brush: Multi-surface rubber brush with bristles
- Nr. of side brushes: 1x
- Type of filter: Washable EPA11 filter

Sensors

- Navigation technology: LDS laser navigation
- Small obstacle detection technology: N/A
- Obstacle recognition via artificial intelligence: No
- Carpet detection sensor: No
- Anti-drop sensors to detect a cliff: Yes, 3 sensors
- Station seeker: Yes, infrared signal receiver & emitter
- Water tank empty sensor
- Dust bin full sensor
- Dust bag full sensor

Maneuverability & Autonomy

- Clean room by room
- Obstacle crossing ability: Up to 17 mm (empty water tank)

- Automatic recharge function
- Automatic resume function

Voice alert & voice control

- Voice alert function via built-in speaker
- Voice alert languages: English, German, French, Italian, Polish, Spanish, Turkish, Bahasa Malaysia, Czech, Dutch, Estonian, Hungarian, Lithuanian, Norwegian, Romanian, Slovak, Slovenian, Swedish

Power

- Battery type: Lithium-Ion
- Battery run time (minimum): Up to 200 minutes
- Battery charging time: Up to 6,5 hours
- Battery voltage: 14.76V
- Standby power consumption: 130mA
- Battery can be removed and replaced

Capacity

- Dust bin capacity: 350 ml
- Water tank capacity: 300 ml
- Range: sqm that can be mopped without refill: Up to 150 sqm

Weight and dimensions

- Robot diameter: 341 mm
- Robot height: 96 mm
- Station width x length x height: 154 x 146 x 90 mm
- Weight of robot: 3.8 kg
- Weight of station: 0.4 kg
- Weight incl. packaging: 10.4 kg
- Dimensions of packaging (LxWxH): 525 x 305 x 525 mm

Accessories included

- Station: Charging station
- Washable mop: 2
- Disposable mops: N/A
- Washable filter: 1
- Main brush: 1
- Side brush: 1

Specifications

- Brush cleaning tool: No
- Dust bag: N/A
- Placemat
- Remote control: No
- Power cord
- Quick Start Guide: Yes, printed
- User manual: Digital



Issue date 2023-12-19

Version: 17.17.1

© 2023 Koninklijke Philips N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips N.V.
or their respective owners.

www.philips.com