

Philips  
Eye mask massager

Airbags massage eye acupoints  
Stereo bone conduction music  
Large area hot compress  
Nano silicone leather lining

PPM2702



## Brilliant eye care with enjoyable music

### 3D airbag massage system

PPM2702 innovatively added bone conduction music system and optimize 3D massage system, fully relieve the eye fatigue. Equipped with independent side airbags, it cares all the areas around the eyes. Support hot compress to relax the eyes.

#### **Double-layer 3D airbags care for the eyes**

- Simulating manual massage with airbags, soothes eye swelling
- All-round care of the eye area with independent side airbags
- Hot compress promotes blood circulation and relieve fatigue

#### **Enjoy bone conduction music, not disturbing others**

- Enjoy the 3D surrounded music with bone conduction music

#### **Visual window design, massage while playing**

- No hindrance to work, reduce direct pressure on the eyeballs
- 5 eye protection modes, switch as you like

#### **Nano silicone lining, skin-friendly & easy to clean**

- Dry, clean, skin-friendly with nano silicone leather lining
- Convenient to store and carry out

# PHILIPS

## Eye mask massager

Airbags massage eye acupoints Stereo bone conduction music, Large area hot compress, Nano silicone leather lining

# Specifications

### General specifications

- Product Dimension (LxWxH): 215x114x80mm mm
- Massage type: Pressing, Hot compress
- Net weight: approx. 365 g
- Color: Dark blue
- Packaging Dimension(L)\*(W)\*(H): 207x142x91 mm
- Main materials: Organic silicone urethane, ABS plastic, Elastic fabric

### Main parameters

- Temperature of heating: 42 (±3) °C
- Battery: 1200 mAh

- Massage modes: 5
- Airbag quantity: 10
- Charging port: USB Type-C
- Music system: Bluetooth/ bone conduction music
- Charging Current: 500 mA
- Charging Voltage: 5 V
- Operating Power: 4 W
- Operating Voltage: 3.7 V

### Country of origin

- Made in: China

### Service

- Warranty period: 2 years

PPM2702DB/97

# Highlights

### 3D airbags massage

Equipped with professionally designed intelligent airbags, covering all parts around the eyes. Through the inflating and deflating of each air bag, it simulates manual kneading massage on acupuncture points to relieve the soreness and discomfort of the eyes. With the just-right strength, the massager cares for eyes without pressing the eyeball while massaging.

### Independent side airbag design

On both sides of the main airbag, there are independent side airbags to further massage the temple area with the right strength. With the main airbag, it can massage the important acupoints around the eyes in an all-round way and take good care of the acupoints around the eyes.

### Constant hot compress function

The built-in temperature sensing device precisely controls the temperature in every minute, and strives to present the best heat sensation of 42C. Promote blood circulation around the eye area can effectively relax the muscles around your eyes, get rid of eye soreness and dryness, and improve the status of eye fatigue.

### Bone conduction music play system

The newly upgraded bone conduction music system, surround 3D stereo sound, immersive and excellent sound quality, enjoy the immersive massage experience. Free your ears, perceive external sounds at any time, reduce claustrophobia, listen more safely, and relax your mind and body more efficiently. Skin-friendly bone conduction earphones, closed and anti-leakage design, no fear of disturbing others, it is more comfortable to enjoy music quietly.

### Visual window design

The visual window design can reduce claustrophobia and relieve eye fatigue, and does not affect daily entertainment, rest, and work. The eyeball area is designed with a groove to avoid direct pressing on the eyeball and there will be no dizziness and other adverse phenomenon after the massage. The massage does not affect the eye makeup, no matter when it is or where you are.

### 5 modes

Short press the power button to cycle through the following massage modes: [Eye Beauty Mode], [Eye Care Mode], [Sleep-aid Mode], [Eye Warming Mode] and [Music Mode]. Combined with the corresponding bluetooth connection status, it can intelligently switch the mode status and provide you an exclusive shutdown settings.

### Skin-friendly fabric

The inner lining is made of nano-silicone leather, which is soft and smooth to the touch like baby skin. Durable and breathable, it ensures that the skin stays dry at all times and cares for the fragile eye area. It can be scrubbed for convenient cleaning.

### Foldable design

Foldable design, make it light and portable, easy to store.



Issue date 2023-05-22

Version: 1.1.1

© 2023 Koninklijke Philips N.V.  
All Rights reserved.

Specifications are subject to change without notice.  
Trademarks are the property of Koninklijke Philips N.V.  
or their respective owners.

[www.philips.com](http://www.philips.com)