

Philips Cineos  
digital widescreen flat TV

127 cm (50")  
plasma  
integrated digital

50PF9631D



## Turn up your viewing experience

with Pixel Plus 2 HD and Ambilight 2

Enjoy the ultimate viewing experience of this Philips Cineos Flat TV with Pixel Plus 2 HD, Ambilight 2, the latest PDP technology and table top stand. The Digital Media Reader via USB gives you full access to multimedia content.

### **True beauty lies in the details**

- Matching stand with elegant design included

### **Unrivalled audio performance**

- Virtual Dolby Digital for a true life audio experience

### **Immersive viewing experience**

- High Definition plasma WXGA display, 1366 x 768p
- Enjoy HDTV that's truer than anything you've seen before
- HD Ready for the highest quality display of HD signals
- Pixel Plus 2 HD for great details, depth and clarity
- 2-channel active Ambilight enhances the viewing experience

### **For advanced performance**

- HDMI input for full digital HD connection in one cable

### **Perfect picture quality from your digital photos**

- USB Connector for easy, instant multimedia playing

# PHILIPS

digital widescreen flat TV  
127 cm (50") plasma, integrated digital

# Highlights

## Plasma WXGA panel, 1366 x 768p

This state-of-the-art plasma screen technology gives you widescreen HD resolution of up to 1366 x 768p pixels. It produces brilliant flicker-free progressive scan pictures in with optimum brightness and superb colors. This vibrant and sharp image will provide you with an enhanced viewing experience.

## HDTV


HDTV delivers exceptional picture quality and real movie-viewing experience that makes television more dynamic, truer than anything you've seen before. It is the latest and best television signal available. It features picture quality more than twice that of traditional analog broadcasts. In order to effectively maximize the HDTV signal, a television must incorporate advanced signal input connectivity and circuitry design.

## HD Ready



Enjoy the exceptional picture quality of High Definition pictures and be fully prepared for HD sources like HDTV settop box or Blu-ray disc. HD Ready is a protected label that offers picture quality beyond that of progressive scan. It conforms to strict standards laid out by EICTA to offer a HD screen that displays the benefits of resolution and picture quality of a High Definition signal. It has a universal connection for both analog YPbPr and uncompressed Digital connection of DVI or HDMI, supporting HDCP. It can display 720p, and 1080i signals at 50 and 60Hz.

## Pixel Plus 2 HD



Pixel Plus 2 HD offers the unique combination of ultimate sharpness, natural detail, increased depth, vivid colors and smooth and natural motion from standard TV, High Definition signals and multimedia sources. Each pixel of the incoming picture is enhanced to better match the surrounding pixels, resulting in a more natural picture. Artifacts in compressed multimedia content are detected and reduced, ensuring that the picture is clean and razor sharp. Digital noise reduction ensures that the picture is perfectly smooth yet razor sharp.

## Ambilight 2 channel



Ambilight makes an impressive contribution to the overall viewing experience by producing ambient light to complement the colors and light intensity of the on-screen image. It adds a new dimension to the viewing experience, completely immersing you into the content you are watching. It creates ambiance, stimulates more relaxed viewing, and improves perceived picture detail, contrast and color. Ambilight automatically and independently adapts its colors according to the changing content on the screen.

## Virtual Dolby Digital

Virtual Dolby Digital is a processing technology for enhancing surround sound effects. It will

50PF9631D/79

create the sensation of Dolby Pro Logic without the necessity of additional rear speakers. You become totally immersed in your television experience.

## Bypacked tabletop stand

A table-top stand with matching design is packed with the set.

## USB Multimedia Connector



The USB connector allows access to multimedia jpg, mp3 and alb files of most USB-sticks and most digital cameras (USB 1.1 memory-class device). Plug the USB into the slot at the side of the TV and access your photos or music files. This makes you easily viewing and sharing your photos and music.

## HDMI input



HDMI makes an uncompressed digital RGB connection from the source to the screen. By eliminating conversion to an analog signal, it delivers an unblemished image. The non-degraded signal reduces flicker and leads to a clearer picture. HDMI intelligently communicates the highest output resolution with the source device. The HDMI input is fully backward compatible with DVI sources but includes digital audio. HDMI uses HDCP copy protection.



# Specifications

## Ambilight

- Ambilight Features: Ambilight 2 Channel, Auto adaptive to video content, Efficient low energy lamp
- Color Settings: Full Multi Color
- Dimming Function: Manual and via Light Sensor

## Picture/Display

- Aspect ratio: 16:9
- Diagonal screen size (inch): 50 inch
- Diagonal screen size (metric): 127 cm
- Color cabinet: High Gloss Black
- Panel resolution: 1366 x 768p
- Brightness: 1500 cd/m<sup>2</sup>
- Contrast ratio (typical): 10000:1
- Picture enhancement: Pixel Plus 2 HD, 3D Combfilter, Active Control + Light sensor, Digital Crystal Clear, Digital Natural Motion, Dynamic contrast enhancement, Jagged Line Suppression, Progressive scan, Pulse Killer Chip, Widescreen Plus
- Display screen type: Plasma HD panel
- Dynamic screen contrast: 10000:1
- Response time (typical): 6 ms
- Viewing angle: 160° (H) / 160° (V)
- Screen enhancement: Anti ageing circuit, Anti-Reflection coated screen

## Supported Display Resolution

- Computer formats: 640 x 480, 60Hz, 800 x 600, 60Hz, 1024 x 768, 60Hz
- Video Formats: 640 x 480i - 1Fh, 640 x 480p - 2Fh, 720 x 576i - 1Fh, 720 x 576p - 2Fh, 1280 x 720p - 3Fh, 1920 x 1080i - 2Fh

## Tuner/Reception/Transmission

- Aerial Input: 75 ohm coaxial (IEC75)
- Tuner bands: Hyperband, S-Channel, UHF, VHF
- TV system: NTSC, PAL B/G, DVB COFDM 2K/8K
- Digital TV: DVB Terrestrial \*
- Video Playback: NTSC, SECAM, PAL

## Multimedia Applications

- Digital Content Management: Digital Media Reader
- Multimedia connections: USB (streaming video capable)
- Playback Formats: MP3, Slideshow files (.alb), JPEG Still pictures, MPEG2

## Convenience

- Child Protection: Child Lock+Parental Control
- Ease of Installation: Auto Program Naming, Automatic Channel Install(ACI), Automatic Tuning System (ATS), Autostore, PLL Digital Tuning, Plug & Play
- Ease of Use: 4 favorite lists, Auto Volume Leveller (AVL), Delta Volume per preset, Graphical User Interface, On Screen Display, Program List, Side Control
- Clock: Smart Clock
- Screen Format Adjustments: 4:3, 6 Widescreen Modes, Auto Format, Movie expand 14:9, Movie expand 16:9, Subtitle and Heading Shift, Super Zoom, Widescreen
- Remote Control: Aux, DVD, STB (Set-Top Box), VCR
- Remote control type: RC4401
- Teletext: 1200 page Hypertext
- VESA Mount: Vesa compliant
- Picture in Picture: Text dual screen
- Teletext enhancements: Habit Watch, Program information Line

## Sound

- Output power (RMS): 2x15W
- Sound System: Virtual Dolby Digital
- Sound Enhancement: Digital Signal Processing, Dynamic Bass Enhancement, Graphic Equaliser

## Loudspeakers

- Built-in speakers: 4
- Loudspeaker types: Integrated woofers with wOOx, Dome tweeter

## Connectivity

- Front / Side connections: Audio L/R in, CVBS in, Headphone Out, S-video in, USB
- Ext 1 Scart: Audio L/R, CVBS in/out, RGB
- Ext 2 Scart: Audio L/R, CVBS in/out, RGB, S-video in
- Other connections: Monitor out, CVBS, L/R (cinch), S/PDIF out (coaxial), Common Interface
- Ext 3: YPbPr
- Ext 4: HDMI
- Ext 5: HDMI

## Power

- Mains power: AC 110 - 240 V +/- 10%


- Ambient temperature: 5 °C to 40 °C
- Power consumption: 400 W
- Standby power consumption: 1W

## Accessories

- Included accessories: Table top stand, Wall mounting bracket, RF antenna cable
- Optional accessories: Floor stand

## Dimensions

- Set Width: 1327 mm
- Set Height: 908 mm
- Set Depth: 114 mm
- Product weight: 57 kg
- Set height (with stand): 968 mm
- Set depth (with stand): 320 mm
- Box width: 1412 mm
- Box height: 1223 mm
- Box depth: 353 mm
- Weight incl. Packaging: 83.4 kg
- Wall mount compatible: 600 x 200 mm



Issue date 2023-10-05

Version: 3.0.4

EAN: 87 10895 99725 6

© 2023 Koninklijke Philips N.V.  
All Rights reserved.

Specifications are subject to change without notice.  
Trademarks are the property of Koninklijke Philips N.V.  
or their respective owners.

[www.philips.com](http://www.philips.com)