

PHILIPS

Full HD Slim LED TV

4300 series

164 cm (65")

Full HD LED TV



65PFA4350



Full HD Slim LED TV

With Digital Crystal Clear

The right TV for every home. Philips 4300 series Full HD LED TV with Digital Crystal Clear picture engine, HDMI and USB connectivity gives you the greatest TV viewing experience and convenience.

Television viewing at your convenience

- Two HDMI inputs and Easylink for integrated connectivity
- USB for multimedia playback

Functional elegance

- Ultra Narrow bezel gives you more picture to love
- Edge foot concept creates airy, floating effect

A clear, vivid picture every time

- Digital Crystal Clear: precision you'll want to share
- 100Hz PMR for sharp moving images

Highlights

Ultra narrow bezel



Traditional TVs have a bezel that wraps around the TV like a picture frame. Our Ultra Narrow bezel is modern and thin, so you have more picture to enjoy.

Digital Crystal Clear

For natural looking pictures from any source, Philips created Digital Crystal Clear. Because whether you indulge in your favorite soap, the news, or have friends over to watch a video—you'll enjoy it all in optimal contrast, color and sharpness.

100Hz Perfect Motion Rate



Perfect Motion Rate combines Philips display technology and advanced video processing techniques to improve the quality of each picture frame. So whether you like gaming, fast paced sporting events or action films, you'll experience the ultimate in sharpness and smooth moving images.

Two HDMI inputs with Easylink

Avoid cable clutter with a single HDMI cable to carry both picture and audio signals from your devices to your TV. HDMI uses uncompressed signals, ensuring the highest quality from source to screen. Together with Philips Easylink, you'll need only one remote control to perform most operations on your TV, DVD, Blu-ray, set top box or home theatre system.

USB (photos, music, video)



Share the fun. Connect your USB memory-stick, digital camera, mp3 player or other multimedia device to the USB port on your TV to enjoy photos, videos and music with the easy to use onscreen content browser.

Modern Edge Feet look



When setting out to create a new TV, our teams consider every aspect: from technology to design. Our new edge feet were engineered to create space beneath your TV where a traditional stand would normally sit, offering you a more immersive viewing experience. The effect? A TV that stands confidently with a nod to the future.

Specifications

Picture/Display

Aspect ratio: 4:3/16:9

Diagonal screen size (inch): 65 inch

Diagonal screen size (metric): 164 cm

Display: LED Full HD

Picture enhancement: Digital Crystal Clear, 100 Hz Perfect Motion Rate

Panel resolution: 1920x1080p

Viewing angle: 176° (H) / 176° (V)

Supported Display Resolution

Computer inputs: up to 1920x1080 @ 60Hz

Video inputs: 24, 25, 30, 50, 60 Hz, up to 1920x1080p

Tuner/Reception/Transmission

Analog TV: NTSC, PAL, SECAM

Multimedia Applications

Video Playback Formats: H264/MPEG-4 AVC, MPEG-2, MPEG-4

Music Playback Formats: MP3, AAC, MPEG1 L1/2

Picture Playback Formats: JPEG, BMP, PNG

User Interaction

Firmware upgradeable: Firmware upgradeable via USB

Screen Format Adjustments: 4:3, Widescreen, 16:9, Fit to Screen

Sound

Output power (RMS): 16W

Sound Enhancement: Incredible Surround

Connectivity

Number of AV connections: 1

Number of HDMI connections: 2

Number of component in (YPbPr): 1

EasyLink (HDMI-CEC): One touch play

Number of USBs: 2

Other connections: Antenna IEC75, Audio L/R in, PC-In VGA, Headphone out

Power

Mains power: AC 110 - 240 V 50/60Hz

Standby power consumption: < 0.5 W

Accessories

Included accessories: Remote Control, 2 x AAA Batteries, Table top stand, Power cord, Quick start guide

Dimensions

Product weight: 19.5 kg

Set Width: 1462 mm

Set width (with stand): 1462 mm

Wall mount compatible: 200 x 300 mm

Set Height: 844 mm

Weight incl. Packaging: 28.0 kg

Set Depth: 88 mm

Set height (with stand): 901 mm

Set depth (with stand): 258 mm

Product weight (+stand): 20.0 kg

