

PHILIPS

Full HD LED TV

5300 series

164 cm (65")

Full HD LED TV

DVB-T/T2

65PFT5409



Full HD LED TV

with Pixel Precise HD

Everyone in your home will enjoy the crisp, clear picture of the Philips 5400 series Full HD LED TV. The minimalist design, vivid images, and great sound make it the ideal choice for any room in your house.

Beyond entertainment, it's interior design

- Modern design complements today's interior
- Ultra Narrow bezel gives you more picture to love

Television viewing at your convenience

- Three HDMI inputs and Easylink for integrated connectivity
- USB for multimedia playback

Entertainment at a higher level

- Pixel Precise HD Engine: discover vivid Picture Quality
- Full HD LED TV—brilliant LED images with incredible contrast
- 600Hz PMR for flawless moving images

Highlights

Ultra narrow bezel



Traditional TVs have a bezel that wraps around the TV like a picture frame. Our Ultra Narrow bezel is modern and thin, so you have more picture to enjoy.

Modern Design

Designed with a contemporary look to blend with your décor. Because your TV should look as beautiful off as it does on.

Three HDMI with Easylink



Avoid cable clutter with a single cable to carry both picture and audio signals from your devices to your TV. HDMI uses uncompressed

signals, ensuring the highest quality from source to screen. Together with Philips Easylink, you'll need only one remote control to perform most operations on your TV, DVD, Blu-ray, set top box or home theatre system.

USB (photos, music, video)

USB



Share the fun. Connect your USB memory-stick, digital camera, mp3 player or other multimedia device to the USB port on your TV to enjoy photos, videos and music with the easy to use onscreen content browser.

600Hz Perfect Motion Rate

600Hz
PERFECT MOTION RATE



Nothing beats the adrenaline rush of gaming, fast paced sporting events or action films. That's why this Philips TV has 600Hz Perfect Motion Rate; so you'll enjoy flawless moving images. Because even though your pulse may jump, the image you're watching shouldn't.

Full HD LED TV

Picture Quality matters. Regular HDTVs deliver quality, but you expect more. Imagine crisp detail paired with high brightness, incredible contrast and realistic colors for a true to life picture.

Pixel Precise HD

The Philips Pixel Precise HD Engine brings the world to you. Experience your favorite nature and travel programs in vivid clarity. Drenched in color and high contrast thanks to deeper blacks and brighter whites, you'll explore new frontiers without ever leaving your couch.

Specifications

Picture/Display

Aspect ratio: 16:9
Diagonal screen size (inch): 65 inch
Diagonal screen size (metric): 164 cm
Display: LED Full HD
Picture enhancement: 600 Hz Perfect Motion Rate, Digital Natural Motion, Pixel precise HD
Panel resolution: 1920x1080p

Supported Display Resolution

Computer inputs: up to 1920x1080 @ 60Hz
Video inputs: 24, 25, 30, 50, 60 Hz, up to 1920x1080p

Tuner/Reception/Transmission

Digital TV: DVB-T/T2
Video Playback: NTSC, PAL, SECAM
Analog TV: NTSC, PAL, SECAM

Multimedia Applications

Video Playback Formats: Containers: AVI, MKV, H264/MPEG-4 AVC, MPEG-1, MPEG-2, MPEG-4, WMV9/VC1
Music Playback Formats: MP3
Subtitles Formats Support: .AAS, .SMI, .SRT, .SSA, .SUB
Picture Playback Formats: JPEG, BMP, PNG

User Interaction

Ease of Use: One-stop Home button
Firmware upgradeable: Firmware upgradeable via USB
Screen Format Adjustments: Dot: dot, Zoom 1, Zoom 2, 4:3, Widescreen
Teletext: 1000 page Smart Text

Sound

Output power (RMS): 20W
Sound Enhancement: Virtual Surround, Auto Volume Leveler, Bass Control
Sound Features: Digital Surround Sound Read*
Audio Codecs: E-AC3 multi-channel, MPEG-4 HE AAC multi-channel

Connectivity

Number of AV connections: 1
Number of HDMI connections: 3
Number of component in (YPbPr): 1
EasyLink (HDMI-CEC): System standby, One touch play
Number of USBs: 1
Other connections: Antenna IEC75, Digital audio out (coaxial), Audio L/R in, PC-in VGA + Audio L/R in, Headphone out

Power

Mains power: AC 110- 240V 50/60Hz
Ambient temperature: 5 °C to 40 °C
Standby power consumption: < 0.5 W
Power Saving Features: Auto switch-off timer, Eco mode
Off mode power consumption: < 0.5

Accessories

Included accessories: Remote Control, 2 x AAA Batteries, Table top stand, Power cord, Quick start guide, Edge feet stand, Legal and safety brochure, User Manual, Warranty Leaflet

Dimensions

Box depth: 160 mm
Product weight: 31.8 kg
Set Width: 1457.8 mm
Set width (with stand): 1482.52 mm
Wall mount compatible: 400 x 400 mm
Compatible wall mount: 400 x 400mm
Box height: 990 mm
Box width: 1569 mm
Set Height: 851.69 mm
Weight incl. Packaging: 33 kg
Set Depth: 66.2 mm
Set height (with stand): 893.6 mm
Set depth (with stand): 316.2 mm
Product weight (+stand): 32.6 kg

