

PHILIPS



Q-Line Display

Signage Solutions

43"

Direct LED Backlight

Ultra HD



43BDL3510Q

Stand out

Easy-setup 18/7 display.

Inform and enthrall with a Philips Q-Line Professional Ultra HD Display. This reliable solution can be up and running as quickly as you need.

Cost-effective system solution

- Energy-saving automatic backlight control
- Integrated media player. Easily schedule USB content
- FailOver ensures content is always playing
- Easy control. Remotely manage networked displays

Effortless setup. Total control.

- Operate, monitor and maintain with CMND & Control
- Schedule what you want, when you want with SmartPlayer

Superb picture. Ultra-high brightness.

- Ultra-HD. Rich images. Stunning contrast

Highlights

CMND & Control




Run your display network over a local (LAN) connection. CMND & Control allows you to perform vital functions like controlling inputs and monitoring display status. Whether you're in charge of one screen or 100.

Integrated media player

Easily schedule content to play from USB. Your Philips Professional Display will wake from standby to play the content you want, and then return to standby once playback is done.

FailOver



From waiting room to meeting room, never show a blank screen. FailOver lets your Philips Professional Display switch automatically between primary and secondary inputs ensuring

content keeps playing even if the primary source goes down. Simply set a list of alternate inputs to be sure your business is always on.

SmartPlayer



Turn your USB into a true cost effective digital signage device. Simply save your content (video, audio, pictures) on your USB and plug into your display. Create your playlist and schedule your content via the on screen menu, and enjoy your own created playlists anytime, anywhere.

Specifications

Picture/Display

Diagonal screen size (metric): 108 cm
 Diagonal screen size (inch): 42.5 inch
 Aspect ratio: 16:9
 Panel resolution: 3840 x 2160
 Pixel pitch: 0.315 x 0.315 mm
 Optimum resolution: 3840 x 2160 @ 60 Hz
 Brightness: 400 cd/m²
 Display colors: 1.07 Billion
 Contrast ratio (typical): 1300:1
 Dynamic contrast ratio: 500,000:1
 Response time (typical): 8 ms
 Viewing angle (horizontal): 178 degree
 Viewing angle (vertical): 178 degree
 Picture enhancement: 3/2 - 2/2 motion pull down, 3D Combfilter, 3D MA deinterlacing, Dynamic contrast enhancement, Motion compens. deinterlacing, Progressive scan
 Panel technology: ADS
 Clinical image: D-Image preset (dicom part 14 compatible)

Connectivity

Audio output: 3.5mm jack
 Video input: DVI-I (x 1), HDMI 2.0 (x2), USB 2.0 (x2)
 Audio input: 3.5 mm jack
 External control: RJ45, RS232C (in/out) 2.5 mm jack, IR (in/out) 3.5 mm jack

Convenience

Placement: Landscape, Portrait
 Tiled Matrix: Up to 15 x 15
 Keyboard control: Lockable, Hidden

Remote control signal: Lockable
 Signal loop through: RS232, IR Loophthrough
 Energy saving functions: Smart Power
 Network controllable: RS232, RJ45
 Start-up: Switch on delay, Switch on status, Boot on source
 Start-up window: enable / disable Philips logo

Sound

Built-in speakers: 2 x 10W RMS

Power

Mains power: 100 - 240V~, 50/60Hz
 Consumption (Typical): 90 W
 Consumption (Max): 150 W
 Standby power consumption: <0.5 W
 Power Saving Features: Smart Power
 Energy Label Class: G

Supported Display Resolution

Computer formats: 1024 x 768, 60, 70, 75Hz, 1152 x 864, 75Hz, 1152 x 870, 75Hz, 1280 x 1024, 60Hz, 1280 x 720, 60Hz, 1280 x 800, 60Hz, 1440 x 900, 60Hz, 1600 x 1200, 60Hz, 1680 x 1050, 60Hz, 1920 x 1080, 60Hz, 640 x 480, 60, 67, 72, 75Hz, 720 x 400, 70Hz, 800 x 600, 56, 60, 72, 75Hz, 832 x 624, 75Hz
 Video formats: 720p, 60Hz, 576p, 50Hz, 576i, 50Hz, 480p, 60Hz, 480i, 60Hz, 1080i, 50, 60Hz, 1080p, 50, 60Hz, 3840 x 2160, 30Hz, 3840 x 2160, 60Hz

Dimensions

Set Width: 973.0 mm
 Product weight: 11.3 kg
 Set Height: 561.2 mm
 Set Depth: 63.5 mm
 Set Width (inch): 38.31 inch
 Set Height (inch): 22.09 inch
 Wall Mount: 200mm x 200mm, M6
 Set Depth (inch): 2.50 inch
 Bezel width: 13.9 mm (Even bezel)
 Product weight (lb): 24.91 lb

Operating conditions

Altitude: 0 ~ 3000 m
 Temperature range (operation): 0 ~ 40 °C
 MTBF: 50,000 hour(s)
 Temperature range (storage): -20 ~ 60 °C
 Humidity range (operation)[RH]: 20 ~ 80% RH (No condensation)
 Humidity range (storage) [RH]: 5 ~ 95% RH (No condensation)

Multimedia Applications

USB Playback Video: H.264, JPEG, MPEG, WMV3
 USB Playback Picture: BMP, JPEG, PNG
 USB Playback Audio: AAC, WMA, HEAAC, MPEG

Accessories

Included accessories: AC Power Cord, RS232 cable, Remote Control, Batteries for remote control, Quick start guide
 Included Accessories: IR sensor cable (1.8 m) (x1), RS232 daisy-chain cable, Philips logo (x1), USB Cover and screw (x2)
 Stand: BM05922(optional)

Miscellaneous

On-Screen Display Languages: English, French, German, Italian, Polish, Russian, Spanish, Turkish, Simplified Chinese, Traditional Chinese, Arabic, Japanese
 Warranty: 3 year warranty
 Regulatory approvals: CE, CB, BSMI, CU, EPA, ETL, FCC, Class A, VCCI

Philips 43BDL3510Q
 Version: 1.0
 Release Date: 2020/03/23

