



#### Q-Line Display

- 43"
- Direct LED Backlight
- Full HD

BDL4330QL/00

## Stand out

Easy-setup 16/7 display.

Inform and enthrall with a Philips Q-Line professional Full HD display. This reliable solution can be up and running as quickly as you need-with no additional hardware.

### Benefits

Brilliant picture. Reliable performance

- Full HD. Clear images. Crisp contrast

Effortless setup. Total control.

- Remote system management through CMND
- Operate, monitor and maintain with CMND & Control
- CMND & Create. Develop and launch your own content

Cost-effective system solution

- Integrated media player. Easily schedule USB content
- Internal memory. Upload content for instant play
- Energy-saving automatic backlight control
- Easy control. Remotely manage networked displays


### Features

#### CMND

Take control of your Philips Professional Display network. CMND lets you manage, update, maintain, and play via one easy-to-use interface. From installation to daily operation.

# PHILIPS

## CMND & Control



Run your display network over a local (LAN) connection. CMND & Control allows you to perform vital functions like controlling inputs and monitoring display status. Whether you're in charge of one screen or 100.

## Integrated media player

Easily schedule content to play from USB. Your Philips Professional Display will wake up and standby to play the content you want, and then return to standby once playback is done.

## Internal memory

Save and play content without the need for a permanent external player. Your Philips professional display has an internal memory, which allows you to upload media into the display for instant playback. The internal memory also functions as a cache for online streaming.

## CMND & Create



Take control of your content with CMND & Create. A drag-and-drop interface makes it simple to publish your own content-whether it's a daily specials board or branded corporate information. Preloaded templates and integrated widgets ensure your stills, text, and video will be up and running in no time.

## Specifications

[field not found 'disclaimer\_text']

### Picture/Display

Diagonal screen size (metric)	108 cm
Diagonal screen size (inch)	42.5 inch
Panel resolution	1920x1080p
Optimum resolution	1920 x 1080 @ 60 Hz
Brightness	350 cd/m <sup>2</sup>
Contrast ratio (typical)	3000:1
Dynamic contrast ratio	500,000:1
Response time (typical)	6.5 ms
Aspect ratio	16:9
Viewing angle (horizontal)	178 degree
Viewing angle (vertical)	178 degree
Pixel pitch	0.49 x 0.49 mm
Display colors	16.7 Million
DICOM	Clinical D-image

### Supported Display Resolution

Computer formats	640 x 480, 60, 67, 72, 75Hz
	800 x 600, 56, 60, 72, 75Hz
	1024 x 768, 60Hz
	1280 x 768, 60Hz
	1280 x 800, 60Hz
	1360 x 768, 60Hz
	1366 x 768, 60Hz
	1440 x 900, 60Hz
	1920 x 1080, 60Hz
	Video formats
	480p, 60Hz
	576p, 50Hz
	576i, 50Hz
	720p, 50, 60Hz
	1080i, 50, 60Hz
	1080p, 50, 60Hz

### Connectivity

Video input	DVI-D HDMI Component (RCA) Composite (RCA) VGA (Analog D-Sub)
Audio input	3.5 mm jack Audio Left/Right (RCA)
Audio output	Audio Left/Right (RCA) 3.5mm jack
External control	RJ45 RS232C (in/out) 2.5 mm jack IR (in/out) 3.5 mm jack
Other connections	USB

### Convenience

Memory	Internal memory access 8GB eMMC Pixel Shift
Screen saving functions	
Energy saving functions	Smart Power
Tiled Matrix	Up to 15 x 15
Start-up	Switch on delay Switch on status Wake up on LAN
Start-up window	enable / disable Philips logo
Keyboard control	Lockable Hidden
Network controllable	RS232 RJ45 One Wire (HDMI-CEC)
Signal loop through	RS232 IR Loophthrough

### Dimensions

Bezel width	11.9 (TLR) / 14.9 (B) mm
Set Width	968.2 mm
Set Height	559.4 mm
Set Depth	59.9 mm
Set Width (inch)	38.12 inch
Set Height (inch)	22.02 inch

Set Depth (inch) 2.36 inch  
Wall Mount 400 x 400mm, 200x200 mm,M6  
Product weight 8.70 kg  
Product weight (lb) 19.18 lb

#### Operating conditions

Temperature range (operation) 5 ~ 40 °C  
Temperature range (storage) -20 ~ 60 °C  
Relative humidity 20 ~ 80 %  
MTBF 50,000 hour(s)

#### Power

Consumption (On mode) 87 W (EnergyStar 6.0 test method)  
Mains power 100 ~ 240 VAC  
Standby power consumption <0.5 W

#### Sound

Built-in speakers 2 x 10W RMS

#### Multimedia Applications

USB Playback Video 3G2  
3GP  
ASF  
ASX  
AVI  
DAT  
F4V  
FLV  
M2TS  
M4V  
MK3D  
MKV  
MOV  
MP4  
MPE  
MPEG  
MPG  
MTS  
QT  
TRP  
TS  
TTS  
VOB  
WEBM  
WMV

USB Playback Picture Xvid  
BMP  
GIF  
JPEG  
JPG  
USB Playback Audio AAC  
AC3  
AIF  
AIFF  
AMR  
EC3  
M4A  
MP3  
OGA  
OGG  
WAV  
WMA

#### Accessories

Included accessories AC Power Cord  
RS232 cable  
VGA cable  
Remote Control  
Batteries for remote control  
User manual on CD-ROM  
Quick start guide

#### Miscellaneous

Warranty 3 year warranty  
On-Screen Display English  
Languages French  
German  
Italian  
Polish  
Russian  
Spanish  
Turkish  
Simplified Chinese  
Traditional Chinese

#### Regulatory approvals

CE  
CCC  
UL/cUL  
C-Tick  
BSMI  
CB  
GOST  
CECP  
EPA



data subject to change  
2023, June 19

Version: 3.1.1  
EAN: 8712581730307

© 2023 Koninklijke Philips N.V.  
All rights reserved.

Specifications are subject to change without notice. Trademarks are the property of Koninklijke Philips N.V. or their respective owners.

[www.philips.com](http://www.philips.com)