

Philips  
LED TV

**81 cm (32")**

HDTV  
DTV

**32PFL1335D**



# Pure Entertainment

## Slim LED TV

Enjoy this Philips DTMB digital TV powered by Digital Crystal Clear for extremely vivid images combined with a minimalist TV design. Take one home for a memorable viewing experience in any room.

### **Brings entertainment to life**

- LED TV for images with incredible contrast
- 100Hz Perfect Motion Rate (PMR) for clear motion sharpness
- Digital Crystal Clear to enhance picture quality
- Two HDMI input for integrated connectivity
- PC Input lets you use your TV as a PC monitor
- USB for multimedia playback
- Hear every word with Clear Sound

# PHILIPS

LED TV  
81 cm (32") HDTV, DTV

# Highlights

## LED TV



With LED backlight you can enjoy low power consumption and beautiful lines combined with high brightness, incredible contrast and vibrant colors. On top of that, LED lighting technology does not contain any hazardous materials, making it a greener choice too.

## 100Hz PMR



For picture movement that looks precise, smooth and natural, Philips created PMR—our standard for measuring moving image sharpness. Perfect Motion Rate is the combined result of our unique video processing, number of frames per second and refresh rate of each frame, perfection in dimming capabilities, and backlighting technology. A higher PMR number contributes

to higher contrast and better motion clarity—which means a superior image for you.

## Digital Crystal Clear

Enjoy extremely clear pictures from any source. This package of picture innovations digitally adjusts and optimizes picture quality to optimal contrast, color and sharpness levels.

## USB (photos, music, video)



Connect your USB memory-stick, digital camera, mp3 player or other multimedia device to the USB port at the side of your TV to enjoy photos, videos and music with the easy to use on screen content browser.

## Clear Sound TV



This innovative audio technology significantly increases the comprehensibility of the voice, whether spoken or sung. It ensures you hear every word, so you can enjoy what you're watching to the fullest.

## PC input

Use your TV as a monitor. Simply connect using an HDMI-DVI cable/converter and you are ready to go.

## Two HDMI input



Avoid cable clutter with a single cable to carry both picture and audio signals from your devices to your TV. HDMI uses uncompressed signals, ensuring the highest quality from source to screen.

DIGITAL  
CRYSTALCLEAR



Clear Sound



32PFL1335D/30

# Specifications

## Picture/Display

- Aspect ratio: 16:9
- Diagonal screen size (inch): 32 inch
- Diagonal screen size (metric): 81 cm
- Display: LED HD TV
- Panel resolution: 1366 x 768p
- Picture enhancement: Digital Crystal Clear, 100 Hz Perfect Motion Rate

## Supported Display Resolution

- Computer inputs: up to 1920x1080 @ 60Hz
- Video inputs: 24, 25, 30, 50, 60 Hz, up to 1920x1080p

## Tuner/Reception/Transmission

- TV system: NTSC, PAL B/G, PAL D/K, PAL I
- Digital TV: DTV
- Video Playback: PAL, SECAM, NTSC

## Multimedia Applications

- Video Playback Formats: Containers: AVI, MKV, H264/MPEG-4 AVC, MPEG-1, MPEG-2, MPEG-4, RealMedia (.rm, .rmvb, RV8-10)
- Music Playback Formats: MP3
- Picture Playback Formats: JPEG

## User Interaction

- Ease of Use: One-stop Home button
- Screen Format Adjustments: 4:3, Movie expand 16:9, Widescreen, Zoom 1

## Sound

- Output power (RMS): 20W
- Sound Enhancement: Auto Volume Leveler, Clear Sound, Treble and Bass Control

## Connectivity

- Number of AV connections: 2
- Number of HDMI connections: 2
- Number of component in (YPbPr): 1
- Number of USBs: 2
- Other connections: Antenna IEC75, Composite video (CVBS) out, Analog audio Left/Right out, PC-in VGA + Audio L/R in, Digital audio out (coaxial), Headphone out

## Power

- Mains power: AC 220 - 240 V 50/60Hz
- Ambient temperature: 5 °C to 40 °C
- Power consumption: 55 W
- Standby power consumption: <math>\leq</math> 0.5 W

## Accessories

- Included accessories: Remote Control, 2 x AAA Batteries, Table top stand, Quick start guide, User Manual

## Dimensions

- Set Width: 739 mm
- Set Height: 452 mm
- Set Depth: 68 mm
- Product weight: 6.6 kg
- Set width (with stand): 739 mm
- Set height (with stand): 492 mm
- Set depth (with stand): 220 mm
- Product weight (+stand): 7 kg
- Box width: 930 mm
- Box height: 547 mm
- Box depth: 160 mm
- Weight incl. Packaging: 9 kg
- Compatible wall mount: 100 x 100mm



Issue date 2023-10-05

Version: 2.3.1

EAN: 87 12581 71917 3

© 2023 Koninklijke Philips N.V.  
All Rights reserved.

Specifications are subject to change without notice.  
Trademarks are the property of Koninklijke Philips N.V.  
or their respective owners.

[www.philips.com](http://www.philips.com)