

Philips E-Line Display

46'' Edge LED Backlight Full HD

BDL4650EL

Deliver your marketing messages in style

with this sleek LED display

Maximising your content delivery whilst lowering your TCO has never been so easy or stunning. This 46" display offers gorgeous full HD picture quality with lower power consumption thanks to the edge LED backlight.

- Optimized for public viewing
- Full HD LCD display, 1920x1080p
- Lower total cost of ownership
- SmartPower for energy saving

Operational flexibility

- Edge LED Backlight
- Portrait mode operability
- Smart Control Software Suite
- Smart insert in the backcover to place a small pc
- Keep your content up and running with FailOver
- IR Passthrough
- Enhanced zoom feature supports tiled matrix applications
- Display Port for faster graphics support
- Remote Management and Configuration via RS232
- Designed for 24/7 operation



Highlights

Edge LED Backlight

Experience an even dispersion of light with cutting edge LED technology. White LED's (light emitting diodes) are positioned around the rim of the panel to give a more even spread of light. This results in even lower power consumption, less heat to dissipate, and a true, uniform color range.

Smart Control

Control and manage all of the signage displays on your network with this powerful software tool which allows you to change the settings of your display centrally via an RJ45 or RS232 connection. Smart Control allows you to set the video input, modify the color settings, set the display's ID when creating video walls and even diagnose each display's status, giving you all the power you need to manage your displays from one central location.

Smart Insert

Professional PC's are part of most public signage installations. Quite often they increase the overall depth to the display and cause a lot of cable clutter. So we have designed this display with Smart insert in the back cover which is ideal for the integration of a professional small form factor PC. On top of that, the cable management system offers a great solution to keep your cables neat and professional looking.

SmartPower

The backlight intensity can be controlled and pre-set by the system to reduce the power consumption by up to 50%, which saves substantially on energy costs.

FailOver

Keeping your content up and running is critical for demanding commercial applications. While it is unlikely you will face a content disaster, FailOver provides content protection with a revolutionary technology that plays back-up content on screen in the event of a media player failure. FailOver automatically kicks in when the primary input fails. Simply select a primary input connection and a FailOver connection and your ready for instant protection.

BDL4650EL/00

Zoom function for tiled matrix

The internal zoom function enables easy implementation of a video wall matrix, without the need for expensive external equipment. Capable of many different configurations, creating a stunning video wall has become simplicity itself.

IR Passthrough

Control all displays in your signage network through one single remote control, via the primary display. Simple and convenient, this means you don't have to worry about other displays changing configuration settings when using your remote control unit.

Display Port

Enjoy crystal clear images with the highbandwidth graphics support of the Display Port. As well as transmitting full high-definition video the Display Port will also transmit audio, thus eliminating the need for extra cables.













✓ SmartPower







Specifications

Picture/Display

- Diagonal screen size: 46 inch / 117 cm
- Panel resolution: 1920x1080p
- Optimum resolution: 1920 x 1080 @ 60Hz
- Brightness: 500 cd/m²
- Contrast ratio (typical): 4000:1
- Aspect ratio: 16:9
- Response time (typical): 6.5 ms
- Pixel pitch: 0.17675 x 0.53025 mm
- Display colors: 1.07 billion
- Viewing angle (H / V): 178 / 178 degree
- Picture enhancement: 3/2 2/2 motion pull down, 3D Combfilter, Motion compens. deinterlacing, 3D MA deinterlacing, Dynamic contrast enhancement

Connectivity

- PC: RJ45, VGA-in D-Sub 15HD, VGA-out (via DVI-I), RS232 D-Sub9, RS232 D-sub9 output, 3.5 mm PC audio input x1
- AV input: DVI-D x1, Component (BNC) x1, Composite (BNC) x1
- Other connections: Display Port, DVI Out, HDMI, AC-out, IR out, External loudspeaker connector • AV output: Audio (L/R) x1

Supported Display Resolution

| Computer formats | |
|--------------------------------------|------------------|
| Resolution | Refresh rate |
| 1920 x 1200 | 60Hz |
| 1920 x 1080 | 60Hz |
| 1600 x 1200 | 60Hz |
| 1440 x 900 | 60Hz |
| 1366 x 768 | 60Hz |
| 1360 x 768 | 60Hz |
| 1280 x 1024 | 60Hz |
| 1280 x 800 | 60Hz |
| 1280 x 768 | 60Hz |
| 1024 x 768 | 60Hz |
| 800 x 600 | 60, 72, 75Hz |
| 640 x 480 | 60, 67, 72, 75Hz |
| Video formats | |
| Resolution | Refresh rate |
| 480i | 60Hz |
| 480p | 60Hz |
| 576p | 50Hz |
| 576i | 50Hz |
| 720p | 50, 60Hz |
| 1080i | 50, 60Hz |
| 1080p | 50, 60Hz |
| | |

Dimensions

• Set dimensions (W x H x D):

- 1052.7 x 607.3 x 69 mm
- · Bezel width: 15.8 mm
- Product weight: 22 kg
- VESA Mount: 400 x 400 mm, 400 x 200 mm, 200 x 200 mm
- Smart Insert mount: 100 x 100 mm, 100 x 200 mm

Convenience

- Signal loop through: DVI, VGA, RS232, IR
- Loopthrough
- Network controllable: RJ45, RS232, HDMI (One Wire)
- Placement: Landscape, Portrait
- Picture in picture: PBP, PIP, POP
- · Energy saving functions: Smart Power
- Ease of installation: Smart Insert, AC Out
- Keyboard control: Hidden, Lockable
- · Other convenience: Carrying handles
- Packaging: Reusable box
- Tiled Matrix: Up to 5 x 5

Power

- Consumption (On mode): 66.89 W (EnergyStar
 - 6.0 test method)
- Standby power consumption: <0.5W
- Mains power: 100 ~ 240 VAC, 50 ~ 60 Hz

Sound

• Built-in speakers: 2 x 10 W RMS

Operating conditions

- Temperature range (operation): 0 ~ 40 °C
- Temperature range (storage): -20 ~ 60 °C
- Relative humidity: 20 ~ 80 %
- Altitude: 0 ~ 3000 m
- MTBF: 60,000 hour(s)

Accessories

- Included accessories: Remote Control, Batteries for remote control, AC Power Cord, VGA cable, User manual on CD-ROM, Quick start guide
- Stand: BM05462 (Optional)

Miscellaneous

- On-Screen Display Languages: English, French, German, Spanish, Polish, Turkish, Russian, Simplified Chinese, Italian
- Regulatory approvals: CE, FCC, Class B, UL/cUL,
- CCC, C-Tick, RoHS, GOST
- Warranty: 3 year warranty



Issue date 2022-05-18 © 2022 Koninklijke Philips N.V. All Rights reserved. Version: 5.3.1 Specifications are subject to change without notice. Trademarks are the property of Koninklijke Philips N.V. or their respective owners. 12 NC: 8670 000 90644 www.philips.com

EAN: 87 12581 64632 5

DL4650EL/00