



Curved LCD monitor with Ultra Wide-Color

- E Line
- 27" (68.6 cm)
- 1920 x 1080 (Full HD)

278E8QJAW/69

Ultra-curved, ultra-colorful

Colors like you've never seen before. This brilliant wide view display with Ultra Wide-Color offers the richest and most vivid colors wrapped in an immersive curved design for a your best creations yet.

Benefits

Curved design inspired by the world around us

- Curved display design for more immersive experience

Superb Picture Quality

- Ultra Wide-Color wider range of colors for a vivid picture
- VA display delivers awesome images with wide viewing angles
- 16:9 Full HD display for crisp detailed images
- Less eye fatigue with Flicker-free technology
- SmartImage Lite for easy optimized image settings
- SmartContrast for deep black level details

Elegant Design

- Elegant, slim design complements your home decor

Features designed for you

- Built-in stereo speakers for multimedia
- DisplayPort connection for maximum visuals
- HDMI-ready for Full HD entertainment

PHILIPS

Features

Curved display design



Desktop monitors offer a personal user experience, which suits a curve design very well. The curved screen provides a pleasant yet subtle immersion effect, which focuses on you at the center of your desk.

Ultra Wide-Color Technology



Ultra Wide-Color Technology delivers a wider spectrum of colors for a more brilliant picture. Ultra Wide-Color wider "color gamut" produces more natural-looking greens, vivid reds and deeper blues. Bring media entertainment, images, and even productivity more alive and vivid colors from Ultra Wide-Color Technology.

VA display



Philips VA LED display uses an advanced multi-domain vertical alignment technology which gives you super-high static contrast ratios for extra vivid and bright images. While standard office applications are handled with ease, it is especially suitable for photos, web-browsing, movies, gaming, and demanding graphical applications. It's optimized pixel management technology gives you 178/178 degree extra wide viewing angle, resulting in crisp images.

16:9 Full HD display



Picture quality matters. Regular displays deliver quality, but you expect more. This display features enhanced Full HD 1920 x 1080 resolution. With Full HD for crisp detail paired with high brightness, incredible contrast and realistic colors expect a true to life picture.

Flicker-free technology



Due to the way brightness is controlled on LED-backlit screens, some users experience flicker on their screen which causes eye fatigue. Philips Flicker-free Technology applies a new solution to regulate brightness and reduce flicker for more comfortable viewing.

SmartImage Lite

SmartImage Lite is an exclusive, leading edge Philips technology that analyzes the content displayed on your screen. Based on a scenario you select, SmartImage Lite dynamically enhances the contrast, color saturation and sharpness of images and videos for ultimate display performance - all in real time with the press on a single button.

SmartContrast



SmartContrast is a Philips technology that analyzes the contents you are displaying, automatically adjusting colors and controlling backlight intensity to dynamically enhance contrast for the best digital images and videos or when playing games where dark hues are displayed. When Economy mode is selected, contrast is adjusted and backlighting fine-tuned for just-right display of everyday office applications and lower power consumption.

Built-in stereo speakers

A pair of high quality stereo speakers built into a display device. It can be visible front firing, or invisible down firing, top firing, rear firing, etc depending on model and design.

DisplayPort connection



DisplayPort is a digital link from PC to Monitor without any conversion. With higher capabilities than DVI standard, it is fully capable to support up to 15meter cables and 10.8 Gbps/sec data transfer. With this high performance and zero latency, you get the fastest imaging and refresh rates - making DisplayPort the best choice for not only general office or home use, but also for the demanding gaming and movies, video editing and more. It also keeps interoperability in mind via use of various adapters.

HDMI Ready



An HDMI-ready device has all the required hardware to accept High-Definition Multimedia Interface (HDMI) input. A HDMI cable enables high-quality digital video and audio all transmitted over a single cable from a PC or any number of AV sources (including set-top boxes, DVD players, A/V receivers and video cameras).

Specifications

[field not found 'disclaimer_text']

Picture/Display

LCD panel type	VA LCD
AMD FreeSync™ technology	Yes
Backlight type	W-LED system
Panel Size	27 inch / 68.6 cm
Effective viewing area	597.9 (H) x 336.3 (V) - at a 1800 R curvature*
Aspect ratio	16:9
Maximum resolution	1920 x 1080 @ 75 Hz*
Response time (typical)	4 ms (Gray to Gray)*
Brightness	250 cd/m²
Contrast ratio (typical)	3000:1
SmartContrast	20,000,000:1
Pixel pitch	0.311 x 0.311 mm
Viewing angle	178° (H) / 178° (V) @ C/R > 10
Flicker-free	Yes
Picture enhancement	SmartImage Lite
Color gamut (typical)	NTSC 104%*, sRGB 130%*
Display colors	16.7 M
Scanning Frequency	54 - 84 kHz (H) / 49 - 75 Hz (V)
sRGB	Yes

Connectivity

Signal Input	VGA (Analog) DisplayPort x 1 HDMI (digital, HDCP)
Sync Input	Separate Sync Sync on Green
Audio (In/Out)	PC audio-in Headphone out

Convenience

Built-in Speakers	3 W x 2
User convenience	Power On/Off Menu Volume Input
OSD Languages	SmartImage lite Brazil Portuguese Czech Dutch English Finnish French German Greek Hungarian Italian Japanese Korean Polish Portuguese Russian Simplified Chinese

Other convenience	Spanish Swedish Traditional Chinese Turkish Ukrainian
Plug & Play Compatibility	Kensington lock DDC/CI Mac OS X sRGB Windows 10 / 8.1 / 8 / 7

Stand

Tilt	-5/20 degree
------	--------------

Power

On mode	31.8 W (typ.)
Standby mode	0.5 W
Off mode	0.5 W
Power LED indicator	Operation - White Standby mode- White (blinking)
Power supply	100-240VAC, 50-60Hz External

Dimensions

Product with stand (mm)	620 x 470 x 189 mm
Product without stand (mm)	620 x 365 x 68 mm
Packaging in mm (WxHxD)	730 x 539 x 186 mm

Weight

Product with stand (kg)	4.80 kg
Product without stand (kg)	4.57 kg
Product with packaging (kg)	7.02 kg

Operating conditions

Temperature range (operation)	0 to 40 °C
Temperature range (storage)	-20 to 60 °C
Relative humidity	20%-80 %
Altitude	Operation: +12,000ft (3,658m), Non-operation: +40,000ft (12,192m)
MTBF	50,000 hrs (excluding backlight) hour(s)

Sustainability

Environmental and energy	RoHS Lead-free Mercury Free
Recyclable packaging material	100 %

Compliance and standards

Regulatory Approvals CE Mark
FCC Class B
CECP
TUV/ISO9241-307
CU-EAC

Cabinet

Color
Finish

cETLus

White
Glossy

- * Radius of the arc of the display curvature in mm
- * The maximum resolution works for either HDMI input or DP input.
- * Response time value equal to SmartResponse
- * NTSC Area based on CIE1976
- * sRGB Area based on CIE 1931



data subject to change
2020, October 30

Version: 7.0.1
EAN: 8712581743192

© 2020 Koninklijke Philips N.V.
All rights reserved.

Specifications are subject to change without notice. Trademarks are the property of Koninklijke Philips N.V. or their respective owners.

www.philips.com