

Philips LCD monitor with SmartControl Lite

V Line

21 (Viewable 20.7"/52.6 cm)

216V6LSB2

Great LED images in vivid colours

Enjoy vivid LED pictures on this Philips display. Equipped with SmartControl Lite, it's a great choice!

Vivid pictures every time

- LED technology for vivid colours
- SmartContrast for rich black details
- 16:9 Full HD display for crisp, detailed images
- Easy display performance tuning with SmartControl Lite

Great choice

- Compact design saves space
- · Mercury Free eco-friendly display
- VESA mount allows for flexibility



Highlights

LED technology

Specifications

Picture/Display

- LCD panel type: TFT-LCD
- Backlight type: W-LED system
- Panel Size: 20.7 inch/52.6 cm
- Effective viewing area: 457.92 (H) x 257.58 (V)
- Aspect ratio: 16:9
- Optimum resolution: 1920 x 1080 @ 60 Hz
- Response time (typical): 5 ms
- Brightness: 200 cd/m²
- SmartContrast: 10,000,000:1
- Contrast ratio (typical): 600:1
- Pixel pitch: 0.2385 x 0.2385 mm
- Viewing angle: 90° (H)/65° (V), @ C/R > 10
- Display colours: 16.7 M
- Scanning Frequency: 30–83 kHz (H)/56–76 Hz (V)
- sRGB

Connectivity

- Signal Input: VGA (Analogue)
- Sync Input: Separate Sync, Sync on Green

Convenience

- User convenience: Power On/Off, Menu/OK, Brightness/Back, 4:3 Wide/Up, Auto/Down
- OSD Languages: Brazil Portuguese, Czech, Dutch, English, Finnish, French, German, Greek, Hungarian, Italian, Japanese, Korean, Polish, Portuguese, Russian, Simplified Chinese, Spanish, Swedish, Traditional Chinese, Turkish, Ukrainian
- · Other convenience: Kensington lock, VESA mount $(100 \times 100 \text{ mm})$
- Plug and Play Compatibility: DDC/CI, Mac OS X, sRGB, Windows 7, Windows 8

Stand

• Tilt: -5/20 degree

• On mode: 27.03 W (typ.), 29.65 W (max.)

















• Standby mode: 0.5 W (typ.)

- Off mode: 0.5 W (typ.)
- · Power LED indicator: Operation White, Standby mode - White (flashing)
- Power supply: Built-in, 100–240 VAC, 50–60 Hz

Dimensions

- Product with stand (mm): $488 \times 365 \times 200$ mm
- Product without stand (mm): 488 x 295 x 39 mm
- Packaging in mm (W \times H \times D): 560 \times 427 \times 110 mm

Weight

- · Product with stand (kg): 2.10 kg
- Product without stand (kg): 1.82 kg
- Product with packaging (kg): 3.27 kg

Operating conditions

- Temperature range (operation): 0°C to 40°C °C
- Temperature range (storage): -20°C to 60°C °C
- Relative humidity: 20-80% %
- Altitude: Operation: +12,000 ft (3658 m), Nonoperation: +40,000 ft (12,192 m)
- MTBF: 50 000 (Excluding backlight) hour(s)

Sustainability

- Environmental and energy: RoHS, Lead-free, Mercury Free
- Recyclable packaging material: 100 %

Compliance and standards

 Regulatory Approvals: CEL, CE Mark, FCC Class B, CU, SEMKO, BSMI, cETLus, TUV/ISO9241-307, CB, WEEE

Cabinet

- · Colour: Black
- Finish: Glossy / textured

SmartControl Lite

SmartControl Lite is the next generation 3D iconbased GUI monitor control software. This allows the user to fine-tune most parameters of the monitor like Colour, Brightness, screen calibration, Multimedia, ID management etc. with the mouse.

White LED's are solid state devices which light up to

full, consistent brightness faster saving startup time.

LED's are free from mercury content, which allows

for eco-friendly recycling and disposal process. LED's

backlight, resulting in a super high contrast ratio. It

also gives superior colour reproduction thanks to

allow for better dimming control of the LCD

consistent brightness across the screen.

SmartContrast



SmartContrast is a Philips technology that analyses the contents you are displaying, automatically adjusting colours and controlling backlight intensity to dynamically enhance contrast for the best digital images and videos or when playing games where dark hues are displayed. When Economy mode is selected, contrast is adjusted and backlighting finetuned for just-right display of everyday office applications and lower power consumption.

16:9 Full HD display



Picture quality matters. Regular displays deliver quality, but you expect more. This display features enhanced Full HD 1920×1080 resolution. With Full HD for crisp detail paired with high brightness, incredible contrast and realistic colours, expect a true-to-life picture.

Mercury Free

Philips monitors with LED backlighting are free from Mercury, one of the most toxic natural substances, which affects humans and animals. This reduces the environmental impact of the display throughout its lifecycle, from manufacturing to disposal.



Issue date 2019-11-29

Version: 3.0.1

© 2019 Koninklijke Philips N.V. All Rights reserved.

Specifications are subject to change without notice. Trademarks are the property of Koninklijke Philips N.V. or their respective owners.

12 NC: 8670 001 25955 EAN: 87 12581 73372 8

www.philips.com