

Philips Modea
mirror TV

76 cm (30")
LCD

30HM9202



Mirror TV Multimedia Display

with latest high definition LCD display

An elegantly designed TV that you can hang on the wall is now a reality. When off, it's a mirror; when on it delivers best-in-class picture quality for your home or hotel entertainment set-up.

Superb sound reproduction

- Virtual Dolby Surround for a cinema-like audio experience
- Unique new slim speakers deliver better stereo performance.

Breathtaking natural pictures

- High-definition LCD WXGA display, 1280 x 768p
- Digital Crystal Clear provides vivid cinema-like images
- Digital Natural Motion for smooth moving images

Slim, stylish design to complement your interior

- Unique Miravision technology
- Compact and slim design that fits in every room

PHILIPS

Specifications

Picture/Display

- Aspect ratio: 15:9
- Diagonal screen size (inch): 30 inch
- Diagonal screen size (metric): 76 cm
- Panel resolution: 1280 x 768p
- Brightness: 450 cd/m²
- Picture enhancement: Digital Crystal Clear, Progressive scan, Comb Filter Digital, Active Control + Light sensor, 3/2 - 2/2 motion pull down, Widescreen Plus
- Contrast ratio (typical): 350:1
- Display screen type: LCD WXGA Active Matrix TFT
- Response time (typical): 12 ms
- Viewing angle (horizontal): 176 degree
- Screen enhancement: Anti ageing circuit, Anti-Reflection coated screen

Supported Display Resolution

- Computer formats: 640 x 480, 60, 67, 72, 75Hz, 800 x 600, 56, 60, 72, 75Hz, 1024 x 768, 60, 70, 75Hz
- Video Formats: 640 x 480p - 2Fh

Tuner/Reception/Transmission

- Aerial Input: 75 ohm coaxial (IEC75)
- Tuner bands: Hyperband, S-Channel, UHF, VHF
- TV system: PAL, SECAM
- Video Playback: NTSC, PAL, SECAM

Convenience

- Ease of Installation: Auto Volume Leveler, Autostore, PLL Digital Tuning, Plug & Play
- Ease of Use: On Screen Display, Smart Picture

- Screen Format Adjustments: 6 Widescreen Modes, Auto Format, Subtitle and Heading Shift
- Remote Control: Multi-functional
- Remote control type: SIN type number tbc
- Teletext: 10 page Smart Text
- Picture in Picture: Twin page text

Sound

- Output power (RMS): 2 x 15W
- Sound System: Virtual Dolby Surround
- Sound Enhancement: Smart Sound

Loudspeakers

- Built-in speakers: 2

Connectivity

- Ext 1 Scart: CVBS in/out, RGB
- Ext 2 Scart: CVBS in/out, Y/C
- Other connections: Analog audio Left/Right out, Antenna IEC75, PC-in VGA + Audio L/R in

Power

- Mains power: AC 220 - 240 V +/- 10%
- Ambient temperature: 5 °C to 40 °C
- Power consumption: 185 W
- Standby power consumption: < 3 W

Accessories

- Included accessories: Wall mounting bracket

Dimensions

- Product weight: 25 kg
- Weight incl. Packaging: 30 kg

Highlights

Miravision

By utilising a proprietary polarizing cover a decorative mirror that turns into a full featured flat TV when switched on. Unique and Stylish.

Compact and slim design

This design style emphasizes a slim, compact look that saves space and fits in anywhere.

LCD WXGA display, 1280 x 768p

This WXGA display with state-of-the-art LCD screen technology gives you HD resolution of 1280 x 768p pixels. It produces brilliant flicker-free progressive scan pictures with optimum brightness and superb colors. This vibrant and sharp image will provide you with an enhanced viewing experience.

Digital Crystal Clear

Digital Crystal Clear is a package of picture innovations that digitally adjusts and optimizes picture quality to optimal contrast, color and sharpness levels. It's like watching vivid cinema-like images.

Digital Natural Motion

Philips invented Digital Natural Motion to eliminate juddering effects that are visible with moving picture content. Digital Natural Motion estimates motion in the picture and corrects juddering movements in both broadcast and recorded movie material (such as DVD). The resulting smooth motion reproduction and excellent sharpness take the viewing experience to a higher level.

Virtual Dolby Surround

Virtual Dolby Surround is a processing technology for enhancing surround sound effects. It will create the sensation of Dolby Pro Logic without the necessity of additional rear speakers. You become totally immersed in your television experience.

Unique new slim speakers

Enjoy improved balanced sound and stereo performance like you've never heard before. The slim speakers use patented technology featuring a hi-fi like magnet system and unique speaker cones.

