

Philips LCD monitor with SmartControl Lite

V Line 18.5" / 47 cm

193V5LHSB2

Great LED images in vivid colors

Enjoy vivid LED pictures on this Philips display. Equipped with HDMI and SmartControl lite, it's a great choice!

Vivid pictures every time

- LED technology for vivid colors
- Easy display performance tuning with SmartControl Lite

Experience multimedia

• HDMI-ready for Full HD entertainment

Great choice

- Compact design saves space
- Mercury Free eco-friendly display
- VESA mount allows for flexibility



Specifications

Picture/Display

- LCD panel type: TFT-LCD
- Backlight type: W-LED system
- Panel Size: 18.5 inch / 47 cm
- Effective viewing area: 409.8 (H) x 230.4 (V)
- Aspect ratio: 16:9
- Optimum resolution: 1366 x 768 @ 60 Hz
- Response time (typical): 5 ms
- Brightness: 200 cd/m²
- Contrast ratio (typical): 700:1
- Pixel pitch: 0.30x 0.30 mm
- Viewing angle: 90° (H) / 65° (V), @ C/R > 10
- Display colors: 16.7 M • Scanning Frequency: 30 -83 kHz (H) / 56 -76 Hz (V) sRGB
- Connectivity
- Signal Input: VGA (Analog), HDMI (digital, HDCP)
- Sync Input: Separate Sync, Sync on Green

Convenience

- User convenience: Power On/Off
- OSD Languages: Brazil Portuguese, Czech, Dutch, English, Finnish, French, German, Greek, Hungarian, Italian, Japanese, Korean, Polish, Portuguese, Russian, Simplified Chinese, Spanish, Swedish, Traditional Chinese, Turkish, Ukranian
- Other convenience: Kensington lock, VESA mount (100x100mm)
- Plug & Play Compatibility: DDC/Cl, Mac OS X, sRGB, Windows 7, Windows 8

Stand

• Tilt: -3/10 degree

Power

• On mode: 15.24 W (typ.), 17.65 W (max.)



31-	НЭ
	HIGH-DEFINITION MULTIN
-t Control ^{lite}	

ноп
HIGH-DEFINITION MULTIMEDIA



• Standby mode: 0.5 W (typ.)

- Off mode: 0.5 W (typ.)
- · Power LED indicator: Operation White, Standby mode- White (blinking)
- Power supply: Built-in, 100-240VAC, 50-60Hz

Dimensions

- Product with stand (mm): 437 x 338 x 170 mm
- Product without stand (mm): 437 x 273 x 48 mm
- Packaging in mm (WxHxD): 481 x 350 x 103 mm

Weight

- Product with stand (kg): 2.15 kg
- Product without stand (kg): 1.94 kg
- Product with packaging (kg): 3.00 kg

Operating conditions

- Temperature range (operation): 0°C to 40°C °C
- Temperature range (storage): -20°C to 60°C °C
- Relative humidity: 20%-80 %
- Altitude: Operation: +12,000ft (3,658m), Nonoperation: +40,000ft (12,192m)
- MTBF: 30,000 hour(s)
- · Environmental and energy: EPEAT Silver, RoHS, Lead-free, Mercury Free
- Recyclable packaging material: 100 %

Compliance and standards

• Regulatory Approvals: CE Mark, FCC Class B, EAC, SEMKO, BSMI, cETLus, TUV/ISO9241-307

Cabinet Color: Black

• Finish: Hairline (front bezel) / Texture (rear cover)



Highlights

LED technology

White LED's are solid state devices which light up to full, consistent brightness faster saving startup time. LED's are free from mercury content which allows for eco-friendly recycling and disposal process. LED's allow for better dimming control of LCD backlight, resulting in super high contrast ratio. It also gives superior color reproduction thanks to consistent brightness across the screen.

SmartControl Lite

SmartControl Lite is the next generation 3D icon based GUI monitor control software. This allows user to fine-tune most parameters of the monitor like Color, Brightness, screen calibration, Multimedia, ID management, etc with the mouse.

HDMI Ready



HDMI-read

An HDMI-ready device has all the required hardware to accept High-Definition Multimedia Interface (HDMI) input. A HDMI cable enables high-quality digital video and audio all transmitted over a single cable from a PC or any number of AV sources (including set-top boxes, DVD players, A/V receivers and video cameras).

Mercury Free

Philips monitors with LED backlighting are free of Mercury content, one of the most toxic natural substances, which affects humans and animals. This reduces the environmental impact of the display throughout its life-cycle, from manufacturing to disposal.



Issue date 2016-07-04

© 2016 Koninklijke Philips N.V. All Rights reserved.

Version: 2.0.1

Specifications are subject to change without notice. Trademarks are the property of Koninklijke Philips N.V. or their respective owners.

12 NC: 8670 001 37627 EAN: 87 12581 73988 1

www.philips.com

Sustainability