

PHILIPS

EVNIA

4K UHD gaming
monitor

Gaming Monitor

Evnia 5000

32 (31.5" / 80 cm diag.)

3840 x 2160 (4K UHD)

32M1N5800A



Feel your game

This Philips gaming monitor brings games to life with its 4K IPS display and DisplayHDR 400. Rapid 144Hz refresh rate, 1ms response time and Sync technology guarantee smooth visuals.

Features designed for you

- MultiView enables simultaneous dual connection and view
- 1ms (MPRT) fast response for crisp image and smooth gameplay
- SIAA certified antibacterial treatment to keep sanitary

Best synchronization between GPU and monitor

- AMD FreeSync™ Premium; tear free, stutter free, fluid gaming
- Certified NVIDIA® G-SYNC® compatible for smooth fast gaming

Meet the most recent update of HDMI specification

- Low input lag reduces time delay between devices to monitor
- 144Hz refresh rates for ultra-smooth, brilliant images
- SmartImage HDR gives optimal viewing from your HDR content
- UltraClear 4K UHD (3840x2160) resolution for precision

Immersive visuals

- IPS LED wide view technology for image and color accuracy
- Ultra Wide-Color wider range of colors for a vivid picture

Gaming Monitor

4K UHD gaming monitor

32M1N5800A/75

Highlights

AMD FreeSync™ Premium



Gaming shouldn't be a choice between choppy gameplay or broken frames. AMD FreeSync™ Premium equips serious gamers with a fluid, tear-free gameplay experience at peak performance. There are no compromises, game confidently with a high refresh rate, low framerate compensation, and low latency.

NVIDIA® G-SYNC® compatible



When playing intense games with high refresh rates, screen tearing may appear without optimal graphics synchronization. This Philips display is certified as NVIDIA® G-SYNC® compatible, reducing screen tearing and syncing your monitor's refresh rate with your graphic card's output for a smoother gaming experience. Scenes appear instantly, objects look sharper, and gameplay is smooth, giving you a stunning visual experience and a serious competitive edge.

UltraClear 4K UHD resolution



These Philips displays utilize high performance panels to deliver UltraClear, 4K UHD (3840 x 2160) resolution images. Whether you are


demanding professional requiring extremely detailed images for CAD solutions, using 3D graphics applications or a financial wizard working on huge spreadsheets, Philips displays will make your images and graphics come alive.

144Hz Gaming



You play intense, competitive gaming. You demand display with lag free, ultra-smooth images. This Philips display redraws the screen image up-to 144 times per second, effectively 2.4x faster than a standard display. A lower frame rate can make enemies appear to jump from spot to spot on the screen, making them difficult targets to hit. With 144Hz frame rate, you get those critical missing images on the screen which shows enemy movement in ultra-smooth motion so you can easily target them. With ultra-low input lag and no screen tearing, this Philips display is your perfect gaming partner

1ms MPRT fast response



MPRT (motion picture response time) is more intuitive way to describe the response time, which directly refers the duration from seeing blurry noise to clean and crisp images. Philips gaming monitor with 1 ms MPRT effectively eliminates smearing and motion blur, delivers shaper and precise visuals to enhance gaming experience. Best choice for playing thrilling and twitch-sensitive games.

Low Input Lag



Input lag is the amount of time that elapses between performing an action with connected devices and seeing the result on screen. Low input lag reduces the time delay between entering a command from your devices to monitor, greatly improve on playing twitch-sensitive video games, particularly important to whom plays fast-paced, competitive games.

SmartImage HDR



Select one of SmartImage HDR modes to best suit your needs. HDR Game: Optimize for playing video games. With brighter white and darker black, the gaming scene is vivid and revealing more details, easily spot enemies hiding in the dark corner and shadows. HDR Movie: Ideal for watching HDR movie. Deliver better contrast and brightness for more realistic and immerse viewing experience. HDR Photo: Enhance red, green, and blue for lively visuals. DisplayHDR: VESA DisplayHDR certified*. Personal: Customize settings in picture menu. *Please refer to specification for HDR grade.

AMD
FreeSync
Premium

NVIDIA
G-SYNC

144Hz

1ms
Fast Response
1ms MPRT

Low Input Lag

SIAA
ISO 22196
Anti Bacteria

Ultra Wide Color

IPS
Wide Viewing
Angle

Gaming Monitor

4K UHD gaming monitor

32M1N5800A/75


Highlights

Antibacterial-treated surface



Bacteria are often transferred by touching infected surfaces. Philips introduces antibacterial agents with ionic silver treatment on monitor surface to inhibit bacterial growth and reduce bacterial adhesion on constant touch part, to keep the surface clean and reduce bacteria spread.

MultiView technology



With the ultra-high resolution Philips MultiView display you can now experience a world of connectivity. MultiView enables active dual connect and view so that you can work with multiple devices like a PC and notebook simultaneously, for complex multi-tasking.

Ultra Wide-Color Technology



Ultra Wide-Color Technology delivers a wider spectrum of colors for a more brilliant picture. Ultra Wide-Color wider "color gamut" produces

more natural-looking greens, vivid reds and deeper blues. Bring, media entertainment, images, and even productivity more alive and vivid colors from Ultra Wide-Color Technology.

IPS technology



IPS displays use an advanced technology which gives you extra wide viewing angles of 178/178 degree, making it possible to view the display from almost any angle. Unlike standard TN panels, IPS displays gives you remarkably crisp images with vivid colors, making it ideal not only for Photos, movies and web browsing, but also for professional applications which demand color accuracy and consistent brightness at all times.

Specifications

Picture/Display

Panel Size: 31.5 inch / 80 cm
Aspect ratio: 16:9
LCD panel type: IPS technology
Backlight type: W-LED system
Pixel pitch: 0.181 x 0.181 mm
Brightness: 500 cd/m²
Display colors: Color support 1.07 billion colors
Color gamut (typical): NTSC 113%*, sRGB 124%*, Adobe RGB 87.5%*
Contrast ratio (typical): 1000:1
SmartContrast: Mega Infinity DCR
Response time (typical): 1 ms (Gray to Gray)*
Viewing angle: 178° (H) / 178° (V), @ C/R > 10
Picture enhancement: SmartImage game
Maximum resolution: 3840 x 2160 @ 144 Hz
Effective viewing area: 697.344 (H) x 392.2344 (V)
Scanning Frequency: 30 - 255 kHz (H) / 48 - 144 Hz (V)
sRGB
Delta E: < 2 (sRGB)
Flicker-free
Pixel Density: 139.87 PPI
LowBlue Mode
Display Screen Coating: Anti-Glare, 3H, Haze 25%
SmartUniformity: 93 ~ 105%
MPRT: 1 ms
Low Input Lag
EasyRead
AMD FreeSync™ technology: Premium
G-SYNC: Compatible (DP)*
HDR: DisplayHDR 400 certified

Connectivity

Signal Input: HDMI 2.1 x 2, DisplayPort 1.4 x 2
Sync Input: Separate Sync
Audio (In/Out): Audio out
USB: USB-B x 1 (upstream), USB 3.2 Gen 1 x 4 (downstream with 2 fast charge B.C 1.2)
HDCP: HDCP 1.4 (HDMI / DP); HDCP 2.2 (HDMI / DP)

Convenience

Built-in Speakers: 5 W x 2
Plug & Play Compatibility: DDC/CI, Mac OS X, sRGB, Windows 10 / 8.1 / 8 / 7
User convenience: Power On/Off, Menu/OK, Input/Up, Game Settings/Down, SmartImage

game/Back

OSD Languages: Brazil Portuguese, Czech, Dutch, English, Finnish, French, German, Greek, Hungarian, Italian, Japanese, Korean, Polish, Portuguese, Russian, Spanish, Simplified Chinese, Swedish, Turkish, Traditional Chinese, Ukrainian
Other convenience: Kensington lock, VESA mount (100x100mm)
MultiView: PBP (2x devices)

Stand

Height adjustment: 130 mm
Pivot: -/+ 90 degree
Swivel: -/+ 45 degree
Tilt: -5/20 degree

Power

Power supply: Internal, 100-240VAC, 50-60Hz
Off mode: 0.3 W (typ.)
On mode: 64.0 W (typ.)
Standby mode: 0.5 W (typ.)
Power LED indicator: Operation - White, Standby mode - White (blinking)

Dimensions

Packaging in mm (WxHxD): 930 x 526 x 186 mm
Product without stand (mm): 715 x 420 x 60 mm
Product with stand(max height): 715 x 640 x 297 mm

Weight

Product with packaging (kg): 15.37 kg
Product with stand (kg): 10.55 kg
Product without stand (kg): 7.74 kg

Operating conditions

Altitude: Operation: +12,000ft (3,658m), Non-operation: +40,000ft (12,192m)
Temperature range (operation): 0°C to 40 °C
MTBF: 50,000 (Excluded backlight) hour(s)
Relative humidity: 20%-80 %
Temperature range (storage): -20°C to 60 °C

Sustainability

Environmental and energy: RoHS
Recyclable packaging material: 100 %
Specific Substances: Mercury free, PVC / BFR free housing, SIAA

Compliance and standards

Regulatory Approvals: CB, CE Mark, FCC Class B, ICES-003, CU-EAC, EAEU RoHS, TUV/ISO9241-307, TUV-BAUART

Cabinet

Color: Black
Finish: Textured



* "IPS" word mark / trademark and related patents on technologies belong to their respective owners.
 * For best output performance, please always ensure that your graphic card is capable of achieving the maximum resolution and refresh rate of this Philips display.
 * Response time value equal to SmartResponse
 * MPRT is to adjust brightness for blur reduction, so cannot adjust brightness while MPRT is turned on. To reduce motion blur, LED backlight will strobe synchronously with screen refresh, which may cause noticeable brightness change.
 * MPRT is gaming-optimized mode. Turn on MPRT may cause noticeable screen flickering. It is recommended to turn off when you are not using the gaming function.
 * NTSC Area based on CIE1976
 * sRGB Area based on CIE1931
 * Adobe RGB Coverage based on CIE1976
 * NVIDIA® G-SYNC® support interface: DisplayPort
 * Make sure to update NVIDIA® G-SYNC® driver to the latest version, see more information on NVIDIA website: <https://www.nvidia.com/>
 * Make sure your graphic card supports NVIDIA® G-SYNC®
 * 2020 Advanced Micro Devices, Inc. All rights reserved. AMD, the AMD Arrow logo, AMD FreeSync™ and combinations thereof are trademarks of Advanced Micro Devices, Inc. Other product names used in this publication are for identification purposes only and may be trademarks of their respective companies.
 * The monitor may look different from feature images.