

PHILIPS

4K Ultra Slim Smart
LED TV

6700 series

164 cm (65")

4K Ultra HD LED TV

Quad Core

DVB-T/T2



65PUT6703S

Ultra Slim 4K UHD LED Smart TV with Ambilight 3-sided and Saphi system

Sit back and enjoy the rich quality of 4K UHD on a Smart TV that's brilliantly easy to use. Access favourite content instantly with SAPHI. Pixel Precise Ultra HD makes everything look smooth and sharp. And Ambilight ties it all together.

Passionate about Picture Quality

- Micro Dimming optimizes the contrast on your TV
- Experience better contrast, color & sharpness with HDR Plus

SAPHI: intuitive app content selection

- SAPHI. The smart way to enjoy your TV.

Slim TV. Clear sound.

- Philips Sound Processing for accurate audio.

Sharp. Light. Beautiful.

- Ambilight. Take the emotion beyond the screen.
- Ultra-slim frame with aluminium coloured bezel & stand.

See every detail

- Pixel Precise Ultra HD. Fluid images with incredible depth.
- 4K Ultra HD is unlike any resolution you ever seen before

Highlights

Ambilight 3-sided



With Philips Ambilight, movies and games feel more immersive. Music gets a light show. And your screen will feel bigger than it is. Intelligent LEDs around the edges of the TV cast on-screen colours onto the walls, and into the room, in real time. You get perfectly tuned ambient lighting. And one more reason to love your TV.

Metal Angled Stand

Modern European Design is visible in the floating aluminium stands finished in dark silver matching the ultra-slim bezel.

Pixel Precise Ultra HD

The beauty of 4K Ultra HD TV is in savoring every detail. Philips Pixel Precise Ultra HD engine converts any input picture into stunning UHD resolution on your screen. Enjoy a smooth, yet sharp moving image and exceptional contrast. Discover deeper blacks, whiter whites, vivid colors and natural skin tones - every time, and from any source.

HDR Plus



High Dynamic Range Plus redefines in-home entertainment. Experience a sensory journey with its advanced processing power. Capture the richness and liveliness of the content just as the creator intended. Get ready to enjoy brighter highlights, greater contrast, a broader range of colors and detail like never before.

Saphi TV system

SAPHI is a fast, intuitive operating system that makes your Philips Smart TV a real pleasure to use. Enjoy great picture quality and one-button access to a clear icon-based menu. Operate your TV with ease, and quickly navigate to popular Philips Smart TV apps including YouTube, and more.

Micro Dimming



Thanks to our special software that analyzes the picture in 6400 different zones and adjusts it accordingly, you'll enjoy incredible contrast and image quality for a truly lifelike visual experience.

4K Ultra HD



Ultra HD TV has four times the resolution of a conventional Full HD TV. With over 8 million pixels and our unique Ultra Resolution Upscaling technology, you'll experience the best possible picture quality. The higher the quality of your original content, the better images and resolution you will be able to experience. Enjoy improved sharpness, increased depth perception, superior contrast, smooth natural motion, and flawless details.

DTS HD

DTS HD optimizes sound processing by preserving the original sound content so that you can enjoy a better sound from your speakers with crystal-clear dialog.



Specifications

Ambilight

Ambilight Version: 3-sided

Picture/Display

Aspect ratio: 16:9

Display: 4K Ultra HD LED

Picture enhancement: Micro Dimming, 1100 PPI, Pixel Precise Ultra HD, Ultra Resolution

Panel resolution: 3840x2160

Supported Display Resolution

Video inputs on HDMI1: up to 4K UHD 3840x 2160 @30Hz

Computer inputs on HDMI1: up to 4K UHD 3840x 2160 @30Hz

Computer inputs on HDMI2/3: up to 4K UHD 3840x 2160 @60Hz

Video inputs on HDMI2/3: up to 4K UHD 3840x 2160 @60Hz

Tuner/Reception/Transmission

Digital TV: DVB-T/T2

Video Playback: PAL, SECAM

MPEG Support: MPEG2, MPEG4

TV Program guide*: 8 day Electronic Program Guide

Smart TV Features

User Interaction: MultiRoom client,

SimplyShare, Wi-Fi Miracast certified*

Program: Pause TV

SmartTV apps*: Open internet browser, Youtube, Netflix TV, Philips store

Ease of Installation: Device connection wizard, Network installation wizard, Settings assistant wizard

Firmware upgradeable: Firmware auto upgrade wizard, Firmware upgradeable via USB, Online firmware upgrade

Screen Format Adjustments: Basic - Fill Screen, Fit to screen, Zoom, stretch

Philips TV Remote app*: Apps, Channels, Control, TV Guide

Multimedia Applications

Video Playback Formats: Containers: AVI, MKV, H264/MPEG-4 AVC, MPEG-1, MPEG-2, MPEG-4, WMV9/VC1, VP9, HEVC

Music Playback Formats: AAC, MP3, WAV, WMA (v2 up to v9.2), WMA-PRO (v9 and v10)

Subtitles Formats Support: .SMI, .SRT, .SUB, .TXT, .ASS, .SSA

Picture Playback Formats: JPEG, BMP, GIF, PNG

Processing

Processing Power: Quad Core

Sound

Output power (RMS): 20W

Sound Enhancement: Incredible Surround, Clear Sound, Auto Volume Leveler, Smart Sound

Connectivity

Number of AV connections: 1

Number of HDMI connections: 3

HDMI features: Audio Return Channel, 4K

Number of component in (YPbPr): 1

EasyLink (HDMI-CEC): Remote control pass-through, System audio control, System standby, One touch play

Number of USBs: 2

Wireless connection: Wi-Fi 802.11n 2x2 integrated, Dual Band

Other connections: Digital audio out (optical), Ethernet-LAN RJ-45, Audio L/R in, Headphone out, Antenna IEC75

Power

Mains power: 110 - 240 V 50/60Hz

Ambient temperature: 5 °C to 35 °C

Power Saving Features: Auto switch-off timer

Accessories

Included accessories: Remote Control, 2 x AAA Batteries, Power cord, Quick start guide, Legal and safety brochure, Table top stand

Dimensions

Box depth: 185 mm

Product weight: 24.45 kg

Set Width: 1462.3 mm

Set width (with stand): 1462.3 mm

Wall mount compatible: 400 x 200 mm

Box height: 995 mm

Box width: 1600 mm

Set Height: 852.3 mm

Weight incl. Packaging: 32.0 kg

Set Depth: 87.5 mm

Set height (with stand): 884.1 mm

Set depth (with stand): 295.7 mm

Product weight (+stand): 25.1 kg

