



Philips
LCD monitor

38 cm (15")
XGA

150S6FS

performance and convenience maximize your budget

This slim, compact 150S6 pumps up productivity with great performance and convenience while business-friendly features like SmartManage deliver the best total cost of ownership and lead-free design safeguards our environment.

Best total cost of ownership solution

- SmartManage compatibility enables LAN-based asset management
- Power consumption below the industry average
- Environmentally responsible Energy Star partner
- Kensington anti-theft lock-ready for added security

Outstanding front of screen performance

- 16ms On/off response time: Better text and graphics display
- XGA 1024x768 resolution for sharper display
- sRGB ensures color matching between display and printouts

Great convenience

- Embedded power supply eliminates external power adaptors
- Easy, user friendly plug-and-play installation
- Convenient, built in holder for notes, cards or photos
- Screen tilts to your ideal, individualized viewing angle

PHILIPS

Highlights

SmartManage enabled

SmartManage is a system for monitoring, managing and checking status of display devices as well as delivering remote support to users who experience difficulties - all accomplished over a LAN.

Lower power consumption

Reduction of the electrical power required to operate a device.

Kensington lock compatible

Small apertures built into the display's frame for use with a locking device that secures a display to a fixed object for added protection against theft.

16ms response time (On-Off)

On-Off response time is the period required for a liquid crystal cell to go from active (black)

to inactive (white) and back to active (black) again. It is measured in milliseconds. Faster is better: Lower response time means faster transitions and, therefore, results in fewer visible image artifacts in the display of transition of text and graphics. On-Off response time is a more important measure in the display of business content like documents, graphs and photos.

sRGB ready

sRGB is an industry standard that ensures the best possible match between the colors displayed on your screen and those in your printouts.

Embedded power supply

An embedded power supply is a power adaptor built into the body of a display device that replaces a bulky external power adaptor.

Easy plug-and-play

Plug-and-play is a peripheral connectivity standard. A plug and play display device can be connected to a PC and operate without requiring user intervention to adjust complicated settings.

FlexiHolder

FlexiHolder is a slim groove on the top of monitor that neatly and conveniently stores favorite photos, reminders, to-do lists or phone numbers in your line of sight.

Adjustable tilt

Adjustable tilt is backward and forward movement of a screen on its base to achieve custom positioning for an ideal viewing angle and more comfort for people who spend long hours working on the computer.



Specifications

Picture/Display

- LCD panel type: 1024 x 768 pixels, Anti-glare polarizer, RGB vertical stripe
- Panel Size: 15"/ 38 cm
- Effective viewing area: 304.1 x 228.1 mm
- Pixel pitch: 0.297 x 0.297 mm
- Brightness (nits): 250 nit
- Contrast ratio (typical): 450:1
- Display colors: 16.2 M
- Viewing angle: @ C/R > 5
- Viewing angle (H / V): 160 / 140 degree
- Response time (typical): 16 ms
- White Chromaticity, 6500K: $x = 0.313$ / $y = 0.329$
- White Chromaticity, 9300K: $x = 0.283$ / $y = 0.297$
- Maximum Resolution: 1024 x 768 @ 75 Hz
- Optimum resolution: 1024 x 768 @ 60 Hz
- Factory Preset Modes: 15 modes
- User definable modes: 50 modes
- Video Dot Rate: 80 MHz
- Horizontal Scanning Frequency: 30 - 63 kHz
- Vertical Scanning Frequency: 56 - 76 Hz
- sRGB

Connectivity

- Signal Input: VGA (Analog)
- Sync Input: Composite Sync, Separate Sync, Sync on Green

Convenience

- User convenience: On-screen Display, SmartManage enabled
- Monitor Controls: Auto, Brightness Control, Left/

- Right, Menu (OK), Power On/Off, Up/Down
- OSD Languages: English, French, German, Italian, Simplified Chinese, Spanish
- Other convenience: Kensington lock compatible, FlexiHolder
- Plug & Play Compatibility: DDC/CI, sRGB, Windows 98/ME/2000/XP
- Regulatory approvals: Energy Star, FCC Class B, UL
- Tilt: -5° to 25°
- VESA Mount: 100 x 100 mm

Accessories

- Included accessories: AC Power Cord, VGA cable
- User Manual

Dimensions

- Dimensions (with base) (W x H x D):
342 x 344 x 180 mm
- MTBF: 50,000 hrs
- Relative humidity: 20% - 80%
- Temperature range (operation): 5°C to 40°C
- Temperature range (storage): -20°C to 60°C
- Weight: 2.7 kg

Power

- Complies with: Energy Star
- Consumption (On mode): 17W (Typical)
- Consumption (Off Mode): < 1 W
- Power LED indicator: Operation - green, Stand by/sleep - Amber
- Power supply: Built-in, 90-264 VAC, 50/60 Hz



Issue date 2022-05-10

Version: 2.0.3

12 NC: 8639 000 16456
EAN: 87 10895 91089 7

© 2022 Koninklijke Philips N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips N.V.
or their respective owners.

www.philips.com