

Philips
LCD monitor

V Line
20 (19.5"/49.5 cm diag.)

203V5LSB26



Great LED images in vivid colours

Enjoy vivid LED pictures on this Philips display. Compact design and VESA mount give your workspace flexibility. It's a great choice!

Vivid pictures every time

- LED technology for vivid colours

Great choice

- Compact design saves space
- VESA mount allows for flexibility
- Mercury Free eco-friendly display

PHILIPS

Specifications

Picture/Display

- LCD panel type: TFT-LCD
- Backlight type: W-LED system
- Panel Size: 19.5 inch / 49.5 cm
- Effective viewing area: 433.9 (H) x 236.3 (V)
- Aspect ratio: 16:9
- Optimum resolution: 1600 x 900 @ 60 Hz
- Response time (typical): 5 ms
- Brightness: 200 cd/m²
- Contrast ratio (typical): 600:1
- Pixel pitch: 0.26 x 0.26 mm
- Viewing angle: 90° (H)/50° (V), @ C/R > 10
- Display colours: 16.7 M
- Scanning Frequency: 30–83 kHz (H)/56–75 Hz (V)
- sRGB

Connectivity

- Signal Input: VGA (Analogue)
- Sync Input: Separate Sync, Sync on Green

Convenience

- User convenience: Power On/Off
- OSD Languages: Brazil Portuguese, Czech, Dutch, English, Finnish, French, German, Greek, Hungarian, Italian, Japanese, Korean, Polish, Portuguese, Russian, Simplified Chinese, Spanish, Swedish, Traditional Chinese, Turkish, Ukrainian
- Other convenience: Kensington lock, VESA mount (100 x 100 mm)
- Plug and Play Compatibility: DDC/CI, Mac OS X, sRGB, Windows 7, Windows 8

Stand

- Tilt: -3/10 degree

Power

- On mode: 14.52 W (typ.) (EnergyStar 6.0 test method)
- Energy Label Class: E
- Standby mode: 0.5 W (typ.)

- Off mode: 0.5 W (typ.)
- Power LED indicator: Operation - White, Standby mode - White (flashing)
- Power supply: Built-in, 100–240 VAC, 50–60 Hz

Dimensions

- Product with stand (mm): 465 x 345 x 170 mm
- Product without stand (mm): 465 x 285 x 48 mm
- Packaging in mm (W x H x D): 503 x 350 x 109 mm

Weight

- Product with stand (kg): 2.33 kg
- Product without stand (kg): 2.03 kg
- Product with packaging (kg): 3.23 kg

Operating conditions

- Temperature range (operation): 0°C to 40°C °C
- Temperature range (storage): -20°C to 60°C °C
- Relative humidity: 20%-80 %
- Altitude: Operation: +12,000 ft (3658 m), Non-operation: +40,000 ft (12,192 m)
- MTBF: 30,000 hour(s)

Sustainability

- Environmental and energy: RoHS, Mercury Free
- Recyclable packaging material: 100 %

Compliance and standards

- Regulatory Approvals: BSMI, CE Mark, FCC Class B, GOST, SEMKO, TUV/ISO9241-307, cETLus, WEEE

Cabinet

- Colour: Black
- Finish: Hairline (front bezel)/Texture (rear cover)

What's in the box?

- Monitor with stand
- Cables: VGA, Power
- User Documentation

Highlights

LED technology

White LED's are solid state devices which light up to full, consistent brightness faster saving startup time. LED's are free from mercury content, which allows for eco-friendly recycling and disposal process. LED's allow for better dimming control of the LCD backlight, resulting in a super high contrast ratio. It also gives superior colour reproduction thanks to consistent brightness across the screen.

Mercury Free

Philips monitors with LED backlighting are free from Mercury, one of the most toxic natural substances, which affects humans and animals. This reduces the environmental impact of the display throughout its lifecycle, from manufacturing to disposal.



Issue date 2021-03-14

Version: 9.0.1

12 NC: 8670 001 03168
EAN: 87 12581 68838 7

© 2021 Koninklijke Philips N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips N.V.
or their respective owners.

www.philips.com