



LCD monitor with SmartControl Lite

- V Line
- 24 (23.8" / 60.5 cm diag.)

240V5QDSB/01

Great LED images in vivid colors

Enjoy vibrant pictures on this Philips display. Equipped with HDMI and SmartControl lite, it's a great choice!

Benefits

Vivid pictures every time

- IPS-ADS wide-view technology for image and color accuracy
- 16:9 Full HD display for crisp detailed images
- SmartContrast for rich black details
- Easy display performance tuning with SmartControl Lite

Experience multimedia

- HDMI-ready for Full HD entertainment

Great choice

- Mercury Free eco-friendly display
- Compact design saves space
- VESA mount allows for flexibility

Features

IPS-ADS technology



IPS-ADS displays use an advanced technology which gives you extra wide viewing angles of 178/178 degree, making it possible to view the display from almost any angle. Unlike standard TN panels, IPS-ADS displays give you

remarkably crisp images with vivid colors, making it ideal not only for Photos, movies and web browsing, but also for professional applications which demand color accuracy and consistent brightness at all times.


PHILIPS

16:9 Full HD display



Picture quality matters. Regular displays deliver quality, but you expect more. This display features enhanced Full HD 1920 x 1080 resolution. With Full HD for crisp detail paired with high brightness, incredible contrast and realistic colors expect a true to life picture.

SmartContrast



SmartContrast is a Philips technology that analyzes the contents you are displaying, automatically adjusting colors and controlling backlight intensity to dynamically enhance contrast for the best digital images and videos or when playing games where dark hues are displayed. When Economy mode is selected, contrast is adjusted and backlighting fine-tuned for just-right display of everyday office applications and lower power consumption.

SmartControl Lite

SmartControl Lite is the next generation 3D icon based GUI monitor control software. This allows user to fine-tune most parameters of the monitor like Color, Brightness, screen calibration, Multi-media, ID management, etc with the mouse.

HDMI Ready



An HDMI-ready device has all the required hardware to accept High-Definition Multimedia Interface (HDMI) input. A HDMI cable enables high-quality digital video and audio all transmitted over a single cable from a PC or any number of AV sources (including set-top boxes, DVD players, A/V receivers and video cameras).

Mercury Free

Philips monitors with LED backlighting are free of Mercury content, one of the most toxic natural substances, which affects humans and animals. This reduces the environmental impact of the display throughout its life-cycle, from manufacturing to disposal.

Specifications

[field not found 'disclaimer_text']

Picture/Display

LCD panel type	IPS-ADS LCD
Backlight type	W-LED system
Panel Size	23.8 inch / 60.5 cm
Effective viewing area	527.04 (H) x 296.46 (V)
Aspect ratio	16:9
Optimum resolution	1920 x 1080 @ 60 Hz
Brightness	250 cd/m ²
Response time (typical)	5 ms (GtG)*
SmartContrast	10,000,000:1
Contrast ratio (typical)	1000:1
Pixel pitch	0.275 x 0.275 mm
Viewing angle	178° (H) / 178° (V) @ C/R > 10
Display colors	16.7 M
Scanning Frequency	30 -83 kHz (H) / 56 -76 Hz (V)
sRGB	Yes

Connectivity

Signal Input	VGA (Analog) DVI-D (digital, HDCP) HDMI (digital, HDCP)
Sync Input	Separate Sync Sync on Green

Convenience

User convenience	Power On/Off Menu/OK Brightness/Back 4:3 Wide/Up Auto/Down
OSD Languages	Brazil Portuguese Czech Dutch English Finnish French German

Greek
Hungarian
Italian
Japanese
Korean
Polish
Portuguese
Russian
Spanish
Simplified Chinese
Swedish
Turkish
Traditional Chinese
Ukrainian
Kensington lock
VESA mount (100x100mm)
DDC/CI
Mac OS X
sRGB
Windows 7
Windows 8.1

Other convenience

Plug & Play Compatibility

Stand

Tilt	-5/20 degree
------	--------------

Power

On mode	19.23 W (typ.) (EnergyStar 6.0 test method)
Standby mode	0.5 W (typ.)
Off mode	0.5 W (typ.)
Power LED indicator	Operation - White Standby mode- White (blinking)
Power supply	Built-in 100-240VAC, 50-60Hz

Dimensions

Product with stand (mm)	553 x 420 x 219 mm
Product without stand (mm)	553 x 343 x 55 mm

Packaging in mm
(WxHxD) 600 x 415 x 118 mm

Recyclable packaging
material 100 %

Weight

Product with stand
(kg) 4.09 kg
Product without
stand (kg) 3.69 kg
Product with pack-
aging (kg) 5.36 kg

Operating conditions

Temperature range
(operation) 0°C to 40°C °C
Temperature range
(storage) -20°C to 60°C °C
Relative humidity 20%-80 %
Altitude Operation: +12,000ft (3,658m), Non-
operation: +40,000ft (12,192m)
MTBF 50,000 (Excluded backlight) hour(s)

Sustainability

Environmental and
energy EnergyStar 6.0
RoHS
Lead-free
Mercury Free

Compliance and standards

Regulatory Approvals CE Mark
FCC Class B
TCO Certified
cETLus
TUV/ISO9241-307
BSMI
PSB
C-tick
UKRAINIAN
EPA

Cabinet

Color Black
Finish Hairline (front bezel) / Texture (rear
cover)

What's in the box?

Monitor with stand yes
Cables VGA, Power
User Documentation yes

* "IPS" word mark / trademark and related patents on technologies belong to their respective owners.

* HDMI cables vary depending on region and models.

* Response time value equal to SmartResponse



data subject to change
2019, November 27

Version: 5.0.1
EAN: 8712581732424

© 2019 Koninklijke Philips N.V.
All rights reserved.

Specifications are subject to change without notice. Trademarks are the property of Koninklijke Philips N.V. or their respective owners.

www.philips.com