



Philips
LCD monitor with LED
backlight

V Line
20 (19.5" / 49.5 cm diag.)

200V4LAB2

Enjoy great LED pictures in vivid colors

with stereo speakers

Enjoy vivid LED pictures with this attractive, glossy design display. Equipped with stereo speakers, it's a great choice!

Vivid pictures every time

- 16:9 display for great viewing experience
- LED technology for vivid colors
- SmartContrast for rich black details

Modern design

- Attractive glossy design
- Small footprint saves space
- VESA mount allows for flexibility

Experience multimedia

- Powerful sound with 2x2 watts RMS speakers

Greener everyday

- Mercury Free eco-friendly display
- Low power consumption saves energy bills
- Energy Star for energy efficiency and low power consumption

PHILIPS

LCD monitor with LED backlight
V Line 20 (19.5" / 49.5 cm diag.)

200V4LAB2/00

Highlights

LED technology

White LED's are solid state devices which light up to full, consistent brightness faster saving startup time. LED's are free from mercury content which allows for eco-friendly recycling and disposal process. LED's allow for better dimming control of LCD backlight, resulting in super high contrast ratio. It also gives superior color reproduction thanks to consistent brightness across the screen.

Built-in stereo speakers

Now you can enjoy all your multimedia and social applications with stereo sound. These built in speakers not only sound great, but also helps you to get rid of external wire clutter and save valuable desktop space.

SmartContrast



SmartContrast is a Philips technology that analyzes the contents you are displaying, automatically adjusting colors and controlling backlight intensity to dynamically enhance contrast for the best digital images and videos or when playing games where dark hues are displayed. When Economy mode is selected, contrast is adjusted and backlighting fine-tuned for just-right display of everyday office applications and lower power consumption.

Mercury Free

Philips monitors with LED backlighting are free of Mercury content, one of the most toxic

natural substances, which affects humans and animals. This reduces the environmental impact of the display throughout its life-cycle, from manufacturing to disposal.

Low power consumption

Low power consumption saves energy bills

Attractive glossy design

Attractive glossy design

Small footprint saves space

Small footprint saves space

VESA mount

VESA mount allows for flexibility

16:9 display

16:9 display for great viewing experience

Energy Star

Energy Star for energy efficiency and low power consumption



Hg Free



VESA Mount



ENERGY STAR



Built-in Speaker



LED



10,000,000:1

SmartContrast



Low Power

Specifications

Connectivity

- Signal Input: VGA (Analog), DVI-D (digital, HDCP)
- Sync Input: Separate Sync, Sync on Green
- Audio (In/Out): PC audio-in

Picture/Display

- Panel Size: 19.5 inch / 49.5 cm
- Aspect ratio: 16:9
- LCD panel type: TFT-LCD
- Backlight type: W-LED system
- Pixel pitch: 0.32 x 0.31 mm
- Optimum resolution: 1600 x 900 @ 60 Hz
- Brightness (max.): 200 cd/m²
- Display colors: 16.7 M
- Contrast ratio (typical): 600:1
- SmartContrast: 10,000,000:1
- Response time (typical): 5 ms
- Viewing angle: 90° (H) / 65° (V), @ C/R > 10
- Effective viewing area: 432.00 (H) x 239.76 (V)
- Scanning Frequency: 30 -83 kHz (H) / 56 -76 Hz (V)
- sRGB

Convenience

- Plug & Play Compatibility: DDC/CI, Mac OS X, sRGB, Windows 8/7/XP
- Built-in Audio: 2.0Wx2
- User convenience: Auto/Down, Brightness/Back, Menu/OK, Power On/Off, Volume/Up
- OSD Languages: Brazil Portuguese, Czech, Dutch, English, Finnish, French, German, Greek, Hungarian, Italian, Japanese, Korean, Polish, Portuguese, Russian, Simplified Chinese, Spanish, Swedish, Turkish, Traditional Chinese, Ukrainian
- Other convenience: Kensington lock, VESA mount (100x100mm)

Stand

- Tilt: -5/20 degree

Power

- Power supply: Built-in, 100-240VAC, 50-60Hz
- Off mode: 0.5 W

- On mode: 16 W (typ.), 19 W (max.)
- Standby mode: 0.5 W
- Power LED indicator: Operation - White, Standby mode- White (blinking)
- Energy Label Class: E

Dimensions

- Product with stand (mm): 479 x 369 x 201 mm
- Packaging in mm (WxHxD): 567 x 372 x 124 mm
- Product without stand (mm): 479 x 299 x 48 mm

Weight

- Product with packaging (kg): 3.83 kg
- Product with stand (kg): 2.72 kg
- Product without stand (kg): 2.39 kg

Operating conditions

- Altitude: Operation: +12,000ft (3,658m), Non-operation: +40,000ft (12,192m)
- Temperature range (operation): 0°C to 40°C °C
- MTBF: 30,000 hour(s)
- Relative humidity: 20%-80 %
- Temperature range (storage): -20°C to 60°C °C

Sustainability

- Environmental and energy: Energy Star, RoHS, Mercury Free
- Recyclable packaging material: 100 %

Compliance and standards

- Regulatory Approvals: CE Mark, FCC Class B, EAC, SEMKO, TCO Certified, UL/cUL, BSMI, TUV/ISO9241-307, WEEE, CECP

Cabinet

- Color: Black
- Finish: Glossy (front bezel) /Texture (rear cover)

What's in the box?

- Cables: VGA, Audio, Power
- Monitor with stand
- User Documentation



Issue date 2024-03-24

Version: 4.0.1

EAN: 87 12581 73686 6

© 2024 Koninklijke Philips N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips N.V.
or their respective owners.

www.philips.com