

Philips  
LED Touch Monitor

140 cm (55")  
multimedia  
Full HD

BDT5530EX



## More audience interaction

with robust multi-touch screen LED Display

Deliver the message to your audience in startling clarity. Thanks to the capacitive touch screen, you can engage your customer in public spaces much more closely than ever before.

### Optimised for public touch

- Slim bezel design for a stylish look

### Can be used as Touch Table!

- Delivered with 4 stainless steel feet (8 cm)

### Lower total cost of ownership

- Edge LED Backlight
- SmartPower for energy saving

### Operational flexibility

- Capacitive Touch
- 2 Touch Points
- Software Independent

### Sustainable and safe

- Temperature sensor measures the health condition
- Complies with RoHS standards of care for the environment

# PHILIPS

# Highlights

## Capacitive Touch

This capacitive touch has 5-mm tempered glass. Therefore it is perfectly practical for public use and easy to clean.

## 2 Touch Points

Enjoy the interactivity of multi-touch functionality. It has the advantages of a more robust touch screen combined with the multi-touch gestures for using more versatile touch software.

## Edge LED Backlight

Experience an even dispersion of light with cutting-edge LED technology. White LEDs (light emitting diodes) are positioned around the rim of the panel to give a more even spread of light. This results in even lower power

consumption, less heat to dissipate and a true, uniform colour range.

## SmartPower

The backlight intensity can be controlled and pre-set by the system to reduce the power consumption by up to 50%, which saves substantially on energy costs.

## Compliant with RoHS standards

Philips designs and produces display products in compliance with strict Restriction of Hazardous Substances (RoHS) standards that restrict lead and other toxic substances that can harm the environment.

## Temperature sensor

This multi-user Touch Screen contains a temperature sensor to monitor the internal

health condition. If the internal temperature surpasses the pre-set threshold, two internal fans will be automatically activated to cool down the display to normal conditions.

## Slim bezel

A slim bezel design adds a stylish look to a Touch Screen to nicely blend in most environments.

## Software Independent

Our touch screens are software independent and work with most touch-screen software commercially available, including Windows XP/7 and Mac OS, Omnitapps – BMT1909/00. Connect via USB to a PC or laptop.

## With 4 stainless steel feet

Delivered with 4 stainless steel feet (8 cm)



# Specifications

## Picture/Display

- Diagonal screen size: 54.6 inch / 138.6 cm
- Aspect ratio: 16:9
- Panel resolution: 1920 x 1080p
- Pixel pitch: 0.21 x 0.63 mm
- Optimum resolution: 1920 x 1080 @ 60 Hz
- Brightness: 450 cd/m<sup>2</sup>
- Display colours: 1.07 Billion
- Contrast ratio (typical): 4000:1
- Response time (typical): 6.5 ms
- Viewing angle: 178° (H)/178° (V)
- Picture enhancement: 3/2 - 2/2 motion pull down, 3D Combfilter, Motion compens. deinterlacing, Progressive scan, 3D MA deinterlacing, Dynamic contrast enhancement

## Connectivity

- PC: VGA-in D-Sub 15HD, VGA-out D-Sub 15HD, DVI-D x 1, RS232 D-Sub9, RS232 D-sub9 output, 3.5 mm PC audio input x 1
- AV input: HDMI x 1, Component (BNC) x 1, S-video x 1, Audio (L/R) x 2
- Other connections: Component RCA x1
- Touch Screen: USB

## Convenience

- Placement: Portrait, Landscape
- Picture in picture: PIP
- Screen-saving functions: Pixel Shift, Low Brightness
- Keyboard control: Hidden, Lockable
- Remote control signal: Lockable
- Energy-saving functions: Ambient light sensor, Smart Power
- Safety control functions: Heat Control, Temperature Sensor

## Sound

- Built-in speakers: 2 x 12 W RMS

## Power

- Mains power: 90-264 V/AC, 50/60 Hz
- Standby power consumption: <1 W

## Supported Display Resolution

- Computer formats: 640 x 480, 60, 67, 72, 75 Hz, 800 x 600, 56, 60, 72, 75 Hz, 1024 x 768, 60 Hz, 1280 x 768, 60 Hz, 1280 x 800, 60 Hz, 1360 x 768,

- 60 Hz, 1366 x 768, 60 Hz, 1440 x 900, 60 Hz, 1600 x 1200, 60 Hz, 1920 x 1080, 60 Hz, 1920 x 1200, 60 Hz
- Video formats: 480i, 60 Hz, 480p, 60 Hz, 576i, 50 Hz, 576p, 50 Hz, 720p, 50, 60 Hz, 1080i, 50, 60 Hz, 1080p, 50, 60 Hz

## Dimensions

- Bezel thickness: 62.50 mm
- Set dimensions (W x H x D): 1350 x 815 x 74.84 mm
- Product weight: 53 kg
- Wall Mount: 400 x 400 mm

## Operating conditions

- Temperature range (operation): 0 - 40 °C
- MTBF: 60,000 hour(s)
- Relative humidity: 5 - 90 %

## Accessories

- Included accessories: Remote Control, Batteries for remote control, AC Power Cord, VGA cable, User manual on CD-ROM, Owner's Manual, 4 stainless steel feet, Touch Driver on USB
- Optional accessories: Fixed wall mount, Flexible wall mount, Ceiling mount, Electric Stand BMT1851/00, Multi User Touch SW, Software Omnitapps BMT1909/00

## Miscellaneous

- Bezel: Black 9005F13
- On-Screen Display Languages: English, French, German, Italian, Polish, Turkish, Russian, Simplified Chinese
- Warranty: Europe 2 years

## Packaging Data

- Packaging dimensions (W x H x D):: 1450 x 1000 x 300
- Tare weight: 30 kg
- Number of products included: 1

## Interactivity

- Multi-touch technology: 2 Touch Points simultaneously, Capacitive touch, USB connection, 5-mm safety glass



Issue date 2024-03-24

Version: 1.0.1

EAN: 87 12581 65495 5

© 2024 Koninklijke Philips N.V.  
All Rights reserved.

Specifications are subject to change without notice.  
Trademarks are the property of Koninklijke Philips N.V.  
or their respective owners.

[www.philips.com](http://www.philips.com)