



Philips  
LCD monitor, LED  
backlight

**E Line**  
23.6" / 60 cm

**247E3LPHSU2**

## Elegant display with PowerSensor

saves energy bills

Experience awesome LED pictures with natural colors. The elegant design with translucent blue bezel, HDMI and Innovative PowerSensor that detects your presence, saving up to 80% of your energy bill, makes it a smart green choice.

### **Great picture quality**

- 16:9 Full HD display for best viewing experience
- SmartResponse of 2ms
- SmartContrast 20000000:1 for incredible rich black details
- SmartImage Lite for an enhanced LCD viewing experience
- LED technology for natural colors

### **Design that complements any interior**

- Sleek, elegant design complements your home decor
- Modern Touch controls
- Translucent blue bezel with glossy finish

### **Greener everyday**

- PowerSensor ensures lower operating costs by saving energy

### **Experience true multimedia**

- HDMI-ready for top quality, multimedia experience

# PHILIPS

# Highlights

## PowerSensor



PowerSensor On

PowerSensor Off

PowerSensor is a built-in 'people sensor' that transmits and receives harmless infrared signals to determine if user is present and automatically reduces monitor brightness when user steps away from the desk, cutting energy costs by up to 80 percent and prolonging monitor life.

## LED technology

White LED's are solid state devices which light up to full, consistent brightness faster saving startup time. LED's are free from mercury content which allows for eco-friendly recycling and disposal process. LED's allow for better dimming control of LCD backlight, resulting in super high contrast ratio. It also gives superior color reproduction thanks to consistent brightness across the screen.

## SmartImage Lite

SmartImage Lite is an exclusive, leading edge Philips technology that analyzes the content displayed on your screen. Based on a scenario you select, SmartImage Lite dynamically enhances the contrast, color saturation and sharpness of images and videos for ultimate display performance - all in real time with the press on a single button.

## 16:9 Full HD



The Full HD screen has the widescreen resolution of 1920 x 1080p. This is the highest

resolution of HD sources for the best possible picture quality. It is fully future proof as it supports 1080p signals from all sources, including the most recent like Blu-ray and advanced HD game consoles. The signal processing is extensively upgraded to support this much higher signal quality and resolution. It produces brilliant flicker-free progressive scan pictures with superb brightness and colors.

## HDMI Ready



HDMI-ready

An HDMI-ready device has all the required hardware to accept High-Definition Multimedia Interface (HDMI) input. A HDMI cable enables high-quality digital video and audio all transmitted over a single cable from a PC or any number of AV sources (including set-top boxes, DVD players, A/V receivers and video cameras).

## SmartResponse - 2ms



2ms GtG response time > 2ms GtG response time

SmartResponse is a exclusive Philips overdrive technology that when turned on, automatically adjusts response times to specific application requirements like gaming and movies which require faster response times in order to produce judder, time-lag and ghost image free images

## SmartContrast ratio 2000000:1



You want the LCD flat display with the highest contrast and most vibrant images. Philips advanced video processing combined with unique extreme dimming and backlight boosting technology results in vibrant images. SmartContrast will increase the contrast with excellent blacklevel and accurate rendition of dark shades and colors. It gives a bright, lifelike picture with high contrast and vibrant colors.

## Touch controls



Touch controls are intelligent, touch sensitive icons that replace protruding buttons that lets the user adjust the monitor to their requirement. Responding to your lightest touch, Touch control gives the monitor a modern feel.

## Translucent blue bezel

Translucent blue bezel with glossy finish

## Sleek, elegant design

A sleek, elegant design look that complements home furnishings in any room.



# Specifications

## Connectivity

- Signal Input: VGA (Analog ), HDMI x 2
- Sync Input: Separate Sync, Sync on Green
- Audio (In/Out): HDMI audio out

## Picture/Display

- Panel Size: 23.6 inch / 59.9 cm
- Aspect ratio: 16:9
- LCD panel type: TFT-LCD
- Backlight type: W-LED system
- Pixel pitch: 0.272 x 0.272 mm
- Optimum resolution: 1920 x 1080 @ 60Hz
- Brightness: 250 cd/m<sup>2</sup>
- Display colors: 16.7 M
- Contrast ratio (typical): 1000:1
- SmartContrast: 20,000,000:1
- Response time (typical): 5 ms
- Viewing angle: 170° (H) / 160° (V), @ C/R >= 10
- Picture enhancement: SmartImage Lite
- Effective viewing area: 521.28 (H) x 293.22 (V)
- Scanning Frequency: 30 -83 kHz (H) / 56 -75 Hz (V)
- sRGB
- SmartResponse (typical): 2 ms

## Convenience

- Plug & Play Compatibility: DDC/CI, Mac OS X, sRGB, Windows 7
- User convenience: SmartImage lite, Input, PowerSensor, Menu, Power On/Off
- OSD Languages: English, French, German, Italian, Russian, Simplified Chinese, Spanish, Portuguese, Turkish
- Other convenience: Kensington lock

## Stand

- Tilt: -5/+20 degree

## Power

- Power supply: 100-240VAC, 50-60Hz, Built-in
- Off mode: <math>0.3\text{ W}</math>
- On mode: 17.53 W (EnergyStar 5.0 test method)

- Standby mode: <math>0.5\text{ W}</math>
- Power LED indicator: Operation - White, Standby mode- White (blinking)

## Dimensions

- Product with stand (mm): 579 x 442 x 238 mm
- Product with stand in inch: 22.8 x 17.4 x 9.4 inch
- Packaging in mm (WxHxD): 619 x 506 x 103 mm
- Product without stand (mm): 579 x 363 x 41 mm
- Packaging in inch (WxHxD): 24.4 x 19.9 x 4.1 inch
- Product without stand in inch: 22.8 x 14.3 x 1.6 inch

## Weight

- Product with packaging (kg): 5.88 kg
- Product with stand (kg): 4.50 kg
- Product with packaging (lb): 12.94 lb
- Product with stand (lb): 9.9 lb
- Product without stand (kg): 3.97 kg
- Product without stand (lb): 8.73 lb

## Operating conditions

- Temperature range (operation): 0°C to 40°C °C
- MTBF: 30,000 hour(s)
- Relative humidity: 20%-80 %
- Temperature range (storage): -20°C to 60°C °C

## Sustainability

- Environmental and energy: EnergyStar 5.0, EPEAT Silver, RoHS, Mercury Free
- Recyclable packaging material: 100 %

## Compliance and standards

- Regulatory Approvals: BSMI, CE Mark, FCC Class B, GOST, PSB, SASO, SEMKO, TUV Ergo, TUV/ GS, TCO Certified, UL/cUL, WEEE

## Cabinet

- Color: Black/ Blue tint
- Finish: Glossy



Issue date 2024-03-24

Version: 2.0.1

UPC: 6 09585 22907 5

© 2024 Koninklijke Philips N.V.  
All Rights reserved.

Specifications are subject to change without notice.  
Trademarks are the property of Koninklijke Philips N.V.  
or their respective owners.

[www.philips.com](http://www.philips.com)