

# Enjoy great LED pictures in vivid colors

Enjoy vivid LED pictures with this attractive, glossy design display. Equipped with SmartControl lite, it's a great choice!

#### Vivid pictures every time

- LED technology for vivid colors
- SmartContrast for rich black details
- 16:9 display for great viewing experience
- Easy display performance tuning with SmartControl Lite

## Modern design

- · Attractive glossy design
- · Small footprint saves space
- · VESA mount allows for flexibility

#### **Greener everyday**

- Mercury Free eco-friendly display
- Energy Star for energy efficiency and low power consumption
- · Low power consumption saves energy bills

Philips LCD monitor with LED backlight

- V-line
- 18.5" / 47 cm

196V4LSB2



Highlights

brightness across the screen.

**SmartControl Lite** 

**SmartContrast** 

White LED's are solid state devices which light up to

full, consistent brightness faster saving startup time.

LED's are free from mercury content which allows

for eco-friendly recycling and disposal process. LED's

allow for better dimming control of LCD backlight,

resulting in super high contrast ratio. It also gives

superior color reproduction thanks to consistent

SmartControl Lite is the next generation 3D icon

based GUI monitor control software. This allows

user to fine-tune most parameters of the monitor

like Color, Brightness, screen calibration, Multi-

media, ID management, etc with the mouse.

LED technology

# Specifications

#### Picture/Display

- LCD panel type: TFT-LCD
- · Backlight type: W-LED system
- Panel Size: 18.5 inch / 47 cm
- Effective viewing area: 409.8 (H) x 230.4 (V)
- Aspect ratio: 16:9
- Optimum resolution: 1366 x 768 @ 60 Hz
- Response time (typical): 5 ms
- Brightness: 200 cd/m<sup>2</sup>
- SmartContrast: 10,000,000:1
- Contrast ratio (typical): 600:1
- Pixel pitch: 0.30x 0.30 mm
- Viewing angle: 90° (H) / 65° (V), @ C/R > 10
- Display colors: 16.7 M
- Scanning Frequency: 30 -83 kHz (H) / 56 -75 Hz (V)
- sRGB

#### Connectivity

- Signal Input: VGA (Analog ), DVI-D (digital, HDCP)
- Sync Input: Separate Sync, Sync on Green

#### Convenience

- User convenience: Auto/Down, 4:3 Wide/Up, Brightness/Back, Menu/OK, Power On/Off
- · OSD Languages: English, French, German, Italian, Portuguese, Russian, Simplified Chinese, Spanish, Turkish
- Other convenience: Kensington lock, VESA mount (100×100mm)
- Plug & Play Compatibility: DDC/Cl, Mac OS X, sRGB, Windows 7, Windows XP

• Tilt: -5/20 degree

• On mode: 14.13 W (EnergyStar 5.0 test method)



















#### Standby mode: 0.5 W

- Off mode: 0.5 W
- Power LED indicator: Operation White, Standby mode- White (blinking)
- Power supply: Built-in, 100-240VAC, 50-60Hz

#### **Dimensions**

- Product with stand (mm):  $443 \times 349 \times 201$  mm
- Product without stand (mm): 443 x 279 x 48 mm
- Packaging in mm (WxHxD): 490 x 351 x 124 mm

### Weight

- Product with stand (kg): 2.98 kg
- · Product without stand (kg): 2.66 kg
- Product with packaging (kg): 3.95 kg

### **Operating conditions**

- Temperature range (operation): 0°C to 40°C °C
- Temperature range (storage): -20°C to 60°C °C
- Relative humidity: 20%-80 %
- MTBF: 30,000 hour(s)

#### Sustainability

- · Environmental and energy: EnergyStar 5.0, EPEAT Silver, RoHS, Lead-free, Mercury Free
- Recyclable packaging material: 100 %

#### **Compliance and standards**

 Regulatory Approvals: BSMI, CE Mark, FCC Class B, GOST, PSB, SASO, SEMKO, TUV/ISO9241-307, UL/cUL, WEEE

#### **Cabinet**

- · Color: Black
- Finish: Glossy (front bezel) /Texture (rear cover)

## **Mercury Free**

Philips monitors with LED backlighting are free of Mercury content, one of the most toxic natural substances which affects humans and animals. This allows for a eco-friendly display through out its lifecycle from manufacturing to disposal.

SmartContrast is a Philips technology that analyzes

the contents you are displaying, automatically adjusting colors and controlling backlight intensity to

dynamically enhance contrast for the best digital

images and videos or when playing games where

tuned for just-right display of everyday office applications and lower power consumption.

dark hues are displayed. When Economy mode is selected, contrast is adjusted and backlighting fine-

#### **Energy Star 5.0**

Energy Star is a US EPA sponsored energy efficiency program also adopted by many other countries. Energy Star certification ensures that you are buying a product which meets the latest power efficiency standards which operates with maximum power efficiency at all operational levels. New Philips monitors are certified for Energy Star 5.0 specifications and meet or exceed the standard. For example, in sleep mode Energy Star 5.0 requires less than 1watt power consumption, whereas Philips monitors consume less than 0.5 watts. Further details can be obtained from www.energystar.gov



Issue date 2013-06-07

Version: 1.0.1

© 2013 Koninklijke Philips N.V. All Rights reserved.

Specifications are subject to change without notice. Trademarks are the property of Koninklijke Philips N.V. or their respective owners.

12 NC: 8670 000 93568 EAN: 87 12581 65556 3

www.philips.com