

PHILIPS



C-Line Display

Signage Solutions

75"

Powered by Windows

350cd/m²



75BDL8051C

Interactive meeting display

high-end capacitive multi-touch technology

Maximise engagement and inspire collaboration with an interactive Philips C-Line display. These Windows powered displays are made to withstand heavy daily usage, and feature up to 10 touchpoints, edge-to-edge glass and flush design.

Smart and powerful

- Anti-glare toughened glass
- Whiteboard mode built-in
- Fast and easy video conferencing
- Install and use your preferred apps and features
- Powered by Windows 10
- Crestron Connected certified
- Annotate over any source and save screenshots

Interactive and collaborative

- Operate, monitor and maintain with CMND & Control
- HID Capacitive Touch with USB Plug & Play
- Works with iOS, Android, Windows, Mac
- Wireless screen sharing & advanced collaboration

Highlights

Wireless screen sharing

Display four feeds on the one screen. Use your existing Wi-Fi network to instantly and securely connect devices, or use the two included HDMI dongles to cast directly to the screen without needing to connect to your secured/protected network.


HID Capacitive Touch

Capacitive Touch gives you the cutting edge appearance of edge to edge glass with a bezel width of just 1.5 mm! Create a memorable interactive experience with up to 10 touchpoints at the same time. Perfect for collaborative and competitive applications, this display connects your audience with any content - making it ideal for education, public venues, corporate, hospitality, and retail settings.

Powered by Windows 10

Powerful Core i7 processor with nVidia GPU. Runs all your favorite apps like Zoom, Skype (included) and MS Teams, MS Office, (not included)

CMND & Control



Run your display network over a local (LAN) connection. CMND & Control allows you to perform vital functions like controlling inputs and monitoring display status. Whether you're in charge of one screen or 100.

Whiteboard mode built-in

Inspire agile collaboration with whiteboard mode. Simply activate this feature to turn your display into a blank canvas that can be drawn on

by multiple users by hand or with dedicated display markers. Everything on screen can then be captured for easy printing or file sharing.

Fast and easy video conference

Ready to use video conferencing software makes one-to-one or group video calls easier than ever. Simply use your own camera or add the optional Logitech Meetup bundle for an all-in-one ConferenceCam solution.

Crestron Connected certified

Integrate this Philips Professional Display to your Crestron network for full remote control via your laptop, desktop or mobile device. Switch the display on and off, schedule content, manage settings, and easily connect external devices. Crestron Connected® provides a fast, reliable and secure enterprise level solution for for system control.

Specifications

Picture/Display

Diagonal screen size (metric): 189.3 cm
Diagonal screen size (inch): 74.5 inch
Aspect ratio: 16:9
Panel resolution: 3840 x 2160
Pixel pitch: 0.4935 (H) x 0.4935 (V)
Optimum resolution: 3840x 2160 @ 60Hz
Brightness: 350 cd/m²
Display colors: 1.07 billion
Contrast ratio (typical): 1000:1
Dynamic contrast ratio: 500,000:1
Response time (typical): 8 ms
Viewing angle (horizontal): 178 degree
Viewing angle (vertical): 178 degree
Picture enhancement: 3/2 - 2/2 motion pull down, Motion compens. deinterlacing, 3D MA deinterlacing, Dynamic contrast enhancement, Progressive scan
Operating system: Windows 10

Connectivity

Audio output: 3.5mm Jack (x2)
Video input: Display Port 1.2 (x1), DVI-I (x 1), HDMI 2.0 (x4), USB-C, USB 2.0 (x2), USB 3.0 (x2)
Audio input: 3.5mm Jack (x1)
Other connections: OPS, micro SD
Video output: DisplayPort 1.2 (x1), DVI - D (x1), HDMI 2.0 (x2)
External control: RJ45, RS232C (in/out) 2.5 mm jack, IR (in/out) 3.5 mm jack

Convenience

Placement: Landscape, Landscape (18/7)
Screen saving functions: Pixel Shift, Low Bright
Keyboard control: Hidden, Lockable

Signal loop through: RS232, IR Loopthrough

Ease of installation: Smart Insert
Energy saving functions: Smart Power
Network controllable: RJ45, RS232
DPMS power saving system

Sound

Built-in speakers: 2 x 20W RMS

Power

Mains power: 100 ~ 240 VAC, 50 ~ 60 Hz
Consumption (Typical): 240 W
Consumption (Max): 340 W
Standby power consumption: <0.5 W
Energy Label Class: G

Supported Display Resolution

Computer formats: 1920 x 1200, 60Hz, 1920 x 1080, 60Hz, 1680 x 1050, 60Hz, 1600 x 1200, 60Hz, 1600 x 900, 60Hz, 1440 x 1050, 60Hz, 1440 x 900, 60, 75Hz, 1400 x 1050, 60, 75Hz, 1366 x 768, 60Hz, 1360 x 768, 60Hz, 1280x1024, 60,67,75Hz, 1280 x 960, 60Hz, 1280 x 800, 60,75Hz, 1280 x 768, 60Hz, 75Hz, 1280 x 720, 60,70Hz, 1152 x 900, 66Hz, 1152 x 864, 60, 70, 75Hz, 1024x768, 60,70Hz, 960x720, 75Hz, 848 x 480, 60Hz, 832 x 624, 75Hz, 800 x 600, 56, 60, 72, 75Hz, 720 x 400, 70Hz, 640 x 350, 70Hz, 640 x 480, 60, 67, 72, 75Hz
Video formats: 1080p, 50, 60Hz, 576i, 50Hz, 576p, 50Hz, 480i, 60Hz, 480p, 60Hz, 1080i, 50, 60Hz, 4K x 2K, 50,60Hz, 720p, 50, 60Hz
UHD Formats: 3840 x 2160, 24, 25, 30, 60 Hz, 3840 x 2160, 50 Hz

Dimensions

Smart Insert mount: 6*M4*L6(200x100)
Set Width: 1703.80 mm
Product weight: 66.5 kg
Set Height: 982.00 mm
Set Depth: 84.20(@wall mount), 99.70(@max) mm
Set Width (inch): 67.08 inch
Set Height (inch): 38.66 inch
Wall Mount: 600(H)x400(V) mm, M8
Set Depth (inch): 3.31(@wall mount), 3.93(@max) inch
Bezel width: 1.50 mm(even)
Product weight (lb): 146.61 lb

Operating conditions

Altitude: 0 ~ 3000 m
Temperature range (operation): 0 ~ 40 °C
MTBF: 50,000 hour(s)
Relative humidity: 20 ~ 80%(operating), 5 ~ 95% (storage) %
Temperature range (storage): -20 ~ 60 °C

Multimedia Applications

USB Playback Video: ASF, AVI, FLV, MKV, MP4, MPEG, MPG, TS, VOB, WEBM, WMV, DAT
USB Playback Picture: BMP, JPEG, JPG, PNG
USB Playback Audio: AAC, M4A, MP3, WMA

Internal Player

CPU: Intel Core i7
GPU: Nvidia GT730
Storage: 256GB eMMC
RAM: 8GB DDR4

Multi-touch Interactivity

Touch points: 10 simultaneous touch points

Accessories

Included Accessories: Philips logo (x1), RS232 Daisy chain cable (x1), Cleaning cloth (x1), DVI - I Cable (1.8m) (x1), HDMI Cable (3m) (x1), IR sensor cable (1.8 m) (x1), M2 Screw (x2), M3 screw (x2), Power cable (x3), Touch Pen (x2), USB A to B cable (3m) (x1), USB Cover (x1), AAA batteries (x1), HDMI transmitter (x2), Quick start guide (x1), Remote control (x1), RS232 cable (3 m) (x1)

Miscellaneous

On-Screen Display Languages: English, French, German, Spanish, Polish, Turkish, Russian, Italian, Simplified Chinese, Traditional Chinese, Arabic, Japanese, Danish, Dutch, Finnish, Norwegian, Portuguese, Swedish
Warranty: 3 year warranty
Regulatory approvals: CE, RoHS, CB, CU, EMF, EPA, FCC, Class A, ETL, PSB

Philips 75BDL8051C
Version: 5.1
Reference Date: 2019/12/18

