



#### D-Line Display

- 43"
- Powered by Android
- 450cd/m<sup>2</sup>

43BDL4050D/11

## Chasing innovation

powered by Android

Amaze your guests with a smarter, faster, signage display. With integrated WiFi and designed for running Android apps, it's the next evolution in signage solutions.

### Benefits

#### Care about you, your business and your audience

- Keep your content up and running with FailOver
- SmartPower for energy saving
- Ensure your content is running with automatic screenshots

#### Maximizing the impact of your message

- Connect and control your content via the cloud

#### Innovative solutions for any signage application

- Free and easy-to-use content management with SmartCMS
- Save and play content with internal memory
- Enhance your connectivity with an integrated mPCIe slot.
- Android: Run your own app or choose your favorite app to run
- Integrated WiFi

**PHILIPS**


## Features

### FailOver



Keeping your content up and running is critical for demanding commercial applications. While it is unlikely you will face a content disaster, FailOver provides content protection with a revolutionary technology that plays back-up content on screen in the event of a media player failure. FailOver automatically kicks in when the primary input fails. Simply select a primary input connection and a FailOver connection and your ready for instant protection.

### SmartPower



The backlight intensity can be controlled and pre-set by the system to reduce the power consumption by up to 50%, which saves substantially on energy costs.

### PCI Slot

With an integrated PCI slot, you can connect a WiFi/bluetooth or 4G LTE module, allowing for even greater communication with the display. Machine to machine communication is also enhanced, with numerous configurations

available for customers to use, such as the ability to expand product features or signal-handling capability.

### Powered by Android

With Android OS integrated into the display, you can work with the most developed OS on the planet and save your own app directly into the display. Or, choose from the large library of Android apps and play content from there. With the built-in scheduler, you can daypart your apps and content based on your customer and time of day and with the auto orientation feature, showing content in portrait or landscape is as simple as turning the display.

### SmartBrowser



Connect and control your content via the cloud with the integrated HTML5 browser. Using the Chromium based browser, design your content online and connect a single display, or your complete network. Show content in both landscape and portrait mode, with fullHD resolution. Streaming content can also be shown in a PIP (picture-in-picture) window. Simply connect the display to the internet using WiFi or with an RJ45 cable, and enjoy your own created playlists

### Proof of Play

Content is king, and with the automatic screenshot feature, you can make sure that your content is up and running at all times. Screenshots are taken throughout the day, which are then stored in the FTP server. From there, the screenshots can be viewed no matter when, or where you are.

## Specifications

[field not found 'disclaimer\_text']

### Picture/Display

Diagonal screen size (inch)	42.5 inch
Diagonal screen size (metric)	107.95 cm
Panel resolution	1920x1080p
Optimum resolution	1920 x 1080 @ 60Hz
Brightness	450 cd/m <sup>2</sup>
Contrast ratio (typical)	1100:1
Dynamic contrast ratio	500,000:1
Aspect ratio	16:9
Response time (typical)	12 ms
Pixel pitch	0.49 x 0.49 mm
Display colors	16.77 million
Viewing angle (horizontal)	178 degree
Viewing angle (vertical)	178 degree

### Connectivity

Video input	DisplayPort (1.2) HDMI (x2) DVI-D USB 2.0 (Type A) (x2) USB 2.0 (Type B)
Video output	DisplayPort DVI-I
Audio input	3.5 mm jack
Audio output	3.5mm jack

Other connections	micro SD micro USB
External control	RJ45 RS232C (in/out) 2.5 mm jack IR (in/out) 3.5 mm jack

### Supported Display Resolution

Computer formats	1920 x 1080, 60Hz 1440 x 900, 60Hz 1366 x 768, 60Hz 1360 x 768, 60Hz 1280 x 800, 60Hz 1280 x 768, 60Hz 1024 x 768, 60Hz 800 x 600, 56, 60, 72, 75Hz 640 x 480, 60, 67, 72, 75Hz
Video formats	1080p, 50, 60Hz 1080i, 50, 60Hz 720p, 50, 60Hz 576i, 50Hz 576p, 50Hz 480p, 60Hz 480i, 60Hz

### Dimensions

Set Width (inch)	39.47 inch
Set Height (inch)	23.26 inch
Set Depth (inch)	2.52 inch
Set Width (mm)	1002.6 mm
Set Height (mm)	590.8 mm
Set Depth (mm)	64.0 mm

Bezel width 9.6 mm (T/L/R), 15.7 mm (B)  
 Product weight (lb) 23.59 lb  
 Product weight 10.7 kg  
 VESA Mount 400 x 400 mm, M6

#### Convenience

Memory 16GB eMMC  
 Placement Landscape  
 Portrait  
 Tiled Matrix Up to 15x 15  
 Keyboard control Hidden  
 Lockable  
 Signal Loop Through DVI  
 VGA  
 RS232  
 IR Loophthrough  
 DisplayPort  
 Network controllable RJ45  
 RS232  
 One Wire (HDMI-CEC)  
 HDMI (One Wire)  
 Energy saving functions Smart Power  
 Screen saving functions Pixel Shift, Low Bright  
 Other convenience Carrying handles  
 G sensor

#### Power

Consumption (On mode) 59 W  
 Standby power consumption <0.5 W  
 Mains power 100 ~ 240 VAC, 50 ~ 60 Hz

#### Operating conditions

Temperature range (operation) 0 ~ 40 °C  
 Temperature range (storage) -20 ~ 60 °C  
 Relative humidity 20 ~ 80 %  
 Altitude 0 ~ 3000 m  
 MTBF 60,000 hour(s)

#### Sound

Built-in speakers 2 x 10W RMS

#### Accessories

Included accessories Remote Control  
 Batteries for remote control  
 Quick start guide  
 RS232 cable  
 VGA cable  
 AC Power Cord  
 Edge alignment plates  
 Stand BM05922(Optional)  
 Included Accessories DVI-VGA adapter  
 Philips logo  
 RS232 daisy-chain cable

#### Multimedia Applications

USB Playback Audio AAC  
 MP3  
 WMA  
 M4A  
 MP1  
 MP2  
 USB Playback Picture BMP  
 GIF  
 JPEG  
 JPG  
 PDF  
 PNG  
 USB Playback Video 3GP  
 AVI  
 FLV  
 MKV  
 MOV  
 MP4  
 TS

#### Miscellaneous

On-Screen Display Languages English  
 French  
 German  
 Spanish  
 Polish  
 Turkish  
 Russian  
 Italian  
 Simplified Chinese  
 Traditional Chinese  
 Arabic  
 Japanese  
 Regulatory approvals CE  
 FCC, Class B  
 UL/cUL  
 CCC  
 C-Tick  
 RoHS  
 GOST  
 BSMI  
 CB  
 J-Moss  
 PSE  
 VCCI  
 Warranty 3 year warranty

#### Internal Player

CPU Quad Core Cortex A9 1.8GHz  
 GPU ARM Mali400 Quad Core 533MHz  
 Memory 2GB DDR3  
 Storage 16GB EMMC



data subject to change  
 2018, April 7

Version: 4.0.1  
 EAN: 8712581739539

© 2018 Koninklijke Philips N.V.  
 All rights reserved.

Specifications are subject to change without notice. Trademarks are the property of Koninklijke Philips N.V. or their respective owners.

[www.philips.com](http://www.philips.com)