

PHILIPS

LCD monitor with
LED backlight

V Line

22" (55.9 cm)

220V4LSB



Enjoy great LED pictures in vivid colours

Enjoy vivid LED pictures with this attractive, glossy design display. Equipped with SmartControl lite, it's a great choice!

Vivid pictures every time

- LED technology for vivid colours
- SmartContrast for rich black details
- Bigger viewing area with 16:10 format
- Easy display performance tuning with SmartControl Lite

Modern design

- Attractive glossy design
- Small footprint saves space
- VESA mount allows for flexibility

Greener every day

- Mercury Free eco-friendly display
- Energy Star for energy efficiency and low power consumption
- Low power consumption saves energy bills

Highlights

LED technology

White LED's are solid state devices which light up to full, consistent brightness faster saving startup time. LED's are free from mercury content, which allows for eco-friendly recycling and disposal process. LED's allow for better dimming control of the LCD backlight, resulting in a super high contrast ratio. It also gives superior colour reproduction thanks to consistent brightness across the screen.

SmartControl Lite

SmartControl Lite is the next generation 3D icon-based GUI monitor control software. This allows the user to fine-tune most parameters of the monitor like Colour, Brightness, screen calibration, Multimedia, ID management etc. with the mouse.

SmartContrast



SmartContrast is a Philips technology that analyses the contents you are displaying, automatically adjusting colours and controlling backlight intensity to dynamically enhance contrast for the best digital images and videos or when playing games where dark hues are displayed. When Economy mode is selected, contrast is adjusted and backlighting fine-tuned for just-right display of everyday office applications and lower power consumption.

Mercury Free

Philips monitors with LED backlighting are free from Mercury, one of the most toxic natural substances, which affects humans and animals. This reduces the environmental impact of the display throughout its lifecycle, from manufacturing to disposal.

Energy Star 5.0

Energy Star is a US EPA sponsored energy efficiency programme also adopted by many other countries. Energy Star certification ensures that you are buying a product which meets the latest power efficiency standards and which operates with maximum power efficiency at all operational levels. New Philips monitors are certified for Energy Star 5.0 specifications and meet or exceed the standard. For example, in sleep mode Energy Star 5.0 requires less than 1 Watt power consumption, whereas Philips monitors consume less than 0.5 Watts. Further details can be obtained from www.energystar.gov



Specifications

Picture/Display

LCD panel type: TFT-LCD
Backlight type: W-LED system
Panel Size: 22 inch/55.9 cm
Effective viewing area: 473.76 (H) x 296.1 (V)
Aspect ratio: 16:10
Optimum resolution: 1680 x 1050 @ 60 Hz
Response time (typical): 5 ms
Brightness: 250 cd/m²
SmartContrast: 10,000,000:1
Contrast ratio (typical): 1000:1
Pixel pitch: 0.282 x 0.282 mm
Viewing angle: 170° (H)/160° (V), @ C/R > 10
Display colours: 16.7 M
Scanning Frequency: 30–83 kHz (H)/56–75 Hz (V)
sRGB

Connectivity

Signal Input: VGA (Analogue), DVI-D (digital, HDCP)
Sync Input: Separate Sync, Sync on Green

Convenience

User convenience: Auto/Down, 4:3 Wide/Up, Brightness/Back, Menu/OK, Power On/Off
OSD Languages: English, French, German, Italian, Portuguese, Russian, Simplified Chinese, Spanish, Turkish

Other convenience: Kensington lock, VESA mount (100 x 100 mm)

Plug and Play Compatibility: DDC/CI, Mac OS X, sRGB, Windows 7, Windows XP

Stand

Tilt: -5/20 degree

Power

On mode: 16.52 W (EnergyStar 5.0 test method)
Standby mode: 0.5 W
Off mode: 0.5 W
Power LED indicator: Operation - White, Standby mode - White (flashing)
Power supply: Built-in, 100–240 VAC, 50–60 Hz

Dimensions

Product with stand (mm): 512 x 416 x 213 mm
Product without stand (mm): 512 x 348 x 48 mm
Packaging in mm (W x H x D): 567 x 421 x 124 mm

Weight

Product with stand (kg): 3.66 kg
Product without stand (kg): 3.32 kg
Product with packaging (kg): 4.83 kg

Operating conditions

Temperature range (operation): 0°C to 40°C °C
Temperature range (storage): -20°C to 60°C °C
Relative humidity: 20%–80% %
Altitude: Operation: +12,000 ft (3658 m), Non-operation: +40,000 ft (12,192 m)
MTBF: 30,000 hour(s)

Sustainability

Environmental and energy: EnergyStar 5.0, EPEAT Silver, RoHS, Lead-free, Mercury Free
Recyclable packaging material: 100 %

Compliance and standards

Regulatory Approvals: BSMI, CE Mark, FCC Class B, GOST, PSB, SASO, SEMKO, TCO certified, TUV/ISO9241-307, UL/cUL, WEEE

Cabinet

Colour: Black
Finish: Glossy (front bezel)/Textured (rear cover)

What's in the box?

Monitor with stand
Cables: VGA, Power
User Documentation

