



Philips  
LED monitor

**E Line**  
21.5" (54.6 cm)

**227E3LHSU**

## Elegant display enhances your viewing experience

Experience awesome LED pictures with natural colors. The elegant design with translucent blue bezel, HDMI and stereo speakers makes it a great choice!

### **Great picture quality**

- 16:9 Full HD display for best viewing experience
- SmartResponse of 2ms
- SmartContrast 20000000:1 for incredible rich black details
- SmartImage Lite for an enhanced LCD viewing experience
- LED technology for natural colors

### **Design that complements any interior**

- Sleek, elegant design complements your home decor
- Modern Touch controls
- Translucent blue bezel with glossy finish

### **Experience true multimedia**

- HDMI-ready for top quality, multimedia experience
- Built-in speakers for audio without desktop clutter

### **Great convenience**

- Easy display performance tuning with SmartControl Lite

# PHILIPS

LED monitor  
E Line 21.5" (54.6 cm)

227E3LHSU/75

# Highlights

## LED technology

White LED's are solid state devices which light up to full, consistent brightness faster saving startup time. LED's are free from mercury content which allows for eco-friendly recycling and disposal process. LED's allow for better dimming control of LCD backlight, resulting in super high contrast ratio. It also gives superior color reproduction thanks to consistent brightness across the screen.

## HDMI Ready



HDMI-ready

An HDMI-ready device has all the required hardware to accept High-Definition Multimedia Interface (HDMI) input. A HDMI cable enables high-quality digital video and audio all transmitted over a single cable from a PC or any number of AV sources (including set-top boxes, DVD players, A/V receivers and video cameras).

## Built-in speakers

A pair of stereo speakers built into a display device. It can be visible front firing, or invisible down firing, top firing, rear firing, etc depending on model and design.

## SmartImage Lite


SmartImage Lite is an exclusive, leading edge Philips technology that analyzes the content displayed on your screen. Based on a scenario you select, SmartImage Lite dynamically enhances the contrast, color saturation and sharpness of images and videos for ultimate display performance - all in real time with the press on a single button.

## 16:9 Full HD



The Full HD screen has the widescreen resolution of 1920 x 1080p. This is the highest resolution of HD sources for the best possible picture quality. It is fully future proof as it supports 1080p signals from all sources, including the most recent like Blu-ray and advanced HD game consoles. The signal processing is extensively upgraded to support this much higher signal quality and resolution. It produces brilliant flicker-free progressive scan pictures with superb brightness and colors.

## SmartContrast ratio 20000000:1



You want the LCD flat display with the highest contrast and most vibrant images. Philips advanced video processing combined with unique extreme dimming and backlight boosting technology results in vibrant images. SmartContrast will increase the contrast with excellent blacklevel and accurate rendition of dark shades and colors. It gives a bright, lifelike picture with high contrast and vibrant colors.

## SmartResponse - 2ms



2ms GtG response time > 2ms GtG response time

SmartResponse is an exclusive Philips overdrive technology that when turned on, automatically adjusts response times to specific application requirements like gaming and movies which require faster response times in order to produce judder, time-lag and ghost image free images.

## Touch controls



Touch controls are intelligent, touch sensitive icons that replace protruding buttons that lets the user adjust the monitor to their requirement. Responding to your lightest touch, Touch control gives the monitor a modern feel.

## SmartControl Lite

SmartControl Lite is the next generation 3D icon based GUI monitor control software. This allows user to fine-tune most parameters of the monitor like Color, Brightness, screen calibration, Multi-media, ID management, etc with the mouse.

## Sleek, elegant design

A sleek, elegant design look that complements home furnishings in any room.

## Translucent blue bezel

Translucent blue bezel with glossy finish



Built-in Speaker



SmartImage Lite



Touch control



SmartControl Lite



SmartResponse 2ms

# Specifications

## Connectivity

- Signal Input: VGA (Analog ), DVI-D (digital, HDCP), HDMI
- Sync Input: Separate Sync, Sync on Green
- Audio (In/Out): Earphone out (3.5 mm jack)x 1, PC audio-in

## Picture/Display

- Panel Size: 21.5 inch / 54.6 cm
- Aspect ratio: 16:9
- LCD panel type: TFT-LCD
- Backlight type: W-LED system
- Pixel pitch: 0.248 x 0.248 mm
- Optimum resolution: 1920 x 1080 @ 60Hz
- Brightness: 250 cd/m<sup>2</sup>
- Display colors: 16.7 M
- Contrast ratio (typical): 1000:1
- SmartContrast: 20,000,000:1
- Response time (typical): 5 ms
- Viewing angle: 176° (H) / 170° (V), @ C/R &gt; 5
- Picture enhancement: SmartImage Lite
- Effective viewing area: 476.64 (H) x 268.11 (V)
- Scanning Frequency: 30 -83 kHz (H) / 56 -75 Hz (V)
- sRGB
- SmartResponse (typical): 2 ms (Gray to Gray)

## Convenience

- Plug & Play Compatibility: DDC/CI, Mac OS X, sRGB, Windows 7
- Built-in Audio: 1.5W x 2
- User convenience: SmartImage lite, Input, Volume, Menu, Power On/Off
- OSD Languages: English, French, German, Italian, Russian, Simplified Chinese, Spanish, Portuguese, Turkish
- Other convenience: Kensington lock

## Stand

- Tilt: -5/+20 degree

## Power

- Power supply: Built-in, 100-240VAC, 50/60Hz
- Off mode: 0.5 W
- On mode: 18.5 W (EnergyStar 5.0 test method)
- Standby mode: 0.5 W
- Power LED indicator: Operation - White, Standby mode- White (blinking)

## Dimensions

- Product with stand (mm): 534 x 408 x 216 mm
- Packaging in mm (WxHxD): 580 x 494 x 106 mm
- Product without stand (mm): 534 x 336 x 41 mm

## Weight

- Product with packaging (kg): 4.96 kg
- Product with stand (kg): 3.68 kg
- Product without stand (kg): 3.46 kg

## Operating conditions

- Temperature range (operation): 0°C to 40°C °C
- MTBF: 30,000 hour(s)
- Relative humidity: 20%-80 %
- Temperature range (storage): -20°C to 60°C °C

## Sustainability

- Environmental and energy: EnergyStar 5.0, EPEAT Silver, RoHS, Mercury Free
- Recyclable packaging material: 100 %

## Compliance and standards

- Regulatory Approvals: BSMI, CE Mark, FCC Class B, GOST, SEMKO, TUV Ergo, TUV/GS, UL/cUL, TCO Certified, PSB, SASO, WEEE

## Cabinet

- Color: Black/ Blue tint
- Finish: Glossy



Issue date 2024-03-24

Version: 4.0.1

EAN: 87 12581 60063 1

© 2024 Koninklijke Philips N.V.  
All Rights reserved.

Specifications are subject to change without notice.  
Trademarks are the property of Koninklijke Philips N.V.  
or their respective owners.

[www.philips.com](http://www.philips.com)