



Curved LCD monitor with Ultra Wide-Color

- E Line
- 32 (31.5" / 80 cm diag.)
- Full HD (1920 x 1080)

328E9QJAB/00

## Stunning color, ultimate immersion

Experience real immersion with Philips Curved Monitors. The 32" curved E line monitor offers a truly immersive experience with stunning Full HD image quality. Ultra wide-color tech gives color quality that brings your images alive!

### Benefits

Curved design inspired by the world around us

- Curved display design for more immersive experience

Superb Picture Quality

- Ultra Wide-Color wider range of colors for a vivid picture
- VA display delivers awesome images with wide viewing angles
- 16:9 Full HD display for crisp detailed images
- Effortlessly smooth gameplay with AMD FreeSync™ technology

Features designed for you

- Narrow border display for a seamless appearance
- Less eye fatigue with Flicker-free technology
- LowBlue Mode for easy on-the-eyes productivity
- HDMI ensures universal digital connectivity
- Built-in stereo speakers for multimedia
- DisplayPort connection for maximum visuals

# PHILIPS

## Features

### Curved display design



Desktop monitors offer a personal user experience, which suits a curve design very well. The curved screen provides a pleasant yet subtle immersion effect, which focuses on you at the center of your desk.

### Ultra Wide-Color Technology



Ultra Wide-Color Technology delivers a wider spectrum of colors for a more brilliant picture. Ultra Wide-Color wider "color gamut" produces more natural-looking greens, vivid reds and deeper blues. Bring media entertainment, images, and even productivity more alive and vivid colors from Ultra Wide-Color Technology.

### VA display



Philips VA LED display uses an advanced multi-domain vertical alignment technology which gives you super-high static contrast ratios for extra vivid and bright images. While standard office applications are handled with ease, it is especially suitable for photos, web-browsing, movies, gaming, and demanding graphical applications. It's optimized pixel management technology gives you 178/178 degree extra wide viewing angle, resulting in crisp images.

### 16:9 Full HD display



Picture quality matters. Regular displays deliver quality, but you expect more. This display features enhanced Full HD 1920 x 1080 resolution. With Full HD for crisp detail paired with high brightness, incredible contrast and realistic colors expect a true to life picture.

### Ultra-smooth gaming



Gaming shouldn't be a choice between choppy gameplay or broken frames. With the new Philips monitor it doesn't have to be. Get fluid, artifact-free performance at virtually any framerate with AMD FreeSync™ technology, smooth quick refresh and ultra-fast response time.

### UltraNarrow Border



The new Philips displays feature ultra-narrow borders which allow for minimal distractions and maximum viewing size. Especially suited for multi-display or tiling setup like gaming, graphic design and professional applications, the ultra-narrow border display gives you the feeling of using one large display.

### Flicker-free technology



Due to the way brightness is controlled on LED-backlit screens, some users experience flicker on their screen which causes eye fatigue. Philips Flicker-free Technology applies a new solution to regulate brightness and reduce flicker for more comfortable viewing.

### LowBlue Mode



Studies have shown that just as ultra-violet rays can cause eye damage, shortwave length blue light rays from LED displays can cause eye damage and affect vision over time. Developed for wellbeing, Philips LowBlue Mode setting uses a smart software technology to reduce harmful shortwave blue light.

## HDMI Ready



An HDMI-ready device has all the required hardware to accept High-Definition Multimedia Interface (HDMI) input. A HDMI cable enables high-quality digital video and audio all transmitted over a single cable from a PC or any number of AV sources (including set-top boxes, DVD players, A/V receivers and video cameras).

## Built-in stereo speakers

A pair of high quality stereo speakers built into a display device. It can be visible front firing, or invisible down firing, top firing, rear firing, etc depending on model and design.

## DisplayPort connection



DisplayPort is a digital link from PC to Monitor without any conversion. With higher capabilities than DVI standard, it is fully capable to support up to 15meter cables and 10.8 Gbps/sec data transfer. With this high performance and zero latency, you get the fastest imaging and refresh rates - making DisplayPort the best choice for not only general office or home use, but also for the demanding gaming and movies, video editing and more. It also keeps interoperability in mind via use of various adapters.

## Specifications

[field not found 'disclaimer\_text']

### Picture/Display

LCD panel type	VA LCD
Backlight type	W-LED system
Panel Size	31.5 inch / 80 cm
Display Screen Coating	Anti-Glare, Haze 25%
Effective viewing area	698.4 (H) x 392.85 (V) - at a 1800R curvature*
Aspect ratio	16:9
Maximum resolution	1920 x 1080 @ 75 Hz*
Pixel Density	70 PPI
Response time (typical)	4 ms (Gray to Gray)*
Brightness	250 cd/m <sup>2</sup>
Contrast ratio (typical)	3000:1
SmartContrast	20,000,000:1
Pixel pitch	0.364 x 0.364 mm
Viewing angle	178° (H) / 178° (V) @ C/R > 10
Flicker-free	Yes
Picture enhancement	SmartImage game
Color gamut (typical)	NTSC 103%*, sRGB 122.8%*
Display colors	16.7 M
Scanning Frequency	53 - 84 kHz (H) / 48 -75 Hz (V)
sRGB	Yes
FreeSync	Yes
LowBlue Mode	Yes

### Connectivity

Signal Input	VGA (Analog ) DisplayPort HDMI (digital, HDCP)
Sync Input	Separate Sync Sync on Green
Audio (In/Out)	PC audio-in Headphone out

### Convenience

Built-in Speakers	3 W x 2
User convenience	Power On/Off Menu Brightness Input SmartImage Game
OSD Languages	Brazil Portuguese Czech Dutch English Finnish

- French
- German
- Greek
- Hungarian
- Italian
- Japanese
- Korean
- Polish
- Portuguese
- Russian
- Simplified Chinese
- Spanish
- Swedish
- Traditional Chinese
- Turkish
- Ukrainian
- Kensington lock
- VESA mount (100x100mm)
- DDC/CI
- Mac OS X
- sRGB
- Windows 10 / 8.1 / 8 / 7

### Stand

Tilt	-5/20 degree
------	--------------

### Power

On mode	38.26 W (typ.)
Standby mode	< 0.5 W (typ.)
Off mode	< 0.3 W (typ.)
Energy Label Class	B
Power LED indicator	Operation - White Standby mode- White (blinking)
Power supply	Internal 100-240VAC, 50-60Hz

### Dimensions

Product with stand (mm)	713 x 525 x 236 mm
Product without stand (mm)	713 x 425 x 52 mm
Packaging in mm (WxHxD)	827 x 626 x 233 mm

### Weight

Product with stand (kg)	6.78 kg
Product without stand (kg)	6.40 kg

Product with packaging (kg)	10.45 kg
<b>Operating conditions</b>	
Temperature range (operation)	0 to 40 °C
Temperature range (storage)	-20 to 60 °C
Relative humidity	20%-80 %
Altitude	Operation: +12,000ft (3,658m), Non-operation: +40,000ft (12,192m)
MTBF	50,000 hrs (excluding backlight) hour(s)

#### Sustainability

Environmental and energy	RoHS Lead-free Mercury Free WEEE
Recyclable packaging material	100 %

#### Compliance and standards

Regulatory Approvals	CE Mark FCC Class B CU-EAC TUV/ISO9241-307 RCM BSMI PSB cETLus MEPS CB
----------------------	---

#### Cabinet

Color Finish	Black / Silver Glossy
--------------	--------------------------

#### What's in the box?

Monitor with stand	Yes
Cables	HDMI cable, Power cable
User Documentation	Yes

\* Radius of the arc of the display curvature in mm

\* The maximum resolution works for either HDMI input or DP input.

\* Response time value equal to SmartResponse

\* NTSC Area based on CIE1976

\* sRGB Area based on CIE 1931

\* 2015 Advanced Micro Devices, Inc. All rights reserved. AMD, the AMD Arrow logo, FreeSync and combinations thereof are trademarks of Advanced Micro Devices, Inc. Other names are for informational purposes only and may be trademarks of their respective owners.

\* The monitor may look different from feature images.



data subject to change  
2019, April 20

Version: 5.0.1  
EAN: 8712581751036

© 2019 Koninklijke Philips N.V.  
All rights reserved.

Specifications are subject to change without notice. Trademarks are the property of Koninklijke Philips N.V. or their respective owners.

[www.philips.com](http://www.philips.com)