

Curved UltraWide display with USB-C dock



- P Line
- 34" (86.36 cm)
- 3440 x 1440 (WQHD)

349P7FUBEB/00

## Simplify your connections

with revolutionary USB-C

See more and do more with the Philips Brilliance 34" curved ultra-wide display. A crystal-clear wide Quad HD curved display puts you at the center of the attention. All-in-one USB-C and a height-adjustable stand make for the ultimate set-up

### Benefits

#### Advanced design for your greatest creations

- Curved display design for more immersive experience
- Narrow border display for a seamless appearance

#### Brilliant performance

- Ultra Wide-Color wider range of colors for a vivid picture
- CrystalClear images with UltraWide QHD 3440 x 1440 pixels
- MultiView enables simultaneous dual connect and view
- 100Hz refresh rates for ultra-smooth images

#### Features for the way you work

- All your connections through one USB-C cable
- USB 3.0 Hub for convenient access and fast charging

#### Designed for comfortable productivity

- Tilt, swivel and height-adjust for an ideal viewing position
- LowBlue Mode for easy on-the-eyes productivity

# PHILIPS

Features

Curved display design



Desktop monitors offer a personal user experience, which suits a curve design very well. The curved screen provides a pleasant yet subtle immersion effect, which focuses on you at the center of your desk.

UltraNarrow Border



The new Philips displays feature ultra-narrow borders which allow for minimal distractions and maximum viewing size. Especially suited for multi-display or tiling setup like gaming, graphic design and professional applications, the ultra-narrow border display gives you the feeling of using one large display.

USB-C Docking



The new USB 3.1 Type-C cable with features a slim and reversible connector and offers easy one-cable-docking. With USB 3.1 you get the fastest data speeds, 20 times as fast as USB 2.0, allowing you to transfer data from a HDD to your PC faster than ever. Simplify by connecting all your peripherals to your monitor as a dock with one cable to the notebook, including high resolution video output from your PC to monitor. Additionally, USB-C with power delivery, can even enable you to power and charge your notebook from the monitor, eliminating the need for extra power cables.

Ultra Wide-Color Technology



Ultra Wide-Color Technology delivers a wider spectrum of colors for a more brilliant picture. Ultra Wide-Color wider "color gamut" produces more natural-looking greens, vivid reds and deeper blues. Bring, media entertainment, images, and even productivity more alive and vivid colors from Ultra Wide-Color Technology.

Specifications

[field not found 'disclaimer\_text']

Picture/Display

LCD panel type	MVA
AMD FreeSync™ technology	Yes
Backlight type	W-LED system

UltraWide CrystalClear images



These Philips screens deliver CrystalClear, UltraWide Quad HD 3440 x 1440 pixel images. Utilizing high performance panels with high-density pixel count, 178/178 wide viewing angles, these new displays will make your images and graphics come alive. The UltraWide 21:9 format enables more productivity with more room for side-by-side comparisons and more viewable spreadsheet columns. Whether you are demanding professional requiring extremely detailed information for CAD-CAM solutions, or a financial wizard working on huge spreadsheets, Philips displays delivers CrystalClear images.

MultiView technology

With the ultra-high resolution Philips MultiView display you can now experience a world of connectivity. MultiView enables active dual connect and view so that you can work with multiple devices like a PC and notebook simultaneously, for complex multi-tasking.

100Hz Fast refresh

For gaming and video performance, you demand display with lag free, ultra-smooth images. This Philips display redraws the screen image up--to 100 times per second, much faster than a standard display. A lower frame rate can make enemies appear to jump from spot to spot on the screen, making them difficult targets to hit. With 100Hz frame rate, you get those critical missing images on the screen which shows enemy movement in ultra-smooth motion so you can easily target them.

LowBlue Mode



Studies have shown that just as ultra-violet rays can cause eye damage, shortwave length blue light rays from LED displays can cause eye damage and affect vision over time. Developed for wellbeing, Philips LowBlue Mode setting uses a smart software technology to reduce harmful shortwave blue light.

USB 3.0 Hub with FastCharge

Super Speed USB 3.0 deploys 5.0 gbit/s transfer rate, which is about 10 times faster than USB 2.0 standard significantly reducing data transfer time saving you time and money. With more bandwidth, super speed transfer rates, better power management and superior overall performance, USB 3.0 sets the latest global standard allowing you to use the large capacity storage devices. Now you don't have to wait so long for devices to charge. New FastCharge enables quick charging to charge and go. USB 3.0 is also backward compatible with USB 2.0 devices.

Panel Size	34 inch / 86.36 cm
Display Screen	Anti-Glare, Haze 25%
Coating	
Color gamut (typical)	NTSC 99.8%*, sRGB 117.3%*

Effective viewing area	797.22 (H) x 333.72 (V) - at a 1800 R curvature*
Aspect ratio	21:9
Maximum Resolution	3440 x 1440 @ 100Hz*
Pixel Density	109.68 PPI
Response time (typical)	4 ms (Gray to Gray)*
Brightness	300 cd/m <sup>2</sup>
Contrast ratio (typical)	3,000:1
SmartContrast	100,000,000 :1
Pixel pitch	0.232 x 0.232 mm
Viewing angle	178° (H) / 178° (V) @ C/R > 10
Flicker-free	Yes
Picture enhancement	SmartImage
Display colors	16.7 M
Scanning Frequency	30 - 160 kHz (H) / 40 - 102 Hz (V) (DisplayPort, USB-C), 23 - 102 Hz (V) (HDMI)
sRGB	Yes
LowBlue Mode	Yes

#### Connectivity

Signal Input	DisplayPort 1.2, HDMI 2.0 x 1, USB-C (PD up to 65 W)
USB	USB 3.0x3 (1 w/fast charging)*
Sync Input	Separate Sync Sync on Green
Audio (In/Out)	PC audio-in Headphone out

#### Convenience

Built-in Speakers	5 W x 2
MultiView	PIP/PBP mode* 2x devices
User convenience	Menu/OK User/Down SmartImage/Return Multiview/Up Power On/Off SmartControl
Control software	Brazil Portuguese Czech Dutch English French Finnish German Greek Hungarian Italian Japanese Korean Portuguese Polish Russian Simplified Chinese Spanish Swedish Traditional Chinese Turkish Ukrainian
Other convenience	Kensington lock VESA mount (100x100mm)
Plug & Play Compatibility	DDC/CI Mac OS X sRGB Windows 10 / 8.1 / 8 / 7

#### Stand

Height adjustment	180 mm
-------------------	--------

Swivel	-170/170 degree
Tilt	-5/20 degree

#### Power

On mode	67.09 W (typ.)
Standby mode	< 0.5 W (typ.)
Off mode	< 0.3 W (typ.)
Power LED indicator	Operation - White Standby mode- White (blinking)
Power supply	External 100-240VAC, 50-60Hz

#### Dimensions

Product with stand (mm)	810 x 621 x 311 mm
Product without stand (mm)	810 x 369 x 98 mm
Packaging in mm (WxHxD)	944 x 578 x 224 mm

#### Weight

Product with stand (kg)	9.60 kg
Product without stand (kg)	6.60 kg
Product with packaging (kg)	14.88 kg

#### Operating conditions

Temperature range (operation)	0°C to 40°C °C
Temperature range (storage)	-20°C to 60°C °C
Relative humidity	20%-80 %
Altitude	Operation: +12,000ft (3,658m), Non-operation: +40,000ft (12,192m)
MTBF	50,000 (Excluding backlight) hour(s)

#### Sustainability

Environmental and energy	RoHS Mercury Free WEEE
Recyclable packaging material	100 %

#### Compliance and standards

Regulatory Approvals	CE Mark CU-EAC RCM CB GS TUV/ISO9241-307 SEMKO MEPS
----------------------	--

#### Cabinet

Color	Black
Foot	Black / Silver
Finish	Texture

#### What's in the box?

Monitor with stand	Yes
Cables	USB-C to USB-C cable, USB-C to USB-A cable, HDMI cable, DP cable, Audio cable, Power cable
User Documentation	Yes

- \* Radius of the arc of the display curvature in mm
- \* The maximum resolution works for either HDMI, DP or USB-C input.
- \* For Video transmission via USB-C, your Notebook/device must support USB-C DP Alt mode
- \* Activities such as screen sharing, on-line streaming video and audio over the Internet can impact your network performance. Your hardware, network bandwidth and its performance will determine overall audio and video quality.
- \* For USB-C power and charging function, your Notebook/device must support USB-C standard Power Delivery specifications. Please check with your Notebook user manual or manufacturer for more details.
- \* Response time value equal to SmartResponse
- \* NTSC Area based on CIE1976
- \* sRGB Area based on CIE1931
- \* 2020 Advanced Micro Devices, Inc. All rights reserved. AMD, the AMD Arrow logo, AMD FreeSync™ and combinations thereof are trademarks of Advanced Micro Devices, Inc. Other product names used in this publication are for identification purposes only and may be trademarks of their respective companies.
- \* Cannot support USB-C vs HDMI for PIP/PBP at the same time
- \* The monitor may look different from feature images.



data subject to change  
2021, November 28

Version: 7.0.1  
EAN: 8712581752279

© 2021 Koninklijke Philips N.V.  
All rights reserved.

Specifications are subject to change without notice. Trademarks are the property of Koninklijke Philips N.V. or their respective owners.

[www.philips.com](http://www.philips.com)