



Philips Signage Solutions  
Q-Line Display

65"

Direct LED Backlight  
Ultra HD

**SignageSolutions**



65BDL3510Q

## Stand out

Easy-setup 18/7 display.

Inform and enthrall with a Philips Q-Line Professional Full HD Display. This reliable solution can be up and running as quickly as you need-with no additional hardware.

### **Effortless setup. Total control.**

- Operate, monitor and maintain with CMND & Control
- Schedule what you want, when you want with SmartPlayer

### **Cost-effective system solution**

- Energy-saving automatic backlight control
- Integrated media player. Easily schedule USB content
- Easy control. Remotely manage networked displays
- FailOver ensures content is always playing

### **Superb picture. Ultra-high brightness.**

- Ultra-HD. Rich images. Stunning contrast

**PHILIPS**

# Highlights

## CMND & Control



Run your display network over a local (LAN) connection. CMND & Control allows you to perform vital functions like controlling inputs and monitoring display status. Whether you're in charge of one screen or 100.

## Integrated media player

Easily schedule content to play from USB. Your Philips Professional Display will wake from

standby to play the content you want, and then return to standby once playback is done.

## FailOver



From waiting room to meeting room, never show a blank screen. FailOver lets your Philips Professional Display switch automatically between primary and secondary inputs ensuring content keeps playing even if the primary source goes down. Simply set a list of

alternate inputs to be sure your business is always on.

## SmartPlayer



Turn your USB into a true cost effective digital signage device. Simply save your content (video, audio, pictures) on your USB and plug into your display. Create your playlist and schedule your content via the on screen menu, and enjoy your own created playlists anytime, anywhere.

# Specifications

## Picture/Display

- Diagonal screen size: 64.5 inch / 163.9 cm
- Panel resolution: 3840 x 2160
- Optimum resolution: 3840 x 2160 @ 60 Hz
- Brightness: 400 cd/m<sup>2</sup>
- Contrast ratio (typical): 1300:1
- Dynamic contrast ratio: 500,000:1
- Response time (typical): 9 ms
- Aspect ratio: 16:9
- Viewing angle (H / V): 178 / 178 degree
- Pixel pitch: 0.372 x 0.372 mm
- Display colors: 1.07 Billion
- Picture enhancement: 3/2 - 2/2 motion pull down, 3D Combfilter, Motion compens. deinterlacing, Progressive scan, 3D MA deinterlacing, Dynamic contrast enhancement
- Panel technology: IPS
- Clinical image: D-Image preset (dicom part 14 compatible)

## Supported Display Resolution

### Computer formats

| Resolution  | Refresh rate     |
|-------------|------------------|
| 1920 x 1080 | 60Hz             |
| 1680 x 1050 | 60Hz             |
| 1600 x 1200 | 60Hz             |
| 1440 x 900  | 60Hz             |
| 1280 x 1024 | 60Hz             |
| 1280 x 800  | 60Hz             |
| 1280 x 720  | 60Hz             |
| 1152 x 870  | 75Hz             |
| 1024 x 768  | 60, 70, 75Hz     |
| 800 x 600   | 56, 60, 72, 75Hz |
| 720 x 400   | 70Hz             |
| 640 x 480   | 60, 67, 72, 75Hz |
| 1152 x 864  | 75Hz             |
| 832 x 624   | 75Hz             |

### Video formats

| Resolution  | Refresh rate |
|-------------|--------------|
| 3840 x 2160 | 60Hz         |
| 3840 x 2160 | 30Hz         |
| 720p        | 60Hz         |
| 576p        | 50Hz         |
| 576i        | 50Hz         |
| 480p        | 60Hz         |
| 480i        | 60Hz         |
| 1080i       | 50, 60Hz     |
| 1080p       | 50, 60Hz     |

## Connectivity

- Video input: DVI-I (x 1), HDMI 2.0 (x3), USB 2.0 (x2)
- Audio input: 3.5 mm jack
- Audio output: 3.5mm jack
- External control: RS232C (in/out) 2.5 mm jack, IR (in/out) 3.5 mm jack, RJ45
- Other connections: OPS

## Convenience

- Keyboard control: Hidden, Lockable
- Network controllable: RS232, RJ45
- Signal loop through: RS232, IR Loopthrough
- Energy saving functions: Smart Power

- Remote control signal: Lockable
- Tiled Matrix: Up to 15 x 15
- Placement: Landscape, Portrait
- Start-up: Switch on delay, Switch on status, Boot on source
- Start-up window: enable / disable Philips logo
- Ease of installation: Smart Insert

## Dimensions

- Bezel width: 14.9 mm (Even bezel)
- Set dimensions (W x H x D): 1462.3 x 837.3 x 68.9mm(D@wall mount) / 89.9mm(D@handle) mm
- Set dimensions in inch (W x H x D): 57.57 x 32.96 x 2.71(@ wall mount) / 3.54(@ handle) inch
- Product weight: 27.80 kg
- Product weight (lb): 61.29 lb
- Wall Mount: 400 x 400 mm, M8

## Operating conditions

- Altitude: 0 ~ 3000 m
- Temperature range (operation): 0 ~ 40 °C
- Temperature range (storage): -20 ~ 60 °C
- MTBF: 50,000 hour(s)
- Humidity range (operation)[RH]: 20 ~ 80% RH (No condensation)
- Humidity range (storage) [RH]: 5 ~ 95% RH (No condensation)

## Power

- Mains power: 100 - 240V~, 50/60Hz
- Standby power consumption: <0.5W
- Power Saving Features: Smart Power
- Consumption (Max): 290 W
- Consumption (Typical): 135 W
- Energy Label Class: G

## Sound

- Built-in speakers: 2 x 10W RMS

## Accessories

- Included accessories: AC Power Cord, RS232 cable, Remote Control, Batteries for remote control, Quick start guide
- Included Accessories: IR sensor cable (1.8 m) (x1), RS232 daisy-chain cable, HDMI cable (1.8 m) (x1), M3 screw (X1), M4 Screw (x1), Philips logo (x1), USB Cover (x1)

## Multimedia Applications

- USB Playback Video: MPEG, H.264, JPEG, WMV3
- USB Playback Picture: BMP, JPEG, PNG
- USB Playback Audio: AAC, WMA, HEAAC, MPEG

## Miscellaneous

- Warranty: 3 year warranty
- On-Screen Display Languages: Simplified Chinese, Traditional Chinese, English, French, German, Italian, Polish, Russian, Spanish, Turkish, Japanese, Arabic
- Regulatory approvals: CE, CB, BSMI, CU, EPA, ETL, FCC, Class A, VCCI



Issue date 2022-07-14

Version: 1.0.1

12 NC: 8670 001 66091  
EAN: 87 12581 76525 5

© 2022 Koninklijke Philips N.V.  
All Rights reserved.

Specifications are subject to change without notice.  
Trademarks are the property of Koninklijke Philips N.V.  
or their respective owners.

[www.philips.com](http://www.philips.com)