



Philips
LED Monitor

15.6" w (39.6 cm) E-line
1366x768 HD

160EL1SB

LED display: Contrast has never been better!!

This Eco friendly LED display comes with a superb 1000000:1 contrast ratio. With Natural colors, SmartContrast and Glossy finish, the 160EL1 is a great choice for all your needs

Great picture quality

- LED technology ensures natural colors
- SmartContrast 1,000,000:1 for incredible rich black details
- Fast 8ms On/off response time: Great text & graphics display
- 16:9 display for best widescreen gaming and video

Design that complements any interior

- Glossy finish to enhance your decor
- Small footprint to blend into any lifestyle

Environmentally friendly green design

- Mercury Free eco-friendly display
- Energy Star for energy efficiency and low power consumption
- Complies with RoHS standards to care for the environment

Great convenience

- Easy picture format control switching in wide and 4:3 format
- sRGB ensures color matching between display and printouts

PHILIPS

Specifications

Picture/Display

- LCD panel type: TFT-LCD
- Backlight type: W-LED system
- Panel Size: 15.6 inch / 39.6 cm
- Aspect ratio: 16:9
- Optimum resolution: 1366 x 768 @ 60 Hz
- Response time (typical): 8 ms
- Brightness: 250 cd/m²
- SmartContrast: 1,000,000:1
- Pixel pitch: 0.252 x 0.252 mm
- Viewing angle: 110° (H) / 85° (V), @ C/R > 5
- Display colors: 16.7 M
- Scanning Frequency: 30 - 60 kHz (H) / 56 - 76 Hz (V)
- sRGB

Connectivity

- Signal Input: VGA (Analog)
- Sync Input: Separate Sync, Sync on Green

Convenience

- User convenience: Brightness, Menu, Auto, Power On/Off
- OSD Languages: English, French, Russian, Simplified Chinese, Spanish, Portuguese, Korean
- Other convenience: VESA mount (75x75mm), Kensington lock
- Plug & Play Compatibility: DDC/CI, Windows 7/ Vista/XP/2000/98, sRGB

Stand

- Tilt: -5/20 degree

Power

- On mode: 9.5W (EnergyStar 5.0 test method)

- Standby mode: <0.8W
- Off mode: <0.5W
- Power LED indicator: Operation - green, Stand by/ sleep - Amber
- Power supply: Built-in, 100-240VAC, 50/60Hz

Dimensions

- Product with stand (mm): 303 x 376 x 156 mm
- Product without stand (mm): 244 x 376 x 59 mm
- Packaging in mm (WxHxD): 323 x 439 x 145 mm

Weight

- Product without stand (kg): 2.51 kg
- Product with packaging (kg): 4.08 kg
- Product with stand (kg): 2.7 kg

Operating conditions

- Temperature range (operation): 0 - 40 °C
- Temperature range (storage): -20 - 60 °C
- Relative humidity: 20 - 80 %
- MTBF: 40,000 hour(s)

Sustainability

- Environmental and energy: EPEAT Silver, RoHS, EnergyStar 5.0

Compliance and standards

- Regulatory Approvals: CE Mark, FCC, Class B, UL/ cUL

Cabinet

- Color: Black
- Finish: Glossy

Highlights

LED technology

White LED's are solid state devices which light up to full, consistent brightness faster saving startup time. LED's are free from mercury content which allows for eco-friendly recycling and disposal process. LED's allow for better dimming control of LCD backlight, resulting in super high contrast ratio. It also gives superior color reproduction thanks to consistent brightness across the screen.

SmartContrast ratio 1000000:1



With SmartContrast



Without SmartContrast

You want the LCD flat display with the highest contrast and most vibrant images. Philips advanced video processing combined with unique extreme dimming and backlight boosting technology results in vibrant images. SmartContrast will increase the contrast with excellent blacklevel and accurate rendition of dark shades and colors. It gives a bright, lifelike picture with high contrast and vibrant colors.

Mercury Free

Philips monitors with LED backlighting are free of Mercury content, one of the most toxic natural substances, which affects humans and animals. This reduces the environmental impact of the display throughout its life-cycle, from manufacturing to disposal.

Energy Star 5.0

Energy Star is a US EPA sponsored energy efficiency program also adopted by many other countries. Energy Star certification ensures that you are buying a product which meets the latest power efficiency standards which operates with maximum power efficiency at all operational levels. New Philips monitors are certified for Energy Star 5.0 specifications and meet or exceed the standard. For example, in sleep mode Energy Star 5.0 requires less than 1 watt power consumption, whereas Philips monitors consume less than 0.5 watts. Further details can be obtained from www.energystar.gov

Easy picture format control

Philips easy picture format control on OSD is to switch from the 4:3 aspect ratio to the widescreen mode and back again to match the display's aspect ratio with your content for working with wide documents without scrolling or viewing widescreen media in the widescreen mode and distortion-free, native mode display of 4:3 ratio content.



Issue date 2022-05-11

Version: 1.0.2

12 NC: 8670 000 61391
EAN: 87 12581 53360 1

© 2022 Koninklijke Philips N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips N.V.
or their respective owners.

www.philips.com