

Philips Evnia Gaming Monitor Quad HD gaming monitor

Evnia 5000 27" (68.5 cm) 2560 x 1440 (QHD)

27M1N5500ZA

Feel your game

This Philips gaming monitor delivers crystal-clear visuals and smooth gameplay. FreeSync, rapid 170Hz refresh rate with HDR create a polished and lifelike experience. The slim-frame display with Ultra Wide-Color enhances visual immersion.

The gaming advantage is yours

- AMD FreeSync™ Premium; tear free, stutter free, fluid gaming
- Certified NVIDIA® G-SYNC® compatible for smooth fast gaming
- 170Hz refresh rates for ultra-smooth, brilliant images
- 1ms (MPRT) fast response for crisp image and smooth gameplay
- Low input lag reduces time delay between devices to monitor

Immersive visuals

- IPS Nano color technology extends gamut for vibrant visuals
- Crystalclear images with Quad HD 2560 x 1440 pixels
- Ultra Wide-Color wider range of colors for a vivid picture
- SmartImage HDR gives optimal viewing from your HDR content

Features designed for you

- · LowBlue mode and Flicker-free easy-on-the eyes viewing
- Built-in stereo speakers for multimedia
- SmartErgoBase enables people-friendly ergonomic adjustments





Highlights

IPS Nano color



For critical imaging, gaming and productivity needs, Nano IPS display provides precise color accuracy across a wide viewing angle without color shift. Richer reds, lusher greens, and deeper blues. Ultra Wide-Color with IPS Nano Color technology uses KSF enhanced phosphor nanoparticles to absorb excess light created by the screen to produce amazing color. True-to-life color. Our display panels achieve up to 98% coverage of the DCI-P3 color gamut standard for color purity as defined by The Society of Motion Pictures and Television Engineers for cinematic picture quality.

AMD FreeSync™ Premium





eSync™ OFF AMD FreeSync™ C

Gaming shouldn't be a choice between choppy gameplay or broken frames. AMD FreeSync™ Premium equips serious gamers with a fluid, tear-free gameplay experience at peak performance. There are no compromises, game confidently with a high refresh rate, low framerate compensation, and low latency.

NVIDIA® G-SYNC® compatible



When playing intense games with high refresh rates, screen tearing may appear without optimal graphics synchronization. This Philips display is certified as NVIDIA® G-SYNC® compatible, reducing screen tearing and syncing your monitor's refresh rate with your graphic card's output for a smoother gaming experience. Scenes appear instantly, objects look sharper, and gameplay is smooth, giving you a stunning visual experience and a serious competitive edge.

170Hz Gaming



You play intense, competitive gaming. You demand display with lag free, ultra-smooth images. This Philips display redraws the screen image up-to 170 times per second, effectively faster than a standard display. A lower frame rate can make enemies appear to jump from spot to spot on the screen, making them difficult targets to hit. With 170Hz frame rate, you get those critical missing images on the screen which shows enemy movement in ultra-

smooth motion so you can easily target them. With ultra-low input lag and no screen tearing, this Philips display is your perfect gaming partner

1ms MPRT fast response





MPRT (motion picture response time) is more intuitive way to describe the response time, which directly refers the duration from seeing blurry noise to clean and crisp images. Philips gaming monitor with 1 ms MPRT effectively eliminates smearing and motion blur, delivers shaper and precise visuals to enhance gaming experience. Best choice for playing thrilling and twitch-sensitive games.

Low Input Lag





Input lag is the amount of time that elapses between performing an action with connected devices and seeing the result on screen. Low input lag reduces the time delay between entering a command from your devices to monitor, greatly improve on playing twitch-sensitive video games, particularly important to whom plays fast-paced, competitive games.



















Specifications

Picture/Display

- LCD panel type: Nano IPS
- · Backlight type: W-LED system
- Panel Size: 27 inch / 68.5 cm
- Display Screen Coating: Anti-Glare, 3H, Haze 25%
 Effective viewing area: 596.736 (H) x 335.664 (V)
- · Aspect ratio: 16:9
- Maximum resolution: 2560 x 1440 @ 170 Hz* (DP -> overclock); 2560 x 1440 @ 144 Hz (HDMI)
- Pixel Density: 108.79 PPI
- Response time (typical): 1 ms (Gray to Gray)*
- MPRT: 1 ms
- · Low Input Lag
- Brightness: 350 cd/m²
- SmartContrast: Mega Infinity DCR
- Contrast ratio (typical): 1000:1
- Pixel pitch: 0.2331 x 0.2331 mm
- Viewing angle: 178° (H) / 178° (V), @ C/R > 10
- · Flicker-free
- · HDR: HDR Ready
- Color gamut (min.): DCI-P3 98%*
- Color gamut (typical): NTSC 113%*, sRGB 133%*, Adobe RGB 93%*
- Picture enhancement: SmartImage game
- Display colors: Color support 1.07 Billion colors
- Scanning Frequency: HDMI: 30 230 kHz (H) / 48 144 Hz (V); DP: 30 - 255 kHz (H) / 48 - 170 Hz (V)
- SmartUniformity: 97 ~ 102%
- Delta E: < 2 (sRGB)
- sRGB
- LowBlue Mode
- · EasyRead
- AMD FreeSync™ technology: Premium
- G-SYNC: Compatible³

Connectivity

- Signal Input: HDMI 2.0 x 2, DisplayPort 1.4 x 2
- HDCP: HDCP 2.2 (HDMI / DisplayPort)
- USB:: USB-B x 1 (upstream), USB 3.2 x 4 (downstream with 2 fast charge B.C 1.2)
- Audio (In/Out): Audio out
- Sync Input: Separate Sync

Convenience

- Built-in Speakers: $5 \text{ W} \times 2$
- User convenience: Power On/Off, Menu/OK, Input/Up, Game Settings/Down, SmartImage game/
- OSD Languages: Brazil Portuguese, Czech, Dutch, English, Finnish, French, German, Greek, Hungarian, Italian, Japanese, Korean, Polish, Portuguese, Russian, Spanish, Simplified Chinese, Swedish, Turkish, Traditional Chinese, Ukrainian
- · Other convenience: Kensington lock, VESA mount (100x100mm)
- Plug & Play Compatibility: DDC/CI, Mac OS X,

sRGB, Windows 10 / 8.1 / 8 / 7

- · Height adjustment: 130 mm
- Pivot: -/+ 90 degree
- Swivel: -/+ 45 degree
- Tilt: -5/20 degree

- On mode: 31.8 W (typ.)
- Standby mode: 0.5 W (typ.)
- Off mode: 0.3 W (typ.)
- · Energy Label Class: F
- Power LED indicator: Operation White, Standby mode- White (blinking)
- Power supply: External, 100-240VAC, 50-60Hz

Dimensions

- Product with stand(max height): 614 x 549 x 212 mm
- Product without stand (mm): 614 x 363 x 43 mm
- Packaging in mm (WxHxD): $780 \times 521 \times 224$ mm

Weight

- Product with stand (kg): 4.80 kg
- Product without stand (kg): 3.40 kg
- Product with packaging (kg): 9.74 kg

Operating conditions

- Temperature range (operation): 0°C to 40 °C
- Temperature range (storage): -20°C to 60 °C
- Relative humidity: 20%-80 %
- Altitude: Operation: +12,000ft (3,658m), Nonoperation: +40,000ft (12,192m)
- MTBF: 50,000 (Excluded backlight) hour(s)

Sustainability

- · Environmental and energy: RoHS
- Recyclable packaging material: 100 %
- · Specific Substances: Mercury free, PVC / BFR free housing

Compliance and standards

• Regulatory Approvals: CB, CU-EAC, EAEU RoHS, TUV/ISO9241-307, TUV-BAUART, CE Mark, FCC Class B, ICES-003

- · Color: Black
- Finish: Textured

What's in the box?

- · Monitor with stand
- · Cables: HDMI cable, DisplayPort cable, USB upstream cable, Power cable
- User Documentation

- * "IPS" word mark / trademark and related patents on technologies belong to their respective owners
- * The maximum resolution works for DP input only.
- * For best output performance, please always ensure that your graphic card is capable of achieving the maximum resolution and refresh rate of this Philips display.
- * Response time value equal to SmartResponse * MPRT is to adjust brightness for blur reduction, so cannot adjust
- brightness while MPRT is turned on. To reduce motion blur, LED backlight will strobe synchronously with screen refresh, which may cause noticeable brightness change.

 MPRT is gaming-optimized mode. Turn on MPRT may cause
- noticeable screen flickering. It is recommended to turn off when you are not using the gaming function.
- * Display colors: 10 bits only can be reached by QHD @ 120 Hz

 DCI-P3 Coverage based on CIE1976

 NTSC Area based on CIE1976

 * SRGB Area based on CIE1931

- * Adobe RGB Coverage based on CIE1976 * 2020 Advanced Micro Devices, Inc. All rights reserved. AMD, the AMD Arrow logo, AMD FreeSync™ and combinations thereof are trademarks of Advanced Micro Devices, Inc. Other product names used in this publication are for identification purposes only and may be trademarks of their respective companies.

 * NVIDIA® G-SYNC® support interface: DisplayPort

 * Make sure to update NVIDIA® G-SYNC® driver to the latest
- version, see more information on NVIDIA website: https:// www.nvidia.com/
- * Make sure your graphic card supports NVIDIA $^{ ext{@}}$ G-SYNC $^{ ext{@}}$
- * The monitor may look different from feature images.

Issue date 2023-09-13 © 2023 Koninklijke Philips N.V.

All Rights reserved.

Version: 9.0.1

Specifications are subject to change without notice. Trademarks are the property of Koninklijke Philips N.V. or their respective owners.

12 NC: 8670 001 80552 EAN: 87 12581 78450 8

www.philips.com