

Q-Line Display

- 32"
- Direct LED Backlight
- Full HD

32BDL3511Q/00

Intensify your signage experience

Easy-setup 18/7 display.

Inform and enthrall with a Philips Q-Line Professional Full HD Display. This reliable solution can be up and running as quickly as you need.

Benefits

Effortless setup. Total control.

- Operate, monitor and maintain with CMND & Control
- Schedule what you want, when you want with SmartPlayer

Cost-effective system solution



- Easy control. Remotely manage networked displays

- Energy-saving automatic backlight control
- FailOver ensures content is always playing
- Integrated media player. Easily schedule USB content

PHILIPS

Features

CMND & Control



and secondary inputs ensuring content keeps playing even if the primary source goes down. Simply set a list of alternate inputs to be sure your business stays on.

Integrated media player

Easily schedule content to play from USB. Your Philips Professional Display will wake from standby to play the content you want, and then return to standby once playback is done.

Run your display network over a local (LAN) connection. CMND & Control allows you to perform vital functions like controlling inputs and monitoring display status. Whether you're in charge of one screen or 100.

FailOver



From waiting room to meeting room, never show a blank screen. FailOver lets your Philips Professional Display switch automatically between primary

SmartPlayer



Turn your USB into a true cost effective digital signage device. Simply save your content (video, audio, pictures) on your USB and plug into your display. Create your playlist and schedule your content via the on screen menu, and enjoy your own created playlists anytime, anywhere.

Specifications

[field not found 'disclaimer_text']

Picture/Display

Diagonal screen size (metric)	80 cm
Diagonal screen size (inch)	31.5 inch
Panel resolution	1920x1080p
Optimum resolution	1920 x 1080 @ 60 Hz
Brightness	350 cd/m²
Dynamic contrast ratio	500,000:1
Response time (typical)	6.5 ms
Aspect ratio	16:9
Viewing angle (horizontal)	178 degree
Viewing angle (vertical)	178 degree
Pixel pitch	0.36375 x 0.36375 mm
Display colors	16.7 Million
Panel technology	VA
Contrast ratio (typical)	4000:1
Clinical image	D-Image preset (dicom part 14 compatible)
Haze	2%

Supported Display Resolution

Computer formats	640 x 480, 60, 67, 72, 75Hz 720 x 400, 70Hz 800 x 600, 56, 60, 72, 75Hz 832 x 624, 75Hz 1024 x 768, 60, 70, 75Hz 1152 x 864, 75Hz 1152 x 870, 75Hz 1280 x 720, 60Hz 1280 x 800, 60Hz 1280 x 1024, 60Hz 1440 x 900, 60Hz 1600 x 1200, 60Hz 1680 x 1050, 60Hz 1920 x 1080, 60Hz
Video formats	480i, 60Hz 480p, 60Hz 576p, 50Hz

576i, 50Hz
720p, 60Hz
1080i, 50, 60Hz
1080p, 50, 60Hz

Connectivity

Video input	DVI-I (x 1) HDMI 2.0 (x2) USB 2.0 (x2)
Audio input	3.5 mm jack
Audio output	3.5mm jack
External control	IR (in/out) 3.5 mm jack RJ45 RS232C (in/out) 2.5 mm jack

Convenience

Placement	Landscape (18/7) Portrait (18/7)
Tiled Matrix	Up to 10 x 15
Signal loop through	RS232 IR Loophrough Smart Power
Energy saving functions	
Network controllable	RS232 RJ45
Keyboard control	Hidden Lockable
Remote control signal	Lockable
Start-up	Switch on delay Switch on status Boot on source enable / disable Philips logo
Start-up window	

Operating conditions

Temperature range (operation)	0 ~ 40 °C
Temperature range (storage)	-20 ~ 60 °C
Altitude	0 ~ 3000 m
MTBF	50,000 hour(s)
Humidity range (operation)[RH]	20 ~ 80% RH (No condensation)

Humidity range (storage) [RH]	5 ~ 95% RH (No condensation)	Regulatory approvals	Turkish Traditional Chinese CE FCC, Class A CB EMF VCCI PSB CU ETL
Power		Warranty	3 year warranty
Consumption (Typical)	45 W	Multimedia Applications	
Consumption (Max)	65 W	USB Playback Video	H.264 JPEG MPEG WMV3
Standby power consumption	<0.5 W	USB Playback Picture	BMP JPEG PNG
Mains power	100 - 240V~, 50/60Hz	USB Playback Audio	AAC WMA MPEG HEAAC
Power Saving Features	Smart Power	Dimensions	
Energy Label Class	G	Set Width	726.5 mm
Sound		Set Height	425.4 mm
Built-in speakers	2 x 10W RMS	Set Depth	69.1(D@Handle) / 65.1(D@Wall mount) mm
Accessories		Set Width (inch)	28.6 inch
Stand	BM02541/BM05911(optional)	Set Height (inch)	16.75 inch
Included Accessories	AC Switch Cover IR sensor cable (1.8 m) (x1) Philips logo (x1) Quick start guide (x1) Remote control & AAA batteries RS232 daisy chain cable (x1) USB Cover and screw x1 Wire Clamper (x3) AC power cord	Set Depth (inch)	2.72 (D@Handle) / 2.56 (D@Wall mount) inch
Miscellaneous		Bezel width	11.9 (TLR) / 17.2 (B) mm
On-Screen Display Languages	Arabic English French German Italian Japanese Polish Russian Spanish Simplified Chinese	Wall Mount	100mm x100mm, 200mm x 200mm ,M4
		Product weight	5.7 kg
		Product weight (lb)	12.57 lb



data subject to change
2023, June 19

Version: 1.0.1
EAN: 8712581778569

© 2023 Koninklijke Philips N.V.
All rights reserved.

Specifications are subject to change without notice. Trademarks are the property of Koninklijke Philips N.V. or their respective owners.

www.philips.com