BDL4988XC 49BDL3005X V1.30



www.philips.com/welcome

User Manual (English)



Safety Instructions

Safety precautions and maintenance



WARNING: Use of controls, adjustments or procedures other than those specified in this documentation may result in exposure to shock, electrical hazards and/or mechanical hazards.

Read and follow these instructions when connecting and using your display:

Operation:

- Keep the display out of direct sunlight and away from stoves or any other heat sources.
- · Remove any object that could fall into ventilation holes or prevent proper cooling of the display's electronics.
- · Do not block the ventilation holes on the cabinet.
- When positioning the display, make sure the power plug and outlet are easily accessible.
- When turning off the display by detaching the power cord, wait 6 seconds before re-attaching the power cord for normal operation.
- Ensure the use of an approved power cord provided by Philips at all times. If your power cord is missing, please contact your local service center.
- Do not subject the display to severe vibration or high impact conditions during operation.
- Do not knock or drop the display during operation or transportation.

Maintenance:

- To protect your display from possible damage, do not put excessive pressure on the LCD panel. When moving your display, grasp the frame to lift; do
 not lift the display by placing your hand or fingers on the LCD panel.
- Unplug the display if you are not going to use it for an extensive period of time.
- Unplug the display if you need to clean it with a slightly damp cloth. The screen may be wiped with a dry cloth when the power is off. However, never
 use organic solvent, such as, alcohol, or ammonia-based liquids to clean your display.
- To avoid the risk of shock or permanent damage to the set, do not expose the display to dust, rain, water or an excessively moist environment.
- If your display becomes wet, wipe it with dry cloth as soon as possible.
- If a foreign substance or water gets in your display, turn the power off immediately and disconnect the power cord. Then remove the foreign substance or water, and send the unit to the maintenance center.
- Do not store or use the display in locations exposed to heat, direct sunlight or extreme cold.
- In order to maintain the best performance of your display and ensure a longer lifetime, we strongly recommend using the display in a location that falls within the following temperature and humidity ranges.
 - Temperature: 0-40°C 32-104°F
 - Humidity: 20-80% RH

IMPORTANT: Always activate a moving screen saver program when you leave your display unattended. Always activate a periodic screen refresh application if the unit will display unchanging static content. Uninterrupted display of still or static images over an extended period may cause "burn in", also known as "after-imaging" or "ghost imaging", on your screen. This is a well-known phenomenon in LCD panel technology. In most cases, the "burned in" or "after-imaging" or "ghost imaging" will disappear gradually over a period of time after the power has been switched off.

WARNING: Severe "burn-in" or "after-image" or "ghost image" symptoms will not disappear and cannot be repaired. This is also not covered under the terms of your warranty.

Service:

- The casing cover should be opened only by qualified service personnel.
- If there is any need for repair or integration, please contact your local service center.
- Do not leave your display under direct sunlight.



If your display does not operate normally, having followed the instructions set out in this document, please contact a technician or your local service center.

Read and follow these instructions when connecting and using your display:



- Unplug the display if you are not going to use it for an extensive period of time.
- Unplug the display if you need to clean it with a slightly damp cloth. The screen many be wiped with a dry cloth when the power is off. However, never use alcohol, solvents or ammonia-based liquids.
- · Consult a service technician if the display does not operate normally when you have followed the instructions in this manual.
- The casing cover should be opened only by qualified service personnel.
- Keep the display out of direct sunlight and away from stoves or any other heat sources.
- Remove any object that could fall into the vents or prevent proper cooling of the display's electronics.
- Do not block the ventilation holes on the cabinet.
- Keep the display dry. To avoid electric shock, do not expose it to rain or excessive moisture.
- When turning off the display by detaching the power cable or DC power cord, wait for 6 seconds before re-attaching the power cable or DC power cord for normal operation..
- To avoid the risk of shock or permanent damage to the set do not expose the display to rain or excessive moisture.
- When positioning the display, make sure the power plug and outlet are easily accessible.
- IMPORTANT: Always activate a screen saver program during your application. If a still image in high contrast remains on the screen for an extended period of time, it may leave an 'after-image' or 'ghost image' on the front of the screen. This is a well-known phenomenon that is caused by the shortcomings inherent in LCD technology. In most cases the afterimage will disappear gradually over a period of time after the power has been switched off. Be aware that the after-image symptom cannot be repaired and is not covered under warranty.

CE Declaration of Conformity

This device complies with the requirements set out in the Council Directive on the Approximation of the Laws of the Member States relating to Electromagnetic Compatibility (2014/30/EU), Low-voltage Directive (2014/35/EU), RoHS directive (2011/65/EU).

This product has been tested and found to comply with the harmonized standards for Information Technology Equipment, these harmonized standards published under Directives of Official Journal of the European Union.

Warning:

This equipment is compliant with Class A of EN55032/CISPR 32. In a residential environment this equipment may cause radio interference.

Federal Communications Commission (FCC) Notice (U.S. Only)



NOTE: This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own expense.



Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Use only an RF shielded cable that was supplied with the display when connecting this display to a computer device.

To prevent damage which may result in fire or shock hazard, do not expose this appliance to rain or excessive moisture.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Envision Peripherals Inc. 47490 Seabridge Drive Fremont, CA 94538 Tel. 510-770-9988

Polish Center for Testing and Certification Notice

The equipment should draw power from a socket with an attached protection circuit (a three-prong socket). All equipment that works together (computer, display, printer, and so on) should have the same power supply source.

The phasing conductor of the room's electrical installation should have a reserve short-circuit protection device in the form of a fuse with a nominal value no larger than 16 amperes (A).

To completely switch off the equipment, the power supply cable must be removed from the power supply socket, which should be located near the equipment and easily accessible.

A protection mark "B" confirms that the equipment is in compliance with the protection usage requirements of standards PN-93/T-42107 and PN-89/F-06251

Wymagania Polskiego Centrum Badań i Certyfikacji

Urządzenie powinno być zasilane z gniazda z przyłączonym obwodem ochronnym (gniazdo z kołkiem). Współpracujące ze sobą urządzenia (komputer, monitor, drukarka) powinny być zasilane z tego samego źródła.

Instalacja elektryczna pomieszczenia powinna zawierać w przewodzie fazowym rezerwową ochronę przed zwarciami, w postaci bezpiecznika o wartości znamionowej nie większej niż 16A (amperów).

W celu całkowitego wyłączenia urządzenia z sieci zasilania, należy wyjąć wtyczkę kabla zasilającego z gniazdka, które powinno znajdować się w pobliżu urządzenia i być łatwo dostępne.

Znak bezpieczeństwa "B" potwierdza zgodność urządzenia z wymaganiami bezpieczeństwa użytkowania zawartymi w PN-93/T-42107 i PN-89/E-06251.


Pozostałe instrukcje bezpieczeństwa

- Nie należy używać wtyczek adapterowych lub usuwać kołka obwodu ochronnego z wtyczki. Jeżeli konieczne jest użycie przedłużacza to należy użyć przedłużacza 3-żyłowego z prawidłowo połączonym przewodem ochronnym.
- System komputerowy należy zabezpieczyć przed nagłymi, chwilowymi wzrostami lub spadkami napięcia, używając eliminatora przepięć, urządzenia dopasowującego lub bezzakłóceniowego źródła zasilania.
- Należy upewnić się, aby nic nie leżało na kablach systemu komputerowego, oraz aby kable nie były umieszczone w miejscu, gdzie można byłoby na nie nadeptywać lub potykać się o nie.
- Nie należy rozlewać napojów ani innych płynów na system komputerowy.
- Nie należy wpychać żadnych przedmiotów do otworów systemu komputerowego, gdyż może to spowodować pożar lub porażenie prądem, poprzez zwarcie elementów wewnętrznych.
- System komputerowy powinien znajdować się z dala od grzejników i źródeł ciepła. Ponadto, nie należy blokować otworów wentylacyjnych. Należy unikać kładzenia lużnych papierów pod komputer oraz umieszczania komputera w ciasnym miejscu bez możliwości cyrkulacji powietrza wokół niego.

Electric, Magnetic and Electronmagnetic Fields ("EMF")

- 1. We manufacture and sell many products targeted at consumers, which, like any electronic apparatus, in general have the ability to emit and receive electromagnetic signals.
- 2. One of our leading Business Principles is to take all necessary health and safety measures for our products, to comply with all applicable legal requirements and to stay well within the EMF standards applicable at the time of producing the products.
- 3. We are committed to develop, produce and market products that cause no adverse health effects.
- 4. We confirm that if its products are handled properly for their intended use, they are safe to use according to scientific evidence available today.
- 5. We play an active role in the development of international EMF and safety standards, enabling us to anticipate further developments in standardization for early integration in its products.

Information for U.K. only



WARNING - THIS APPLIANCE MUST BE EARTHED.

Important:


This apparatus is supplied with an approved moulded 13A plug. To change a fuse in this type of plug proceed as follows:

- 1. Remove fuse cover and fuse.
- 2. Fit new fuse which should be a BS 1362 5A,A.S.T.A. or BSI approved type.
- Refit the fuse cover.

If the fitted plug is not suitable for your socket outlets, it should be cut off and an appropriate 3-pin plug fitted in its place.

If the mains plug contains a fuse, this should have a value of 5A. If a plug without a fuse is used, the fuse at the distribution board should not be greater than 5A.

NOTE: The severed plug must be destroyed to avoid a possible shock hazard should it be inserted into a 13A socket elsewhere.



How to connect a plug

The wires in the mains lead are coloured in accordance with the following code:

BLUE - "NEUTRAL" ("N")

BROWN - "LIVE" ("L")

GREEN & YELLOW - "EARTH" ("E")

- 1. The GREEN & YELLOW wire must be connected to the terminal in the plug which is marked with the letter "E" or by the Earth symbol or coloured GREEN or GREEN & YELLOW.
- 2. The BLUE wire must be connected to the terminal which is marked with the letter "N" or coloured BLACK.
- The BROWN wire must be connected to the terminal which marked with the letter "L" or coloured RED.

Before replacing the plug cover, make certain that the cord grip is clamped over the sheath of the lead - not simply over the three wires.

North Europe (Nordic Countries) Information

Placering/Ventilation

VARNING:

FÖRSÄKRA DIG OM ATT HUVUDBRYTARE OCH UTTAG ÄR LÄTÅTKOMLIGA, NÄR DU STÄLLER DIN UTRUSTNING PÅPLATS.

Placering/Ventilation

ADVARSEL:

SØRG VED PLACERINGEN FOR, AT NETLEDNINGENS STIK OG STIKKONTAKT ER NEMTTILGÆNGELIGE.

Paikka/Ilmankierto

VAROITUS:

SIJOITA LAITE SITEN, ETTÄ VERKKOJOHTO VOIDAAN TARVITTAESSA HELPOSTI IRROTTAA PISTORASIASTA.

Plassering/Ventilasjon

ADVARSEL:

NÅR DETTE UTSTYRET PLASSERES, MÅ DU PASSE PÅ AT KONTAKTENE FOR STØMTILFØRSEL ER LETTE Å NÅ.

中国大陆RoHS

根据中国大陆《电子电气产品有害物质限制使用标识要求》,以下部分列出了本产品中可能包含的有害物质的名称和含量。

	有害物质						
部件名称	铅 (Pb)	汞 (Hg)	镉 (Cd)	六价铬 (Cr (VI))	多溴联苯 (PBB)	多溴二苯醚 (PBDE)	
外壳	0	0	0	0	0	0	
液晶显示屏	×	0	0	0	0	0	
电路板组件*	×	0	0	0	0	0	
电源适配器	×	0	0	0	0	0	
电源线/连接线	×	0	0	0	0	0	
遥控器	×	0	0	0	0	0	

本表格依据SI/T 11364 的规定编制。

- *: 电路板组件包括印刷电路板及其构成的零部件,如电阻、电容、集成电路、连接器等。
- O: 表示该有害物质在该部件所有均质材料中的含量均在 GB/T 26572规定的限量要求以下。
- X: 表示该有害物质至少在该部件的某一均质材料中的含量超出GB/T 26572规定的限量要求。

上表中打"×"的部件,应功能需要,部分有害物质含量超出GB/T 26572规定的限量要求,但符合欧盟RoHS 法规要求(属于豁免部分)。

备注:上表仅做为范例,实际标示时应依照各产品的实际部件及所含有害物质进行标示。



环保使用期限

此标识指期限(十年),电子信息产品中含有的有害物质在正常使用的条件下不会发生外泄或突变,电子信息产品用户使用该电子信息产品不会对环境造成严重污染或对其人身、财产造成严重损害的期限。

《废弃电器电子产品回收处理管理条例》提示性说明

为了更好地关爱及保护地球,当用户不再需要此产品或产品寿命终止时,请遵守国家废弃电器电子产品回收处理相关法律法规,将其交给当地具有国家认可的回收处理资质的厂商进行回收处理。

警告

此为A级产品。在生活环境中,该产品可能会造成无线电干扰。在这种情况下,可能需要用户对干扰采取切实可行的措施。

	限用物質及其化學符號						
單元	鉛 (Pb)	汞 (Hg)	鎘 (Cd)	六價鉻 (Cr ⁺⁶)	多溴聯苯 (PBB)	多溴二苯醚 (PBDE)	
塑料外框	0	0	0	0	0	0	
後殼	0	0	0	0	0	0	
液晶面板	_	0	0	0	0	0	
電路板組件	_	0	0	0	0	0	
底座	0	0	0	0	0	0	
電源線	_	0	0	0	0	0	
其他線材	_	0	0	0	0	0	
遙控器	_	0	0	0	0	0	
喇叭(選配)	_	0	0	0	0	0	
風扇 (選配)	_	0	0	0	0	0	

備考1. "○"係指該項限用物質之百分比含量未超出百分比含量基準值。

備考2. "一"係指該項限用物質為排除項目。

警語: 使用過度恐傷害視力。

注意事項:

- (1) 使用30分鐘請休息10分鐘。
- (2) 未滿2歲幼兒不看螢幕,2歲以上每天看螢幕不要超過1小時。

警告使用者:

此為甲類資訊技術設備,於居住環境中使用時,可能會造成射頻擾動,在此種情況下,使用者會被要求採取某些適當的對策。

Turkey RoHS:

Türkiye Cumhuriyeti: EEE Yönetmeliğine Uygundur.

Ukraine RoHS:

Обладнання відповідає вимогам Технічного регламенту щодо обмеження використання деяких небезпечних речовин в електричному та електронному обладнанні, затвердженого постановою Кабінету Міністрів України від 3 грудня 2008 № 1057.

End-of-Life Disposal

Your new Public Information Display contains materials that can be recycled and reused. Specialized companies can recycle your product to increase the amount of reusable materials and to minimize the amount to be disposed of.

Please find out about the local regulations on how to dispose of your old display from your local Philips dealer.

(For customers in Canada and U.S.A.)

This product may contain lead and/or mercury. Dispose of in accordance to local-state and federal regulations. For additional information on recycling contact www.eia.org (Consumer Education Initiative)

Waste Electrical and Electronie Equipment-WEEE

Attention users in European Union private households



This marking on the product or on its packaging illustrates that, under European Directive 2012/19/EU governing used electrical and electronic appliances, this product may not be disposed of with normal household waste. You are responsible for disposal of this equipment through a designated waste electrical and electronic equipment collection. To determine the locations for dropping off such waste electrical and electronic, contact your local government office, the waste disposal organization that serves your household or the store at which you purchased the product.

Attention users in United States:

Please dispose of according to all Local, State and Federal Laws. For the disposal or recycling information, contact: www.mygreenelectronics.com or www. eiae.org.

End of Life Directives-Recycling



Your new Public Information Display contains several materials that can be recycled for new users.

Please dispose of according to all Local, State, and Federal laws.



As an ENERGY STAR Partner, we have determined that this product meets the ENERGY STAR guidelines for energy efficiency.

Restriction on Hazardous Substances statement (India)

This product complies with the "E-Waste (Management) Rules, 2016" CHAPTERV, rule 16, sub-rule (1) . Whereas New Electrical and Electronic Equipment and their components or consumables or parts or spares do not contain Lead, Mercury, Cadmium, Hexavalent Chromium, polybrominated biphenyls and polybrominated diphenyl ethers beyond a maximum concentration value of 0.1% by weight in homogenous materials for lead, mercury, hexavalent chromium, polybrominated biphenyls and polybrominated diphenyl ethers and of 0.01% by weight in homogenous materials for cadmium. except of exemptions set in Schedule 2 of the Rule.

E-Waste Declaration for India



This symbol on the product or on its packaging indicates that this product must not be disposed of with your other household waste. Instead it is your responsibility to dispose of your waste equipment by handing it over to a designated collection point for the recycling of waste electrical and electronic equipment. The separate collection and recycling of your waste equipment at the time of disposal will help to conserve natural resources and ensure that it is recycled in a manner that protects human health and the environment. For more information about E -waste please visit http://www.india.philips.com/about/sustainability/recycling/index.page and to know where you can drop off your waste equipment for recycling in India please contact on below given contact details.

Helpline number: 1800-425-6396 (Monday to Saturday, 9 a.m. to 5:30 pm)

Centralized E-waste collection center Address:TPV Technology India Private Limited,

59, Maheswari Nagar, 1st Main Road, Mahadevapura Post, Whitefield Road

Bangalore, Karnataka, PIN: 560048, Tel: 080-3023-1000

E-mail: india.callcentre@tpv-tech.com

Batteries



For EU: The crossed-out wheeled bin implies that used batteries should not be put to the general household waste! There is a separate collection system for used batteries, to allow proper treatment and recycling in accordance with legislation.

Please contact your local authority for details on the collection and recycling schemes.

For Switzerland: The used battery is to be returned to the selling point.

For other non-EU countries: Please contact your local authority for correct method of disposal of the used battery.

According to EU directive 2006/66/EC, the battery can't be disposed improperly. The battery shall be separated to collect by local service.



Após o uso, as pilhas e/ou baterias deverão ser entregues ao estabelecimento comercial ou rede de assistência técnica autorizada.

Information for EAC	EAC			
Month and year of manufacturing	please refer information in Rating label.			
Name and location of manufacturer	ООО "Профтехника"			
	Адрес: 3-й Проезд Марьиной рощи, 40/1 офис 1. Москва, 127018, Россия			
Importer and information	Наименование организации: ООО "Профтехника"			
	Адрес: 3-й Проезд Марьиной рощи, 40/1 офис 1. Москва, 127018, Россия			
	Контактное лицо: Наталья Астафьева,			
	+7 495 640 20 20			
	nat@profdisplays.ru			

Table Of Contents

	•	king and	d Installation	1		
	1.1.	_	king			
	1.2.	Package Contents1				
	1.3.	Installation Notes1				
	1.4.		ng on a Wall			
		1.4.1.	VESA Grid			
	1.5.	Mounti	ng in Portrait Position			
	1.6.		ting Instructions of Edge Alignment Kit			
		1.6.1.	Installing the Edge Alignment Kit			
	1.7.		of Edge Finishing Kit (Optional)			
		1.7.1.	Installing the Edge Finishing Kit			
2.	Parts	and Fun	ctions	6		
	2.1.		ol Panel			
	2.2.		Output Terminals			
	2.3.		e Control			
		2.3.1.	General functions			
		2.3.2.	ID Remote Control			
		2.3.3.	Inserting the batteries in the remote			
			control	10		
		2.3.4.	Handling the remote control	10		
		2.3.5.	Operating range of the remote control	ol10		
3.	Connecting External Equipment11					
	3.1.		cting External Equipment (DVD/VCR/	11		
		3.1.1.	Using COMPONENT video input	11		
		3.1.2.	Using Video Source input	11		
		3.1.3.	Using HDMI video input	12		
	3.2.		Using HDMI video input cting a PC			
	3.2.			12		
	3.2.	Conne 3.2.1.	cting a PCUsing VGA input	12		
	3.2.	Conne 3.2.1.	cting a PC	12 12 12		
	3.2.	Conne 3.2.1. 3.2.2.	cting a PC Using VGA input Using DVI input	12 12 12 13		
	3.2. 3.3.	Conne 3.2.1. 3.2.2. 3.2.3. 3.2.4.	cting a PC Using VGA input Using DVI input Using HDMI input	12 12 12 13		
		Conne 3.2.1. 3.2.2. 3.2.3. 3.2.4.	Cting a PC Using VGA input Using DVI input Using HDMI input Using DisplayPort input	12 12 13 13		
		Conne 3.2.1. 3.2.2. 3.2.3. 3.2.4. Conne	cting a PC Using VGA input Using DVI input Using HDMI input Using DisplayPort input cting Audio Equipment	12 12 13 13 13		
		Conne 3.2.1. 3.2.2. 3.2.3. 3.2.4. Conne 3.3.1. 3.3.2. Conne	Using VGA input Using DVI input Using HDMI input Using DisplayPort input cting Audio Equipment Connecting external speakers	12 12 13 13 13 13		
	3.3.	Conne 3.2.1. 3.2.2. 3.2.3. 3.2.4. Conne 3.3.1. 3.3.2. Conne	Using VGA input Using DVI input Using HDMI input Using DisplayPort input cting Audio Equipment Connecting external speakers Connecting an external audio device cting Multiple Displays in a Daisy-chain	12 12 13 13 13 14		
	3.3.	Conne 3.2.1. 3.2.2. 3.2.3. 3.2.4. Conne 3.3.1. 3.3.2. Conne Configu	Using VGA input Using DVI input Using HDMI input Using DisplayPort input cting Audio Equipment Connecting external speakers Connecting an external audio device cting Multiple Displays in a Daisy-chain uration Display control connection	121213131314		
	3.3.	Conne 3.2.1. 3.2.2. 3.2.3. 3.2.4. Conne 3.3.1. 3.3.2. Conne Configu 3.4.1.	Using VGA input Using DVI input Using HDMI input Using DisplayPort input cting Audio Equipment Connecting external speakers Connecting an external audio device cting Multiple Displays in a Daisy-chain uration Display control connection Digital video connection	1212131313141414		
	3.3.	Conne 3.2.1. 3.2.2. 3.2.3. 3.2.4. Conne 3.3.1. 3.3.2. Conne Config 3.4.1. 3.4.2. 3.4.3.	Using VGA input Using DVI input Using HDMI input Using DisplayPort input cting Audio Equipment Connecting external speakers Connecting an external audio device cting Multiple Displays in a Daisy-chain uration Display control connection	121213131314141415		
	3.3. 3.4.	Conne 3.2.1. 3.2.2. 3.2.3. 3.2.4. Conne 3.3.1. 3.3.2. Conne Config 3.4.1. 3.4.2. 3.4.3. IR conn	Using VGA input Using DVI input Using HDMI input Using DisplayPort input cting Audio Equipment Connecting external speakers Connecting an external audio device cting Multiple Displays in a Daisy-chain uration Display control connection Digital video connection	1212131314141515		
	3.2.	Conne	cting a PC	12		

4.	Oper	ation		18
	4.1.	Watch	the Connected Video Source	18
	4.2.	Change	e Picture Format	18
	4.3.	Play m	ultimedia files via Local Area Network	18
		4.3.1.	Network settings	18
		4.3.2.	How to use DLNA-DMP	18
		4.3.3.	How to use DLNA-DMR from PC	19
	4.4.	Play m	ultimedia files from USB device	19
	4.5.	Play op	otions	20
		4.5.1.	Playing music files	20
		4.5.2.	Playing movie files	20
		4.5.3.	Playing photo files	20
	4.6.	How to	o use Opera browser (HTML5)	20
5.	Chan	ge vour	settings	22
٥.	5.1.	• ,	S	
	01	5,1,1,	Picture	
		5.1.2.	Sound	
		5.1.3.	Tiling	
		5.1.4.	Network	
		5.1.5.	General settings	
		5.1.6.	Advanced	
		5.1.7.	Help	
6.	USB (device co	ompatibility	29
7.	Input	Mode		31
8.	Pixel	Defect F	Policy	32
	8.1.		and Sub-Pixels	
	8.2.	Types of Pixel Defects + Dot Definition		
	8.3.	Bright I	Dot Defects	32
	8.4.	_	Oot Defects	
	8.5.	Proxim	nity of Pixel Defects	33
	8.6.	Pixel D	Pefect Tolerances	33
	8.7.	MURA	·	33
9.	Clear	ning and	Troubleshooting	34
	9.1.	•	ng	
	9.2.		eshooting	
10.	Tochr	nical Spa	cifications	37
10.	iecili	iicai spei	CITICACIONS	5/

Remote Control

and AAA Batteries

Edge Alignment Pin

1. Unpacking and Installation


1.1. Unpacking

- This product is packed in a carton, together with the standard accessories.
- Any other optional accessories will be packed separately.
- As this product is high and heavy, the operation of moving the device is recommended to be performed by two technicians.
- After opening the carton, ensure that the contents are complete and in good condition.

1.2. Package Contents

Please verify that you received the following items with your package content:

- LCD display
- Remote control and AAA batteries
- Power cord
- DVI cable
- RS232 cable
- Daisy chain cable
- IR sensor cable
- IR cable
- · Quick start guide
- Edge Alignment Kit-1: 1PC
- Edge Alignment Kit-2: 2PCS
- Thumb Screw: 8PCS
- Edge Alignment Pin: 2PCS





Display design and accessories may differ from those illustrated above.

NOTES:


- For all other regions, apply a power cord that conforms to the AC voltage of the power socket and that has been approved by and complies with the safety regulations of the particular country.
- You might like to keep the carton and packing material for shipping the display.

1.3. Installation Notes

- Due to the high power consumption, always use the plug exclusively designed for this product. If an extended line is required, please consult your service agent.
- The product should be installed on a flat surface, or the product may tip over. Leave a space between the rear of the product and the wall for proper ventilation. Do not install the product in a kitchen, bathroom or a place exposed to moisture, failure to do so may shorten the life of the internal parts.
- Do not install the product where it is 3000m and higher in altitude. Failure to do so may result in malfunctions.

1.4. Mounting on a Wall

To mount this display on a wall, a standard wall-mounting kit (commercially available) is required. It is recommended that you use a mounting interface that complied with TUV-GS and /or UL1678 standard in North America.



- 1. Spread a protective sheet on a flat surface, which is wrapped around the display when it was packed, beneath the screen surface to facilitate your operation without scratching the screen.
- 2. Ensure you have all accessories necessary for all types of mounting (wall-mounting, ceiling mounting, table stand, etc).
- 3. Follow the instructions that came with the base mounting kit. Failure to follow the correct mounting procedures could result in damage to the equipment, or injury to the user or installer. The product warranty does not cover the damage caused by improper installation.
- 4. For the wall-mounting kit, use the M6 mounting screws (with a length 10 mm longer than the thickness of the mounting bracket) and tighten them securely.
- 5. Weight of the unit without base= 21.6 kg. The equipment and its associated mounting facilities still remain secure during the test. Use only the UL
- 6. listed Wall Mount Bracket with a minimum weight/load of 21.6 kg.

1.4.1. VESA Grid

BDL4988XC/49BDL3005X	400(H) × 400(V) mm


Caution:

To prevent the display from falling:

- For wall or ceiling mounting, we recommend that you install the display with metal brackets which are commercially available. For detailed instructions about the installation, refer to the guide provided with the bracket
- To prevent the display from falling in case of earthquake or other natural disaster, please consult the manufacturer of the bracket for the mounting location.

Required space for ventilation


Leave a space of 100 mm at the top, rear, right and left of the display for ventilation.



1.5. Mounting in Portrait Position

This display can be installed in portrait position.


- 1. If the table stand is attached, remove it first.
- 2. Rotate the display counterclockwise by 90°. The "PHILIPS" logo should be in a vertical position when facing the display from the back.




1.6. Operating Instructions of Edge Alignment Kit

1.6.1. Installing the Edge Alignment Kit

- Before installing the edge alignment kit, the display must be mounted to the frame of video wall correctly.
- Use the provided thumb screw to facilitate your installation of the edge alignment kit.
- Use the "Edge Alignment Kit-1" for four adjacent displays.



• Use the "Edge Alignment Kit-2" for two adjacent displays.




NOTE: We recommend that you contact a professional technician when installing the edge alignment kit. We are not responsible for any damage to the product if the installation is not performed by a professional technician.

1.7. Using of Edge Finishing Kit (Optional)


You can use the edge finishing kit to protect the display and have a better appearance.

1.7.1. Installing the Edge Finishing Kit

Installing Edge Finishing Kit for 1x1 Display Configuration




Installing Edge Finishing Kit for 2x2 Display Configuration



^{*} See the instruction guide provided with the kit for details.

2. Parts and Functions

2.1. Control Panel



1 [(b)] button

Turn the display On or turn the display to standby mode.

(2) [MUTE] button

Mute the sound or reactivate sound.

③ [INPUT] button

Select an input source.

• Work as a [OK] button to confirm a selection in the On-Screen-Display menu.

4 [+] button

Increase the adjustment while OSD menu is On, or increase the audio output level while OSD menu is Off.

⑤ [—] button

Decrease the adjustment while OSD menu is On, or decrease the audio output level while OSD menu is Off.

6 [▲] button

Move the selected item one level up while the OSD menu is On.

(7) **[▼]** button


Move the selected item one level down while the OSD menu is On.

(8) [MENU] button

Return to the previous menu while the OSD menu is On. This button can also be used to activate the OSD menu when the OSD menu is Off.

- · Receive command signals from the remote control.
- Indicate the operating status of the display without OPS:
 - Light green when the display is turned On
 - Light red when the display is in the standby mode
 - Light amber when the display enters APM mode
 - When $\{\mbox{SCHEDULE}\}$ is enabled, the light blinks green and red
 - If the light blinks red, it indicates that a failure has been detected
 - Lights off when the main power of the display is turned off

2.2. Input/Output Terminals



1 AC IN

AC power input from the wall outlet.

(2) MAIN POWER SWITCH

Switch the main power between On/Off.

(3) AC OUT

AC power supply to the AC IN jack of a media player.

4 IR IN / 5 IR OUT

IR signal input / output for the loop-through function.

NOTES:

- The remote control sensor of this display will stop working if the jack [IR IN] is connected.
- To remotely control your A/V device via this display, refer to page 16 for IR Pass Through connection.

6 RS232C IN / ⑦ RS232C OUT

RS232C network input/output for the loop-through function.

(8) **RJ-45**

LAN control function for using the remote control signal from the control center.

(9) HDMI1 IN / (10) HDMI2 IN

Connect to a source device using an HDMI cable.

(11) DVI IN

Connect to a source device using a DVI cable.

12 DVI OUT / VGA OUT

DVI or VGA video output.

(3) DisplayPort IN / (4) DisplayPort OUT

DisplayPort video input/output.

(15) VGA IN (D-Sub)

VGA video input.

(16) COMPONENT IN (BNC)

Component YPbPr video source input.

(17) Y/CVBS

Video source input.

(18) PC LINE IN

Audio input for VGA source (3.5mm stereo phone).

(19) SPEAKER SWITCH

Internal speaker on/off switch.

20 AUDIO IN

Audio input from external AV device (RCA).

21) AUDIO OUT

Audio output to external AV device.

22 USB PORT

Connect to a USB storage device.

23 SPEAKERS OUT

Audio output to external speakers.

(24) OPS SLOT


Slot for installing the optional OPS module.

NOTES: Advantech ARK DS262 and Winmate OMIS-OPS modules are two modules recommended by the manufacturer. Any

damage caused by using other type of OPS module is not covered by the warranty.

2.3. Remote Control

2.3.1. General functions



1 [POWER] button

Turn the display On or turn the display to standby mode.

2 [PLAY] buttons

Control playback of media files.

③ [+]] SOURCE button

Select an input source. Press [—] or [—] button to select from USB, Network, HDMI 1, HDMI 2, DisplayPort, Card OPS, DVI-D, YPbPr, AV, or VGA. Press [OK] button to confirm a selection and exit from the current menu.

4 [A] HOME button

Access the OSD menu.

(5) [=] LIST button

(Reserved).

⑥ [i] [v] [→] [►] NAVIGATION buttons

Navigate through the menu and select an item.

7 [OK] button

Confirm an entry or selection.

® [||| ADJUST button

Access currently available options, picture and sound menus.

(9) [IC] MUTE button

Mute the sound or reactivate sound.

(10) [—] [—] [—] COLOR buttons

Select a task or option.

(1) [Number/ ID SET/ ENTER] button

Enter the text for network setting.

Press to set the display ID. Refer to **2.3.2. ID Remote Control** for more detail.

① [M] FORMAT button

Change the picture format.

(13 [**___**] BACK button

Return to the previous menu or exit from the previous function.

(14) [ii] INFO button

Display information about the current activity.

(15) [] OPTIONS button


Access currently available options, picture and sound menus.

(16) [一] [十] **VOLUME** button

Adjust the volume.

2.3.2. ID Remote Control

Set the remote control ID if you intend to use this remote control on several different displays.



Press the [ID] button and the red LED blinks twice.

1. Press the [ID SET] button for more than 1 second to enter the ID mode. The red LED lights up.

Pressing the [ID SET] button again will exit from the ID mode. The red LED lights off.

Press the digit numbers $[0] \sim [9]$ to select the display to be controlled. For example: press [0] and [1] for display No.1, press [1] and [1] for display No.11.

The numbers available are from $[01] \sim [255]$.

- If no button is pressed within 10 seconds, it will exit from the ID mode.
- 3. If a wrong button is pressed, wait for 1 second until the red LED lights off and then turns on again, then press the correct digits.

4. Press [ENTER] button to confirm your selection. The red LED blinks twice and then lights off.

NOTE:


- Press the [NORMAL] button. The green LED blinks twice, indicating that the display is under normal operation.
- It is necessary to set up the ID number for each display before selecting its ID number.

2.3.3. Inserting the batteries in the remote control

The remote control is powered by two 1.5V AAA batteries.

To install or replace the batteries:

- 1. Press and then slide the cover to open it.
- 2. Insert the batteries with the correct polarity (+) and (-).
- 3. Replace the cover.



Caution:

Incorrect use of batteries may cause leakage or explosion. Be sure to follow the instructions below:

- Insert "AAA" batteries with the correct polarity (+ and -).
- Do not mix battery types.
- Do not use a new battery with a used one together. Otherwise, it may cause leakage or shorten the life of the batteries.
- Remove the dead batteries immediately to avoid battery leakage in the battery compartment. Do not touch exposed battery acid, as it may cause injury to your skin.

NOTE: Remove the batteries from the battery compartment when not using for an extended period of time.

2.3.4. Handling the remote control

- Do not drop or apply shock to the remote control.
- Do not allow any liquid to get inside the remote control. If water has entered the remote control, wipe the remote control with a dry cloth immediately.
- Do not place the remote control near heat and steam sources.
- · Do not attempt to disassemble the remote control, unless you need to place batteries in the remote control.


2.3.5. Operating range of the remote control

Point the top front of the remote control at the remote control sensor (back side) on the display when you press the buttons.

Use the remote control within the operating range listed below.

Operation Angle	RC operational distance			
θ = 0° (for H & V)	≥ 8m			
θ= 20° (for H & V)	≥ 5m			
θ= 45° (for H only)	≥ 2m			


NOTE: The remote control may not function properly when the remote control sensor on the display is under direct sunlight or strong illumination, or when there is an object between the remote control and the remote sensor of the display.




3. Connecting External Equipment

3.1. Connecting External Equipment (DVD/VCR/VCD)


3.1.1. Using COMPONENT video input



3.1.2. Using Video Source input




3.1.3. Using HDMI video input




3.2. Connecting a PC


3.2.1. Using VGA input




3.2.2. Using DVI input



3.2.3. Using HDMI input




3.2.4. Using DisplayPort input




3.3. Connecting Audio Equipment

3.3.1. Connecting external speakers



3.3.2. Connecting an external audio device




3.4. Connecting Multiple Displays in a Daisy-chain Configuration

You can interconnect multiple displays to create a daisy-chain configuration for applications such as a video wall.


3.4.1. Display control connection

Connect the [RS232C OUT] connector of DISPLAY 1 to the [RS232C IN] connector of DISPLAY 2.




3.4.2. Digital video connection


Connect the [DVI OUT /VGA OUT] connector of DISPLAY 1 to the [DVI IN] connector of DISPLAY 2.



Connect the [DP OUT] connector of DISPLAY 1 to the [DP IN] connector of DISPLAY 2.




Connect the [DVI OUT] connector of DISPLAY 1 to the [DVI IN] connector of DISPLAY 2.




3.4.3. Analog video connection

Connect the [DVI OUT /VGA OUT] connector of DISPLAY 1 to the [VGA IN] connector of DISPLAY 2.




3.5. IR connection




NOTE: The remote control sensor of this display will stop working if the [IR IN] is connected.

3.6. IR Pass-through Connection



3.7. Wire-connecting to Network

By connecting this display to a home network, you can play photos, music and videos from your computer. See *Play multimedia files via Local Area Network* (Page 18) for details.



Network settings:

- 1. Switch the router On and enable its DHCP setting.
- 2. Connect the router to this display with an Ethernet cable.
- 3. Press [HOME button on the remote control, then select **Setup**.
- 4. Select **Connect to network**, then press **[OK]** button.
- 5. Follow the on-screen instructions to configure the network.
- 6. Wait until this display finds the network connection.
- 7. If the "End User Licence Agreement" window is prompted, accept the agreement.

NOTE: Connect with a shielded CAT-5 Ethernet cable to comply with the EMC directive.

4. Operation

NOTE: The control button described in this section is mainly on the remote control unless specified otherwise.

4.1. Watch the Connected Video Source

See page 11 for external equipments connection.

- 1. Press [---] SOURCE button.
- 2. Press [1] or [7] button to select a device, then press [OK] button.

4.2. Change Picture Format

You can change the picture format to suit the video source. Each video source has its available picture formats.

The available picture formats depend on the video source:

- 1. Press the [FORMAT button.
- 2. Press [1] or [1] button to select a picture format, then press [OK] button.
 - {Auto zoom}: Enlarge the picture to fill the screen. This option is recommended for minimal screen distortion but not for HD or PC.
 - {Movie expand 16:9}: Scale 4:3 format to 16:9. This options is not recommended for HD or PC.
 - {Wide screen}: Show the content undistorted in wide screen format. This options is not recommended for HD or PC.
 - {Unscaled}: Provide maximum detail for PC. This option is available only when PC mode is selected from the {Picture} menu
 - {4:3}: Display the classic 4:3 format.
 - {Custom zoom}: Apply the customized zoom settings selected from the sub-menu of Picture and edges.


4.3. Play multimedia files via Local Area Network

To play files via Local Area Network, you will need:


- A wired home network, connected with a Universal Plug and Play (uPnP) router.
- Optional: A LAN cable that connects your display to your home network.
- A media server running on your computer.
- Appropriate settings on your computer firewall to allow you to run the media server.

4.3.1. Network settings

- Connect your display and the computer to the same home network. Refer to the connection diagram as shown below.
- 2. Switch your PC and router On.
 - Single display setup:



Multiple display setup:



NOTE: If the device does not return to DLNA mode due to external electrical disturbances (e.g. electrostatic discharge), user intervention is required.


Set up media sharing

- Install a media server on your computer to share the media files.
 Here are some media servers for different operating systems:
 - For PC: Windows Media Player 11 (or higher) or TVersity
 - For Mac:Twonky
- Switch on the media sharing on your computer using the media server. For more information on how to set up the media server, refer to the website of the media server.

4.3.2. How to use DLNA-DMP

Ensure that you have connected to the network first.

Press the i button to display the connection of the network.



Play files from display

1. Press [->] **SOURCE** button, select **Network**, and press [**OK**] button.




- 2. As all PCs are connected to the same router now, select the correct one.
- 3. Press [1] and [-] to select the directory and files to play.


You can connect up to 4 displays to the same PC and play the same media stream.

4.3.3. How to use DLNA-DMR from PC


1. Press [HOME button, select **Network** and press [**OK**] button.



2. Set Digital Media Renderer DMR to ON.



3. Set the name of your display.





- 4. Press [♠] HOME button, and press [♣] SOURCE button. Select **Network** and press [○K] button.
- On your PC, go to Network and Sharing Center, and click Choose homegroup and sharing options.

- 6. Check the media formats. Then, click **Choose media streaming options....**
- 7. Go to **Advanced sharing settings**, and click the checkbox **Turn on network discovery**.
- 8. Go to the directory of your media files and select the media file by right clicking on it. From the sub-menu of **Play To**, you can find all displays that are connected to your network. Select the display and the media file to play.

Play files


- 1. Press [SOURCE button.
- 2. Select **Network**, and press [OK] button.
- 3. Select a file from the content browser, and press **[OK]** button to start playing.
- 4. Press [PLAY] button on the remote control to control playback.

Tips:

- Select the top menu bar to filter your files by type.
- Select **Sort** to sort the files by album name, artist, or other fields.
- To clear the list of offline media servers, press [] OPTIONS button. Then, select Clear offline servers and press [OK] button.

4.4. Play multimedia files from USB device

1. Connect your USB device to the USB port on the display.



Press [--] SOURCE button, select USB, and press [OK] button.



- 3. The connected USB device is detected automatically for all its playable files, which will be automatically sorted into 3 types:

 Music, Movie, and Photo.
- Press [➡] BACK button to go up to the top layer of the screen.
 Press [➡] or [➡] button to select the file type. Press [OK] button to enter its playlist.
- 5. Select your desired file. Press **[OK]** button to start playing.
- 6. Follow the on-screen instruction to control the playback option.

7. Press [PLAY] buttons () to control playback.

4.5. Play options

4.5.1. Playing music files

1. Select **Music** from the top menu bar.



- 2. Select one music track and press [OK] button.
 - To play all tracks in a folder, select one music file. Then, press [] to Play All.
 - To skip to the next or previous track, press [1] or [1] button.
 - To pause the track, press **[OK]** button. Press **[OK]** button again to resume playback.
 - To skip backward or forward 10 seconds, press [—] or [—] button.
 - To search backward or forward, press [◄◄] or [▶▶] button, press repeatedly to toggle between different speeds.
 - To stop the music, press [] button.

Music options

While you play the music, press $[\ \]$ OPTIONS button, then press $[\ \ \ \]$ button to select an option:

- {Shuffle}: Songs are played in a randomized order.
- {Repeat}: Play a track or an album repeatedly, or select {Play once} to play a track once.

NOTE: To view information about a song (for example, title, artist or duration), select the song, then press [i] INFO button. To hide the information, press [i] INFO button again.

4.5.2. Playing movie files

1. Select **Movie** from the top menu bar.



- 2. Select a video file and press [OK] button.
 - To play all videos in a folder, select one video file. Then press to **Play All**.
 - To pause the video, press **[OK]** button. Press **[OK]** button again to resume playback.
 - To skip backward or forward 10 seconds, press [—] or [—]
 - To search backward or forward, press [◄◄] or [▶▶] button, press repeatedly to toggle between different speeds.
 - To stop the video, press [] button.

Movie options

While playing a video, press [OFTIONS button, then press [OK] button to select an option:

- {Subtitles}: Select from the available subtitle settings.
- {Subtitle language}: Select the subtitle language if available.
- {Shuffle}: Videos are played in a randomized order.
- {Repeat}: Select {Repeat} to play the video file repeatedly or {Play once} to play the video file once.
- {Status}:To view information about a video (for example, played position, duration, title, or date).

4.5.3. Playing photo files

1. Select **O Photo** from the top menu bar.



2. Select a photo thumbnail, then press [OK] button.

Start a slideshow

- To skip to the previous or next photo, press [→] or [→] button, and press [○K] button.
- To stop the slideshow, press [] button.

Slideshow options

While you play a slideshow, press [OK] OPTIONS button, then press [OK] button to select an option:

- {Shuffle}: Pictures are played in a randomized order.
- {Repeat}: Select {Repeat} to watch a slideshow repeatedly or {Play once} to watch once.
- {Slideshow Time}: Select the displaying time for each photo in the slideshow.
- {Slideshow Transitions}: Select the transition from one photo to the next.

4.6. How to use Opera browser (HTML5)

Please check the LAN wire to make sure the network is connected.

1. Press [---] **SOURCE** button, and select **Internet** > [OK] button.




Move the cursor to URL address bar. Press [OK] button and a
pop-up on-screen keyboard appears. You can move the cursor to
enter the URL address. After completing the URL address, select
Done.



3. Move the cursor to " \rightarrow " icon and press [OK] button.



4. A web page appears as shown below:




NOTES:

- The Opera browser does not support FLASH format.
- The browser is not a video source. It will not stay at the browser screen after you restart the display.


5. Change your settings

Using the remote control:



- 1. Press [button on the remote control to display the OSD menu.
- 2. Press $[\mbox{\em 1}]$ or $[\mbox{\em 1}]$ button to select the item to adjust.
- 3. Press [OK] or [-] button to enter the submenu.
- 4. In the submenu, press [▲] or [¶] button to toggle between items, press [⊸] or [⊸] button to adjust the settings. If there is a submenu, press [OK] or [⊸] button to enter the submenu.
- 5. Press [) button to return to the previous menu, or press [) button to exit from the OSD menu.

Using the display's control buttons




- 1. Press [MENU] button to display the OSD menu.
- 2. Press [▲] [▼] [+] or [—] button to select a menu item or adjust its value.
- Press [INPUT] button to confirm a menu selection and enter its submenu.
- 4. Press [MENU] button to exit from the OSD menu.

5.1. Settings

Press [HOME button.

5.1.1. Picture



Picture style

Select a predefined picture setting.

Backlight

Adjust the brightness of this display's backlight.

Colour

Adjust the colour saturation of the picture.

Sharpness

Adjust the sharpness of the picture.

Noise reduction

Reduce picture noise.

MPEG artifact reduction

Smoothen transitions and haziness of the digital picture.

Picture enhancement

Fine-tune each pixel to match the surrounding pixels and produce a brilliant, high-definition image.

- {Advanced sharpness}: Enable superior sharpness, especially on lines and contours of the picture.
- {Dynamic contrast}: Dynamically enhance the details in the dark, medium and light areas of the picture.
- {Colour enhancement}: Dynamically enhance the vividness and details of colours.

Advanced

Access advanced settings such as gamma, tint, video contrast and so on.

- {Gamma}: Adjust the non-linear setting for picture luminance and contrast.
- {Tint}: Change the colour balance.
- {Custom tint}: Customise colour balance setting. Only available if {Tint} → {Custom} is selected.
- {Video contrast}: Adjust video contrast.
- {Brightness}: Adjust the brightness.
- {Hue}: Adjust hue value.

Scan mode

Change the display area of image.

Format and edges

- {Picture format}: Change the picture format.
- {Zoom}: Expand the horizontal and vertical sizes of image simultaneously.
- {H Zoom}: Expand the horizontal size of image only.

• {V Zoom}: Expand the vertical size of image only.

Note: Zoom, H Zoom and V Zoom are available only when the Picture format setting is set to Custom Zoom.

See page 18 for the descriptions about **Picture format**.

HDMI input range


Color ranges of HDMI video format

- {Auto}: Automatic color range of HDMI video format.
- {Limit}: Limited range of HDMI video format.
- {Full}: Full range of HDMI video format.

Picture reset

Reset all your picture settings to the factory defaults.

5.1.2. Sound



Sound style

Access predefined sound settings.

Bass

Adjust to increase or decrease lower-pitched sounds.

Treble

Adjust to increase or decrease higher-pitched sounds.

Balance

Adjust to emphasize left or right audio output balance.

Volume

Adjust to increase or decrease the volume.

Minimum volume

Set the minimum volume.

Maximum volume

Set the maximum volume.

Surround mode

Set surround effect for audio performance.

Audio out (line out)

Adjust audio output volume.

Advanced

Access advanced settings to enhance your audio experience.

- {Auto volume leveling}: Enable the reduction of sudden volume changes.
- {Speaker settings}:Turn On or Off the internal speaker.
- {Clear sound}: Enhance sound quality.

- {Audio out format}: Select the type of audio output through the digital audio output connector. (HDMI only)
- {Audio out delay}: Automatically synchronize the image of this
 display to the audio from a connected home theatre.
- {Audio out offset}: Adjust the setting for audio output delay. This option is available if {Audio out delay} is switched on.

Sync. Volume

Enable or disable the Sync. Volume function. Set {On} to synchronize the volume of internal speaker and line-out. Set {Off} to adjust the volume of internal speaker and line-out, respectively.

Sound reset

Reset to the default setting.


Card OPS audio

Set OPS audio output format.

The options are: {Auto}, {Analog}, {Digital}

NOTE: When Card OPS source is selected, this item will appear on the OSD menu.

5.1.3. Tiling



Create a single large-screen matrix (video wall) that consists of up to 100 sets of display (up to 10 sets in vertical side and 10 sets on the horizontal side).

Enable

Enable or disable the Tiling function. If $\{On\}$ is selected, the display will apply the settings in $\{H \text{ monitors}\}$, $\{V \text{ monitors}\}$, $\{Position\}$, and $\{Frame \text{ comp.}\}$.

H monitors

Set how many displays in horizontal side.

V monitors


Set how many displays in vertical side.

Position

Set the position of this display in the screen matrix.

Example: 2 x 2 screen matrix (4 displays)

H monitors = 2 displays V monitors = 2 displays



Example: 5 x 5 screen matrix (25 displays)


H monitors = 5 displays V monitors = 5 displays

			H monitors			
_						
	1	2	3	4	5	Position
	6	7	8	9	10	
monitors	11	12	13	14	15	
>	16	17	18	19	20	
L	21	22	23	24	25	


Frame comp.

Turn the frame compensation function On or Off. If you select {On}, the display will adjust the image to compensate for the width of the display bezels in order to accurately display the image.

{On}



{Off}



Frame comp.H

Adjust the horizontal frame compensation.

Frame comp.V

Adjust the vertical frame compensation.

Switch on delay

When multiple displays are connected, adjust the power-on delay time (in seconds) for each display to reduce the power load.

RS232-Routing


Select the control port.

- {RS232}: Select RS232 Control.
- {LAN(RJ-45)}: Select LAN control.
- {IR}: Select the operation mode of the remote control when multiple displays are connected via an RS232C connection.
- {IR Control}: IR control of the display.
- {Normal}: All displays can be operated normally by the remote control unit.
- {Primary}: Designate this display as the primary display for remote control operation. Only this display can be operated by the remote control
- {Secondary}: Designate this display as the primary display for remote control operation. Only this display can be operated by the remote control.
- {Control Monitor-ID}: Select the ID number for the IR control of the display via the RS232C connection.
- {Card OPS RS232}: Select RS232 Control. (Only available when OPS is started.)

Auto ID

Set up $\{Monitor\ ID\}$ of the connected device according to $\{H\ monitors\}$ settings.


Example: set H monitors as 4



Note 1: To use this function, serially connect all machines with RS-232 cable and set their Network control port to RS-232.

Note 2: To use this function for DP 1.2 connectivity, the maximum resolution supported is $1920 \times 1080 / 60$ Hz @ 4 sets. For 4Kx2K/30Hz resolution, it only supports 2 sets connectivity.

5.1.4. Network



Network settings

- {Network configuration}: Select how this display should assign addresses to the network resources.
 The available options are {DHCP & Auto IP} (recommended) and {Static IP}.
- {Network type}: Select Wired (default) to set the network type.

Digital Media Renderer - DMR

Receive the multimedia files from the connected device through your network.

Network name


For multiple-display connection, you can rename each display for easy identification.

Use the on-screen keyboard or the remote control keypad to enter the name.

Clear Internet memory

Clear all cookies, bookmarks, history list and text used for auto fill.

5.1.5. General settings



Menu language

Set OSD menu language.

Monitor group

Adjust the group range of monitor from 1 to 255. The default setting is 255.

Monitor ID

Adjust the ID number for controlling the display via the RS232C connection. Each display must have a unique ID number when multiple sets of display are connected. Monitor ID number ranges from 1 to 255. The default setting is 1.

Eco mode

This setting allows you to reduce the power consumption of the display automatically.

NOTE: If Eco mode is set to "Normal", you cannot reset it to the default setting from the "Factory reset" menu. However, you can still set the Eco mode to "low power standby" manually.

Auto search

By enabling this function, the display detects and displays available signal sources automatically

Clock

Set the current date and time for the display's internal clock. NOTES:

The definition and behavior of the Daylight saving time:

The current implementation of daylight saving is a reminder tool for the user who doesn't know how to adjust the clock of daylight saving.

It does not adjust the real time clock automatically. The problem is that there are no standard rules on when to adjust the clock defined by region or country. To solve this problem, the user must be able to set the daylight saving start/end date. When daylight saving correction is on (user selectable) then the real time clock should be adjusted at the time set of the daylight saving on/off date. At the start date of daylight saving, the clock should be adjusted 1 hour forward at 2 o'clock. At the end date of daylight saving, the clock should be adjusted 1 hour backward at 2 o'clock.

The existing daylight on/off menu should be replaced by the following menu structure:

The menu item {Daylight saving} opens a submenu with the following items:

- Menu item {Daylight saving start date} Selection item {1st, 2nd, 3rd, 4th, last} Sunday of selection item {1-12 month}
- Menu item {Daylight saving stop date} Selection item {1st, 2nd, 3rd, 4th, last} Sunday of selection item {1-12 month}

- Menu item {Correction time} Selection item {0.5, 1.0, 1.5, 2.0} hour
- Menu item {Daylight saving} Selection item {on, off}

When "daylight saving" is "on", the real time clock will be adjusted automatically at the daylight saving time (e.g. April 5, 2015, 02.00 o'clock: time will be set 1 hour later or October 25, 2015, 02.00 o'clock: time will be set 1 hour earlier).

Scheduling


This function allows you to program up to 7 different scheduled time intervals for this display to activate.

You can set:


- Which input source the display will use for each scheduled activation period.
- The time for the display to turn On and turn Off.
- The days in a week for the display to activate.

NOTES:

- It is recommended that you set up the current date and time in the {Clock} menu before using this function.
- After changing the {Clock} option in the {General settings} menu, you need to set this {Scheduling} again.




1. Up to 7 schedules can be set. Go to **Status** and select **On**.




Go to **Source** and select the input source. If {Source} → {USB} is selected, you need to set the playliist. If {Source} → {BROWSER} is selected, you need to set the URL address.


NOTE: If {Source} → {Autoplay} is selected, you need to create a folder named "philips" in the root directory of the USB and place the files (pictures or videos) to display in that folder.




3. Set On time.




4. Set **Off time**.




5. Go to **Repeat modes** and select the repeat mode.



6. If {Source} → {USB} is selected, go to **Playlist setting**.



- Press [1] [7] buttons to select a file.
- Press [→] buttons to switch between Playlist and File Manager.
- Press [OK] button to set or clear the playlist.
- 7. To save the playlist, press [and select **Save list**.



NOTES:

- Each Playlist supports up to 30 files.
- Playlist will not be cleared even you set the default settings in the {Factory settings} menu. You have to manually remove the files or delete "usb schedulinglist.txt" from the USB.

Sleep timer

Switch off the display after a preset period of time.

OneWire

Connect and control your HDMI-CEC compliant devices through HDMI port to this display with the same remote control.

Local KB lock

Enable or disable the keyboard (control buttons) function of the display.

- {Unlock}: Enable the keyboard function.
- {Lock all}: Lock all keyboard functions.
- {Lock but volume}: Disable all keyboard functions except the [—] and [+] button.
- {Lock but power}: Disable all keyboard functions except the [🖒] button.
- {Lock all expect volume and power}: Disable all keyboard functions except the [—], [+] and [()] button:

RC lock

Enable or disable the button function of remote control.

- {Unlock}: Enable the remote control function.
- {Lock all}: Lock all remote control functions.
- {Lock but volume}: Disable all remote control functions except the
 and [+] button.
- {Lock but power}: Disable all remote control functions except the [b] POWER button.
- {Lock all expect volume and power}: Disable all remote control functions except the [—] [—] and [()] POWER button:

NOTE: To disable the lock function from **Local KB lock** or **RC lock**, press the buttons [and 1 9 9 8 on the remote control.

Pixel shift

For video input sources, you may select **{On}** to move the screen image automatically to protect the display from "burn-in" or "after-image" symptoms when there is no operation for 30 seconds.

Smart power

Select a backlight level to optimize the dynamic power consumption and picture contrast.

The options are: {Off}, {Standard}, {Medium}, {High}.

Wake on lan

Select {On} to turn on the display by network.

Switch on state

Select the status that will be applied to your display when you connect the power cord next time.

- {On} The display will turn on when the power cord is connected to a wall outlet.
- {Standby} The display will remain in standby mode when the power cord is connected to a wall outlet.
- {Last status} The display will return to the previous power status (on/off/standby) when removing and replacing the power cord.

Light sensor

Select **(On)** and the display will automatically adjust the backlight. This option is only available when you plug in CRD41.

Human sensor

Set the display to turn on the backlight if human presence is detected and turn off the backlight after a preset period of time.

The options are: {Off, $10 \sim 60$ } minutes. This option is only available when you plug in CRD41.

Power LED Light

Select {Off} to turn off the power LED indicator.

Logo

Select **(Off)** and the **PHILIPS** logo will not appear when you turn the display On.

Advanced power management

When this function is set to $\{On\}$, the display will automatically turn off if no signal is detected.

Source notification

When you press [b] POWER button to turn on the display from standby mode or when you change the input signal, the information OSD is displayed on the top left side of the screen.

Select {Off} to disable this function.

DisplayPort Ver.

Set the DisplayPort version to 1.1a or 1.2, this setting is only valid on DisplayPort input and output,

1.1a: Switch DisplayPort Ver. to 1.1a(default), the DisplayPort output is the clone of DisplayPort input.

1.2: Switch DisplayPortVer. to 1.2 to support MST(Multi-Stream Transport)

NOTES:

- If the display shows a black screen or works abnormally under DisplayPort source, please switch to 1.1a and turn AC off and on
- For DP daisy chain application, please select the same DP version for all PD.

Cooling Fan

Select {On} to turn on the cooling fan permanently. Select {Auto} and the cooling fan turns on according to display's temperature.

NOTES:

- Select the default {Auto} option, and the cooling fan will start running if the temperature reaches 45°C (113°F). The cooling fan will stop running if the temperature reaches 43°C (109°F).
- A temperature warning message will appear on the screen if the temperature reaches 58°C (136°F). All key functions except
 key will then be disabled.
- Once the temperature reaches 60°C (140°F), the display's power will be shut down automatically.

Factory settings

Reset the settings to the factory defaults.

5.1.6. Advanced



litter clean

Turn on/off Jitter cleaning function for HDMI and DVI signal quality enhancement. The default setting is On.


EO boost

Adjust digital signal EQ boost.

USB copying

Copy user logo "Welcomelogo.png" to your internal memory.

5.1.7. Help





6. USB device compatibility

USB Video Subtitle Formats (for language subtitles, etc.)

File Extensions	Container	Video codec	Maximum resolution	Max.Frame Rate (fps)	Max.Bit Rate (Mbps)	Audio codec
		MPEG-1	1920×1080	25p,30p,50i,60i	30	MPEG-1(L1&L2),
	.mpg	MPEG-2	1920×1080	25p,30p,50i,60i	30	MPEG-1,2,2.5 L3,
mpeg	PS	MPEG-4 ASP	1920×1080	25p,30p,50i,60i	30	AAC/HE-AAC(v1&v2),
.vob		H.264	1920×1080	25p,30p,50p,60p,60i	30	DVD-PCM
		MPEG-2	1920×1080	25p,30p,50i,60i	30	
		MPEG-4 ASP	1920×1080	25p,30p,50i,60i	30	
.ts	TS	H.264	1920×1080	25p,30p,50p,60p,60i	30	MPEG-1(L1&L2), MPEG-1,2,2.5 L3,
.13	13	MVC	1920x1080i@field rate=50, 60Hz 1920x1080p@frame rate=24, 25,30Hz 1280x720p@frame rate=50, 60Hz	-	30	AAC/HE-AAC (v1&v2)
		MPEG-2	1920×1080	25p,30p,50i,60i	30	
.ts		MPEG-4 ASP	1920×1080	25p,30p,50i,60i	30	
.m2ts	M.TC TTC	H.264	1920×1080	25p,30p,50p,60p,60i	30	MPEG-1(L1&L2),
.mts MaTS TTS -	MVC	1920x1080i @ field rate=50, 60Hz 1920x1080p @ frame rate=24, 25,30Hz 1280x720p @ frame rate=50, 60Hz	-	30	MPEG-1,2,2.5 L3, AAC/HE-AAC (v1&v2)	
.ts		MPEG-2	1920×1080	25p,30p,50i,60i	30	MPEG-1(L1&L2),
.m2ts	AVCHD	MPEG-4 ASP	1920×1080	25p,30p,50i,60i	30	MPEG-1,2,2.5 L3,
.mts	H.26		1920×1080	25p,30p,50p,60p,60i	30	AAC/HE-AAC (v1&v2)
.ts .m2ts .mts	AVCHD	MVC	1920×1080i@field rate=50, 60Hz 1920×1080p@frame rate=24, 25,30Hz 1280×720p @ frame rate=50, 60Hz	-	30	MPEG-1(L1&L2), MPEG-1,2,2.5 L3, AAC/HE-AAC (v1&v2)
.m4v	M4V	H.264	1920×1080	25p,30p,50p,60p,60i	30	AAC
		H.264	1920×1080	25p,30p,50p,60p,60i	30	
.ism/Manifest .mpd	frag MP4	MVC	1920x1080i@field rate=50, 60Hz 1920x1080p@frame rate=24, 25,30Hz 1280x720p @ frame rate=50, 60Hz	-	30	AAC/HE-AAC(v1&v2), WMA,WMA-PRO
		MPEG-4 ASP	1920×1080	25p,30p,50i,60i	30	
		H.264	1920×1080		30	
.mp4 MP4	MVC	1920x1080i@field rate=50, 60Hz 1920x1080p@frame rate=24, 25,30Hz 1280x720p @ frame rate=50, 60Hz	-	30	AAC/HE-AAC(v1&v2), WMA,WMA-PRO	
		WMV9/VC1	1920×1080	30p,60i	30	
		MPEG-4 ASP	1920×1080	25p,30p,50i,60i	30	MPEG-1(L1&L2),
.mkv .mk3d	MKV	H.264	1920×1080		30	MPEG-1,2,2.5 L3, AAC/HE-AAC (v1&v2), WMA,WMA-PRO

USB Multimedia Formats

File Extensions	Container	Video codec	Maximum resolution	Frequency (kHz)	Max.Bit Rate (Mbps)	Audio codec
.mp3	MP3	-	-	48	384	MPEG-1,2,2.5 L3
.wma .asf	WMA (V2 up to V9.2)	-	-	48	192	WMA
.wma	WMA Pro	-	-	96	768	WMA,WMA Pro
.wav(PC)	LPCM	-	-	192	768	LPCM
.aif(mac)	LPCM	-	-	192	768	LPCM
.aac .mp4 .m4a	AAC	-	-	48	1024	AAC,HE-AAC(v1&v2)
.pls .m3u	Playlists	-	-	-	-	-
.m4a	M4A	-	-	48	1024	AAC,HE-AAC(v1&v2)

NOTES:

- Sound or video may not work if the contents have a standard bit rate/frame rate above the compatible Frame/sec listed in the table above.
- Video content with a Bit rate or Frame rate larger than the rate specified in the table above can cause choppy video during playback.

7. Input Mode

VGA Resolution:

Standard	Active R	esolution	Refresh Rate	Pixel Rate	Assat Datis	Ctord for Mode
Resolution	H Pixels	V Lines	Neiresti Nate	rixei Nate	Aspect Ratio	Stand for Mode
			60 Hz	25.175 MHz		
VGA	640	480	72 Hz	31.5 MHz	4:3	Video Graphic Array
			75 Hz	31.5 MHz		
WVGA	720	400	70 Hz	33.75 MHz	16:9	Wide Video Graphic Array
SVGA	800	600	60 Hz	40 MHz	4:3	Suppos//CA
SVGA	000	600	75 Hz	49.5 MHz	4:3	SuperVGA
XGA	1024	1024 768	60 Hz	65 MHz	4:3	Extended Graphic Array
\\ \dag{A}	1024		75 Hz	78.75 MHz		
WXGA	1280	768	60 Hz	79.5 MHz	5:3	Wide XGA
WXGA	1280	800	60 Hz	79.5 MHz	16:10	Wide XGA
SXGA	1280	960	60 Hz	108 MHz	4:3	Super XGA
SXGA	1280	1024	60 Hz	108 MHz	5:4	Super XGA
WXGA	1360	768	60 Hz	85.5 MHz	16:9	Wide XGA
WXGA	1366	768	60 Hz	85.5 MHz	16:9	Wide XGA
UXGA	1600	1200	60 Hz	162 MHz	4:3	Ultra XGA
HD1080	1920	1080	60 Hz	148.5 MHz	16:9	HD1080

SDTV Resolution:

Standard	Active R	esolution	Refresh Rate	Pixel Rate	Aspect Patie	Stand for Mode
Resolution	H Pixels	V Lines	Neiresii Nate	rixei Nate	Aspect Ratio	Stand for Mode
480i	720	480	29.97 Hz	13.5 MHz	4:3	Modified NTSC Standard
480p		400	59.94 Hz	27 MHz		
576i	720	576	25 Hz	13.5 MHz	4:3	Modified DAI Standard
576p		3/6	50 Hz	27 MHz	4:3	Modified PAL Standard

HDTV Resolution:

Standard	Active R	esolution	Refresh Rate	Pixel Rate	Aspect Ratio	Stand for Mode
Resolution	H Pixels	V Lines	Nell'esti Nate	Fixel Nate	Aspect Natio	Stand for Prode
720-	1280	720	50 Hz	74.25 MHz	16:9	Namelly DVB Made
720p	1200	/20	60 Hz	74,23 1102	10.7	Normally DVB Mode
1080i	1920	1080	25 Hz	74.25 MHz	16:9	Name ally ATCC Made
10001	1720	1000	30 Hz	74,23 1102	10.7	Normally ATSC Mode
1080p	1920	1080	50 Hz	148.5 MHz	16:9	Normally ATSC Mode
Ισουρ	1720	1000	60 Hz	170,511112	10.7	Mornially ATSC Mode


- The PC text quality is optimum in HD 1080 mode (1920 \times 1080, 60Hz).
- · Your PC display screen might appear different depending on the manufacturer (and your particular version of Windows).
- Check your PC instruction book for information about connecting your PC to a display.
- If a vertical and horizontal frequency-select mode exists, select 60Hz (vertical) and 31.5KHz (horizontal). In some cases, abnormal signals (such as stripes) might appear on the screen when the PC power is turned off (or if the PC is disconnected). If so, press the [INPUT] button to enter the video mode. Also, make sure that the PC is connected.
- · When horizontal synchronous signals seem irregular in RGB mode, check PC power saving mode or cable connections.
- The display settings table complies to the IBM/VESA standards, and based on the analog input.
- The DVI support mode is regarded as same to the PC support mode.
- The best timing for the vertical frequency to each mode is 60Hz.

8. Pixel Defect Policy

We strive to deliver the highest quality products and use some of the industry's most advanced manufacturing processes whilst practicing stringent quality control. However, pixel or sub-pixel defects on the PDP / TFT panels used in Plasma- & LCD- displays are sometimes unavoidable. No manufacturer can guarantee that all panels will be free from pixel defects, but Philips guarantees that any Plasma- & LCD- displays with an unacceptable number of defects will be repaired during the warranty period in line with your local guarantee conditions.

This notice explains the different types of pixel defects and defines the acceptable defect level for the LCD screen. In order to qualify for repair under warranty, the number of pixel defects must exceed a certain level as shown in the reference table. If the LCD screen is within specification a warranty exchange / claim back will be refused. Additionally, because some types or combinations of pixel defects are more noticeable than others, Philips sets even higher quality standards for those.

8.1. Pixels and Sub-Pixels




A pixel, or picture element, is composed of three sub-pixels in the primary colors of red, green and blue. Many pixels together form an image. When all sub-pixels of a pixel are lit, the three colored sub-pixels together appear as a single white pixel. When all are dark, the three colored sub-pixels together appear as a single black pixel. Other combinations of lit and dark sub-pixels appear as single pixels of other colors.

8.2. Types of Pixel Defects + Dot Definition

Pixel and sub-pixel defects appear on the screen in different ways. There are three categories of pixel defects and several types of sub-pixel defects within each category.

Dot definition = What is a defective "Dot"?:

One or more defective, adjacent sub-pixel are defined as one "dot". The no. of defective sub-pixels are not relevant to define a defective dot. This means that a defective dot can consist of one, two or three defective sub-pixels which can be dark or lit.



One dot = One Pixel; consists of three sub-pixels of Red, Green, and Blue.


8.3. Bright Dot Defects

Bright dot defects appear as pixels or sub-pixels that are always lit or "on". These are the examples of bright dot defects:



8.4. Dark Dot Defects

Black dot defects appear as pixels or sub-pixels that are always dark or "off". These are the examples of black dot defects:



8.5. Proximity of Pixel Defects

Because pixel and sub-pixels defects of the same type that are nearby one another may be more noticeable, Philips also specifies tolerances for the proximity of pixel defects. In the table below you can find specifications about:

- Allowed amount of adjacent dark dots = (adjacent dark dots =1 pair of dark dots)
- Minimum distance between dark dots
- Total no. of all defective dots

8.6. Pixel Defect Tolerances

In order to qualify for repair due to pixel defects during the warranty period, a PDP / TFT panel in a Philips Plasma / LCD- display must have pixel or sub-pixel defects exceeding the tolerances listed in the following table.

BRIGHT DOT EFFECT	ACCEPTABLE LEVEL
1 lit sub pixel	2
BLACK DOT EFFECT	ACCEPTABLE LEVEL
1 dark sub pixel	10
TOTAL DOT DEFECTS OF ALL TYPES	12

NOTE: * 1 or 2 adjacent sub pixel defects = 1 dot defect

8.7. **MURA**

Dark spots or patches may occasionally appear on some liquid crystal display (LCD) panels. This is known within the industry as Mura, which is a Japanese term for "unevenness." It is used to describe an irregular pattern or area in which uneven screen uniformity appears under certain conditions. Mura is a result of the deterioration of the liquid crystal alignment layer and is most commonly caused by long-term operation under high ambient temperatures. It is an industry- wide phenomenon and Mura is not repairable. It is also not covered by our warranty terms.

Mura has been around since the introduction of LCD technology and with screens getting bigger and in operation 24/7, many displays are running in low light conditions. This all adds to the possibility of Mura affecting displays.

HOW TO SPOT MURA

There are many symptoms of Mura and also multiple causes. Several of these are listed below:

- Impurities or foreign particles in the crystal matrix
- · Uneven distribution of LCD matrix during manufacturing
- Non-uniform luminance distribution of the backlight
- Panel assembly induced stress
- · Flaws within the LCD cells
- Thermal induced stress high temperature operation over long periods of time

HOW TO AVOID MURA

Although we can not guarantee the complete eradication of Mura every time, in general the appearance of Mura can be minimized by these methods:

- · Lower the backlight brightness
- Use a screen saver
- · Reduce the ambient temperature around the unit

9. Cleaning and Troubleshooting

9.1. Cleaning

Caution When Using the Display

- Do not bring your hands, face or objects close to the ventilation holes of the display. The top of the display is usually very hot due to the high temperature of exhaust air being released through the ventilation holes. Burns or personal injuries may occur if any body parts are brought too close. Placing any object near the top of the display could also result in heat related damage to the object as well as the display itself.
- Be sure to disconnect all cables before moving the display. Moving the display with its cables attached may damage the cables and thus cause fire
 or electric shock.
- · Disconnect the power plug from the wall outlet as a safety precaution before carrying out any type of cleaning or maintenance procedure.

Front Panel Cleaning Instructions

- · The front of the display has been specially treated. Wipe the surface gently using only a cleaning cloth or a soft, lint-free cloth.
- If the surface becomes dirty, soak a soft, lint-free cloth in a mild detergent solution. Wring the cloth to remove excess liquid. Wipe the surface of the display to remove dirt. Then use a dry cloth of the same type to dry.
- Do not scratch or hit the surface of the panel with fingers or hard objects of any kind.
- Do not use volatile substances such as insert sprays, solvents and thinners.

Cabinet Cleaning Instructions

- If the cabinet becomes dirty, wipe the cabinet with a soft, dry cloth.
- If the cabinet is extremely dirty, soak a lint-free cloth in a mild detergent solution. Wring the cloth to remove as much moisture as possible. Wipe the cabinet. Use another dry cloth to wipe over until the surface is dry.
- Do not allow any water or detergent to come into contact with the surface of the display. If water or moisture gets inside the unit, operating
 problems, electrical and shock hazards may result.
- Do not scratch or hit the cabinet with fingers or hard objects of any kind.
- Do not use volatile substances such as insert sprays, solvents and thinners on the cabinet.
- Do not place anything made from rubber or PVC near the cabinet for any extended periods of time.

9.2. Troubleshooting

Symptom	Possible Cause	Remedy
No picture is displayed	 The power cord is disconnected. The main power switch on the back of the display is not switched on. The selected input has no connection. The display is in the standby mode. 	 Plug in the power cord. Make sure that the power switch is switched on. Connect a signal connection to the display.
Interference displayed on the display or audible noise is heard	Caused by surrounding electrical appliances or fluorescent lights.	Move the display to another location to see if the interference is reduced.
Color is abnormal	The signal cable is not connected properly.	Make sure that the signal cable is attached firmly to the back of the display.
Picture is distorted with abnormal patterns	 The signal cable is not connected properly. The input signal is beyond the capabilities of the display. 	 Make sure that the signal cable is attached firmly. Check the video signal source to see if it is beyond the range of display. Please verify its specifications with this display's specification.
Display image doesn't fill up the full size of the screen	 The zoom mode is not set correctly. Scan Mode may be set incorrectly to underscan. If the image exceeds the screen size, Scan Mode may need to be set to Underscan. 	Use the Zoom mode or Custom zoom function in the Screen menu to fine tune display geometry and time frequency parameter.
Can hear sound, but no picture	Source signal cable is connected improperly.	Make sure that both video inputs and sound inputs are correctly connected.
Can see picture but no sound is heard	 Source signal cable is connected improperly. Volume is turned all the way down. {Mute} is turned on. No external speaker is connected. 	 Make sure that both video inputs and sound inputs are correctly connected. Press [+] or [-] button to hear sound. Switch MUTE off by using the [•6] button. Connect external speakers and adjust the volume to a suitable level.
Some picture elements do not light up	Some pixels of the display are off.	This display is manufactured using an extremely high level of precision technology: however, sometimes some pixels of the display may not display. This is not a malfunction.
After-Images can still be seen on the display after the display is powered off. (Examples of still pictures include logos, video games, computer images, and images displayed in 4:3 normal mode)	A still picture is displayed for an over extended period of time	Do not allow a still image to be displayed for an extended period of time as this can cause a permanent after-image to remain on the display.

How to setup the settings in the menu to control all the monitors at the same time and individually via RC?	Daisy chained by RS232 and no IR cable	1.The first display sets as "Primary" on OSD (Advanced option/IR control item), others set as "Secondary".
		2. The setup OSD will show on top left side of the display. (Toggle MENU will show again if it disappears)
		3. Default setting: ID NO: 0, GP NO: 0, this setting can control all displays by IR.
		The "+","-" can change "ID NO" to control signal display by "Monitor ID".
		The "UP", "DOWN" can change "GP NO" to control multi-display by "Group ID".
		*The first display is always controlled by IR.
How does the RC work?	Daisy chain : no connection of RS232 and IR cable	No setting is required. Connect with IR cables and control by IR.
		*This may cause out-of-synchronizm phenomenon. It is suggested to use the above settings with RS-232 cable.

10. Technical Specifications

Display:

Item	Specifications
Screen Size (Active Area)	48.5" (123.2 cm) LCD
Aspect Ratio	16:9
Number of pixels	1920 (H) × 1080 (V)
Pixel pitch	0.559 (H) × 0.559 (V) [mm]
Displayable colors	1.07B colors
Brightness (typical)	450 cd/m ²
Contrast ratio (typical)	1300:1
Viewing angle	178 degrees

In/Out Terminals:

Item		Specifications		
Speaker Output	Internal Speakers External Speakers	10W (L) + 10W (R) [RMS]/8Ω 1 Way 1 Speaker System 82 dB/W/M/160 Hz ~ 13 KHz		
Audio Output	3.5mm phone jack × 1	0.5V [rms] (Normal) / 2 Channel (L+R)		
Audio Input	RCA Jack × 2 3.5mm phone jack × 1	0.5V [rms] (Normal) / 2 Channel (L+R)		
RS232C	2.5mm Phone jack × 2	RS232C in/RS232C out		
RJ-45	RJ-45 Jack x 1 (8 pin)	10/100 LAN Port		
HDMI Input	HDMI Jack × 2 (Type A) (18 pin)	Digital RGB:TMDS (Video + Audio) MAX: Video - 720p, 1080p, 1920 × 1080/60 Hz (WUXGA) Audio - 48 KHz/ 2 Channel (L+R) Supports LPCM only		
DVI-D Input	DVI-D jack	Digital RGB:TMDS (Video)		
VGA Input	D-Sub Jack x 1 (15 pin)	Analog RGB: 0.7V [p-p] (75Ω), H/CS/V:TTL (2.2kΩ), SOG: 1V [p-p] (75Ω) MAX: 720p, 1080p, 1920 × 1080/60 Hz (WUXGA)		
DVI-I (DVI-D &VGA) Output	DVI-I Jack x 1 (29 pin)	Digital RGB:TMDS (Video) Analog RGB: 0.7V [p-p] (75Ω), H/CS/V:TTL (2.2kΩ), SOG: 1V [p-p] (75Ω) MAX: 720p, 1080p, 1920 × 1080/60 Hz (WUXGA)		
Component Input	BNC Jack x 3	Y: 1V [p-p] (75Ω), Pb: 0.7V [p-p] (75Ω), Pr: 0.7V [p-p] (75Ω) MAX: 480i, 576i, 480p, 576p, 720p, 1080i, 1080p		
Video Input	BNC x 1 (Share with Component_Y)	Composite 1V [p-p] (75Ω)		
Displayport in/out	Displayport Jack × 2 (20 pin)	Digital RGB:TMDS (Video + Audio) MAX: Video - 720p, 1080p, 1920 × 1080/60 Hz (WUXGA) Audio - 48 KHz/ 2 Channel (L+R) Supports LPCM only		

General:

Item	Specifications
Power Input	100 - 240V~, 50 - 60Hz, 6.0A
Power Output	100 - 240V~, 50 - 60Hz, 2.5A
Power Consumption (Max)	235 W
Power Consumption (typ.)	110 W
Power Consumption (Standby & Off)	<0.5 W (RS232 in active)
Dimensions (without stand) $[W \times H \times D]$	1077.7 × 607.9 × 93.5 (@Wall mount) / 103.8 (@Handle)
Weight (without stand)	21.6 Kg
Gross Weight (without stand)	33.5 Kg
Energy Efficiency Class	A
Visible Screen Size	123.2 cm / 48.50 inch
On Mode Power Consumption (W)	76 W
Annual Energy Consumption (kWh)	111 kWh
Standby Power Consumption (W)	0.50 W
Off Mode Power Consumption (W)	0.50 W
Display Resolution (Pixels)	1920 × 1080p
Network Standby (W)	1W

Environmental Condition:

Item		Specifications
Temperature	Operational	0 ~ 40°C
	Storage	-20 ~ 60°C
Humidity	Operational	20 ~ 80% RH (No condensation)
	Storage	5 ~ 95% RH (No condensation)
Altitude	Operational	0 ~ 3,000 m
	Storage / Shipment	0 ~ 9,000 m

Internal Speaker:

Item	Specifications
Туре	1 Way 1 Speaker
Input	10 W (RMS)
Impedance	8Ω
Output Sound Pressure	82 dB/W/M
Frequency Response	160 Hz ~ 13 KHz



2017 © Koninklijke Philips N.V. All rights reserved.

Philips and the Philips Shield Emblem are registered trademarks of Koninklijke Philips N.V. and are used under license from Koninklijke Philips N.V.

Specifications are subject to change without notice.