

**Philips** 

LCD monitor with LED backlight

V Line

27" (68.6 cm)

273V5QHAB

# Great LED images in vivid colors

### with stereo speakers

Enjoy vibrant AMVA LED pictures on this big Philips display. Equipped with HDMI and stereo speakers, it's a great choice!

### Vivid pictures every time

- · AMVA LED for wide-view super-high contrast, vivid images
- SmartContrast for rich black details
- 16:9 Full HD display for best viewing experience
- Easy display performance tuning with SmartControl Lite

### Experience multimedia

- Built-in stereo speakers for multimedia
- HDMI-ready for Full HD entertainment

### **Great choice**

- · Compact design saves space
- Mercury Free eco-friendly display
- · VESA mount allows for flexibility



## Highlights

### **AMVA LED** display



Philips AMVA LED display uses an advanced multi-domain vertical alignment technology which gives you super-high static contrast ratios for extra vivid and bright images. While standard office applications are handled with ease, it is especially suitable for photos, webbrowsing, movies, gaming, and demanding graphical applications. It's optimized pixel management technology gives you 178/178 degree extra wide viewing angle, resulting in crisp images even in 90 degree pivot mode

### **Built-in stereo speakers**

A pair of high quality stereo speakers built into a display device. It can be visible front firing, or invisible down firing, top firing, rear firing, etc depending on model and design.

### **SmartControl Lite**

SmartControl Lite is the next generation 3D icon based GUI monitor control software. This allows user to fine-tune most parameters of the monitor like Color, Brightness, screen calibration, Multi-media, ID management, etc with the mouse.

#### **SmartContrast**



SmartContrast is a Philips technology that analyzes the contents you are displaying, automatically adjusting colors and controlling backlight intensity to dynamically enhance contrast for the best digital images and videos or when playing games where dark hues are displayed. When Economy mode is selected, contrast is adjusted and backlighting fine-tuned for just-right display of everyday office applications and lower power consumption.

### 16:9 Full HD



The Full HD screen has the widescreen resolution of  $1920 \times 1080p$ . This is the highest resolution of HD sources for the best possible picture quality. It is fully future proof as it

supports 1080p signals from all sources, including the most recent like Blu-ray and advanced HD game consoles. The signal processing is extensively upgraded to support this much higher signal quality and resolution. It produces brilliant flicker-free progressive scan pictures with superb brightness and colors.

### **HDMI Ready**





HDMI-read

An HDMI-ready device has all the required hardware to accept High-Definition Multimedia Interface (HDMI) input. A HDMI cable enables high-quality digital video and audio all transmitted over a single cable from a PC or any number of AV sources (including set-top boxes, DVD players, A/V receivers and video cameras).

### **Mercury Free**

Philips monitors with LED backlighting are free of Mercury content, one of the most toxic natural substances, which affects humans and animals. This reduces the environmental impact of the display throughout its life-cycle, from manufacturing to disposal.

















### **Specifications**

### Picture/Display

- LCD panel type: AMVA LCD
- · Backlight type: W-LED system
- Panel Size: 27 inch / 68.6 cm
- Effective viewing area: 597.6 (H) x 336.15 (V)
- Aspect ratio: 16:9
- Optimum resolution: 1920 x 1080 @ 60 Hz
- Response time (typical): 4 ms (Gray to Gray)\*
- Brightness: 300 cd/m<sup>2</sup>
- SmartContrast: 10,000,000:1
- Contrast ratio (typical): 3000:1
- Pixel pitch:  $0.311 \times 0.311 \text{ mm}$
- Viewing angle: 178° (H) / 178° (V), @ C/R > 10
- Display colors: 16.7 M
- Scanning Frequency: 30 -83 kHz (H) / 56 -75 Hz (V)
- sRGB

### Connectivity

- Signal Input: VGA (Analog), DVI-D (digital, HDCP), HDMI (digital, HDCP)
- Sync Input: Separate Sync, Sync on Green
- Audio (In/Out): PC audio-in, Headphone out

### **Convenience**

- Built-in Speakers: 2W x 2
- User convenience: Auto/Down, Brightness/Back, Menu/OK, Power On/Off, Volume/Up
- OSD Languages: Brazil Portuguese, Czech, Dutch, English, Finnish, French, German, Greek, Hungarian, Italian, Japanese, Korean, Polish, Portuguese, Russian, Simplified Chinese, Spanish, Swedish, Traditional Chinese, Turkish, Ukranian
- Other convenience: Kensington lock, VESA mount (100×100mm)
- Plug & Play Compatibility: DDC/CI, Mac OS X, sRGB, Windows 7, Windows 8

### Stand

• Tilt: -5/20 degree

#### **Power**

- On mode: 26.64 W (typ.) (EnergyStar 6.0 test method)
- Standby mode: 0.5 W (typ.)
- Off mode: 0.3 W (typ.)
- Power LED indicator: Operation White, Standby mode- White (blinking)
- Power supply: Built-in, 100-240VAC, 50-60Hz

### **Dimensions**

- Product with stand (mm): 646 x 471 x 240 mm
- Product without stand (mm): 646 x 398 x 57 mm
- Packaging in mm (WxHxD): 698 x 482 x 139 mm

### Weight

- Product with stand (kg): 4.53 kg
- Product without stand (kg): 4.00 kg
- Product with packaging (kg): 6.17 kg

### **Operating conditions**

- Temperature range (operation): 0°C to 40°C °C
- Temperature range (storage): -20 $^{\circ}$ C to 60 $^{\circ}$ C  $^{\circ}$ C
- Relative humidity: 20%-80 %
- Altitude: Operation: +12,000ft (3,658m), Nonoperation: +40,000ft (12,192m)
- MTBF: 30,000 hour(s)

### Sustainability

- Environmental and energy: EnergyStar 6.0, RoHS, Lead-free, Mercury Free
- $\bullet$  Recyclable packaging material: 100 %

### Compliance and standards

 Regulatory Approvals: BSMI, CE Mark, FCC Class B, GOST, PSB, SASO, SEMKO, TCO Certified, TUV/ISO9241-307, cETLus, WEEE

### Cabinet

- Color: Black
- Finish: Hairline (front bezel) /Texture (rear cover)



Issue date 2019-11-07

© 2019 Koninklijke Philips N.V. All Rights reserved.

Version: 6.0.1

Specifications are subject to change without notice. Trademarks are the property of Koninklijke Philips N.V. or their respective owners.

12 NC: 8670 001 03519 EAN: 87 12581 69000 7 \* HDMI cables vary depending on region and models.

\* Response time value equal to SmartResponse

www.philips.com